



INDUSTRIAL TRUCK DIVISION



OPERATORS MANUAL

**FOR
CF 20-25**

1st REVISION

0-147

CLARK EQUIPMENT COMPANY

PUBLISHED BY

TECHNICAL SERVICE DEPARTMENT,
BATTLE CREEK, MICHIGAN, U.S.A.

SAFETY INSTRUCTIONS FOR MAINTAINING INDUSTRIAL TRUCKS

Powered industrial trucks may become hazardous if adequate maintenance is neglected. Therefore, adequate maintenance facilities, personnel and procedures should be provided.

Maintenance and inspection of all powered industrial trucks should be performed in conformance with the recommendation in this manual and the following practices.

1. A scheduled preventive maintenance, lubrication, and inspection system should be followed.
2. Only qualified and authorized personnel should be permitted to maintain, repair, adjust, and inspect industrial trucks.

3. Before Leaving The Truck:

- A. Stop truck.
- B. Fully lower the load engaging means.
- C. Place directional controls in neutral.
- D. Apply the parking brake.
- E. Stop the engine or turn off power.
- F. Lock the control or ignition circuit.
- G. Block the wheels if truck is on a ramp, or being worked on.

4. Before Working On Truck:

- A. Raise wheels free of floor or disconnect power source.
- B. Use chocks or other positive truck positioning devices.
- C. Block load engaging means, innermast(s), or chassis before working under them.

Before working on engine fuel system of gasoline powered trucks with gravity feed fuel systems, be sure fuel shutoff valve is closed.

Before working on engine fuel system of LP gas powered trucks, close LP gas cylinder valve and run engine until fuel in system is depleted and engine stops running.

Operation to check performance of the truck or attachments should be conducted in an authorized, safe clearance area.

5. Before Starting To Operate The Truck:

- A. Be in operating position.
- B. Depress clutch (or brake pedal on automatic transmission and electric trucks).
- C. Place directional controls in neutral.
- D. Start engine or turn on power.
- E. Before operating truck, check functioning of lift and tilt systems, directional and speed controls, steering, warning devices, brakes, and any attachment. (If used)
- F. Release parking brake.

- continued -

SAFETY INSTRUCTIONS FOR MAINTAINING INDUSTRIAL TRUCKS

6. Avoid fire hazards and have fire protection equipment present. Do not use an open flame to check level, or for leakage, of fuel, electrolyte or coolant. Do not use open pans of fuel or flammable cleaning fluids for cleaning parts.
7. Properly ventilate work area, vent exhaust fumes and keep shop clean and floor dry.
8. Handle LP gas cylinders with care. Do not drop, dent, or damage in any way.
9. Brakes, steering mechanisms, control mechanisms, warning devices, lights, governors, lift overload devices, guards and safety devices should be inspected regularly and maintained in a safe operating condition.
10. All parts of lift and tilt mechanisms and frame members should be carefully and regularly inspected and maintained in a safe operating condition.
11. Special trucks or devices designed and approved for hazardous area operation should receive special attention to ensure that maintenance preserves the original, approved safe operating features.
12. Fuel systems should be checked for leaks and condition of parts. Extra special consideration should be given in the case of a leak in the fuel system. Action should be taken to prevent the use of the truck until the leak has been corrected.
13. All hydraulic systems should be regularly inspected and maintained in conformance with good practice. Tilt cylinders, valves, and other similar parts should be checked to assure that "drift" has not developed to the extent that it would create a hazard.
14. Capacity, operation and maintenance instructions plates, tags, or decals should be maintained in legible condition.
15. Batteries, motors, controllers, limit switches, protective devices, electrical conductors and connections should be inspected and maintained in conformance with good practice. Special attention should be paid to the condition of electrical insulation.
16. Industrial trucks should be kept in a clean condition to minimize fire hazards and facilitate detection of loose or defective parts.
17. Modifications and additions which affect capacity and safe truck operation should not be performed by the customer or user without manufacturers prior written approval. Capacity, operation and maintenance instruction plates, tags or decals should be changed accordingly.
18. Care should be taken to assure that all replacement parts are interchangeable with the original parts and of a quality equal to that provided in the original equipment.



INDUSTRIAL TRUCK DIVISION



PLEASE NOTE

INSTRUCTIONS ON USE OF MANUAL

This Operator's Manual is published as a service reference guide and includes Specifications, Operating Instructions, Lubrication and Preventive Maintenance Instructions, and Trouble Shooting Guide.

The TABLE OF CONTENTS for this manual is printed on green paper and is placed at the front for easy reference. A separate INDEX (also printed on green paper) is placed in front of the Lubrication and Preventive Maintenance Section.

Lubrication and Preventive Maintenance Instructions are listed under the TIME INTERVALS that they should be performed.

The TIME INTERVAL is part of the page number and code number.

Example: 8H 002-0; 8H is the TIME INTERVAL (8 operating hours), 002 is the PAGE NUMBER, and -0 is a CODE NUMBER that you as a customer should disregard. The dash number or code number is for the benefit of the publisher only.

The INDEX is set up under the TIME INTERVALS that the Lubrication and Preventive Maintenance should be performed.

Example: (8 Hours)	Time Interval (H=Hours)	&	Page Number (000-)
Hydraulic Sump Tank, level check...	8H		503
Brake Pedal Free Travel, check....	8H		303

The above states to check the sump tank fluid level every 8 operating hours and refer to page 503 for fluid recommendations etc. Also, to check brake pedal free travel at this interval and turn to page 303 for instructions.

Turn to the eight (8) hour section (8H) and then to the page listed — 503 or 303 etc. The instructions covered therein will pertain only to the checks or adjustments that should be performed at this TIME INTERVAL.

If, for instance, the Brake Pedal Free Travel is incorrect, you would then refer to the INDEX for "Brake Pedal Free Travel, adjust" which would be listed in the TIME INTERVALS following the 8 hour section.

<u>Example:</u> (100 Hours)	Time Interval (H=Hours)	&	Page Number (000-)
Brake Pedal Free Travel, adjust....	100H		302

Turn to the one hundred hour section (100H) and then to



INDUSTRIAL TRUCK DIVISION



(continued)

I N S T R U C T I O N S O N U S E O F M A N U A L

page 302. Complete instructions as to the importance of pedal free travel, the method to check and adjust for correct free travel with illustrations are included therein.

N O T E

YOU WILL NOTE THAT AT THE BEGINNING OF EVERY SECTION A LUBRICATION AND PREVENTIVE MAINTENANCE ILLUSTRATION IS SHOWN GIVING THE LOCATION OF THE COMPONENTS TO BE SERVICED.

It is impossible to cover all types of machine operations in one manual. Operating conditions should determine the lubrication and maintenance intervals. Common sense and a close observance can best determine the frequency with which you should service your machine.

The care you give your machine will greatly determine the satisfaction and service life that you will obtain from it. A definite maintenance program should be set up and followed. Haphazard maintenance will only lead to faulty performance and short life.



INDUSTRIAL TRUCK DIVISION



TABLE OF CONTENTS

<u>Page</u>	<u>Description</u>
A001	Instructions On Use Of Manual
A003	Table Of Contents
B001	Illustration Of Machine
B003	Specifications
B031	New Machine 50 Hour Inspection

O P E R A T I O N S

C002	Overall Controls
C003	Instrument Indicators
C103	Starting and Operating Instructions
C203	Fuel Tank Reserve Manual Cut-in
C303	To Move, Stack and Lower Loads. Safety and Operating Suggestions.
C401	Proper Handling of L.P. Fuel

L U B R I C A T I O N A N D P R E V E N T I V E M A I N T E N A N C E

<u>Time Interval (H-Hours)</u>	<u>& Page Number (0000-)</u>	<u>Description</u>
H	001	Index
8H	000	<u>8 Hour Lubrication & Preventive Maintenance Illustration</u>
8H	001	Horn, Fuel Tank and System Fuses
8H	003	Crankcase Oil Level check; Recommended Lubricants
8H	103	Cooling System check
8H	203	Instrument Indicators, check
8H	303	Brake Pedal Free Travel check; Parking Brake Operation check
8H	403	Engine Air Cleaner service
8H	503	Hydraulic Sump Tank Level check; Hydraulic Control Lever Operation check
8H	603	Tires inspect
8H	605	Clutch Pedal Free Travel check
8H	605	Release Bearing lubricate
100H	000	<u>100 Hour Lubrication & Preventive Maintenance Illustration</u>
100H	001	Transmission & Axle Adaptor Level check; Fuel Tank and Lines inspect
100H	003	Engine Crankcase drain & refill; Crankcase Ventilation inspect; Engine Oil Filter change
100H	103	Cooling System inspect; clean radiator fins
100H	203	Fan and Generator Belt adjustment
100H	302	Brake Pedal Free Travel check
100H	303	Brake Pedal Free Travel adjust; Master Cylinder level check
100H	403	Lift and Tilt Cylinders inspect; Lift Chains check and adjust; visually inspect all wiring and hydraulic piping; lubricate all miscellaneous linkage
100H	503	Hydraulic Sump Tank Breather inspect or replace
100H	603	Steering Gear verify lubricant level; Battery inspect
100H	653	Clutch Pedal Free Travel adjust
100H	703	Lubrication Chart
500H	000	<u>500 Hour Lubrication & Preventive Maintenance Illustration</u>
500H	001	Fuel Pump Strainer clean; Fuel Pump Operation check
500H	103	Hydraulic Sump Tank drain & refill; Hydraulic Sump Tank Oil Filter change
500H	202	Steering Gear adjust
500H	302	Steering Axle and Linkage adjust
500H	403	Manifolds check security of mounting; Nuts, Bolts and Capscrews security check



INDUSTRIAL TRUCK DIVISION



TABLE OF CONTENTS

LUBRICATION AND PREVENTIVE MAINTENANCE

Time Interval (H=Hours)	& Page Number (0000-)	Description
1000H	000	<u>1000 Hour Lubrication & Preventive Maintenance Illustration</u>
1000H	001	Engine Tune Up; Air Cleaner, Fuel Pump
1000H	003	Engine Tune Up; Cylinder Head Stud Nuts Intake and Exhaust Manifolds, Crankcase Ventilation; Intake and Exhaust Valve Clearance adjustments
1000H	004	Engine Tune Up; Intake and Exhaust Valve Clearance adjustments
1000H	103	Engine Tune Up; Compression test, Spark Plugs
1000H	203	Engine Tune Up; Distributor
1000H	204	Engine Tune Up; Tach Dwell Meter
1000H	303	Engine Tune Up; Contact Point adjustment; Ignition Timing
1000H	403	Engine Tune Up; Vacuum Test and Carburetor adjustment
1000H	503	Engine Tune Up; Governor adjustment
1000H	603	Starting Motor inspect
1000H	703	Generator inspect
1000H	803	Wheel Bearings clean and repack; adjust
1000H	805	Axle Ends clean and repack
1000H	912	Bleeding Brake System
1000H	1003	Brake adjustment
1000H	1103	Hand Brake adjustment
1000H	1202	Cooling System inspect and clean
1000H	1303	Transmission, Axle Adaptor drain and refill
1000H	1503	Main Hydraulic System Pressure checks
1000H	1803	Upright Roller lubrication and adjustments

TROUBLE SHOOTING GUIDE

Page	Description
TS 001	Engine
TS 251	Fuel System
TS 301	Clutch
TS 321	Cooling System
TS 341	Ignition System
TS 361	Starter
TS 381	Generator
TS 401	Battery & Horn
TS 421	Transmission
TS 483	Drive Axle
TS 521	Steering Axle
TS 541	Brake System
TS 653	Hydraulic System

CLARK
EQUIPMENT

INDUSTRIAL TRUCK DIVISION

CLARK
EQUIPMENT



ILLUSTRATION OF MACHINE

B001-14

28 FEB 64



INDUSTRIAL TRUCK DIVISION



SPECIFICATIONS

DISTRIBUTOR (All FOUR and SIX Cylinder Engines)

Heavy Duty Points

N O T E

Distributors are equipped with either Standard or Heavy Duty Points. Heavy Duty Points are thicker (have more contact material) than Standard Points.

Heavy Duty Points - All FOUR Cylinder Engines
Set Dwell Angle at..... 31° - 34°

Heavy Duty Points - All SIX Cylinder Engines
Set Dwell Angle at..... 22° - 26°

When connecting leads, terminals must be back to back (flat sides together). Push into slot between insulator and spring. (DO NOT push lever spring.) Then push other terminal in place between first terminal and insulator. See following illustration.

WHEN CONNECTING LEADS, THE TERMINALS MUST BE BACK TO BACK (flat sides together).....



- FOUR (4) CYLINDER ENGINES, ONLY -

Point Opening (in.)	Dwell Angle (deg.)	Centrifugal Advance							
		START		INTERMEDIATE		INTERMEDIATE		MAXIMUM	
		Eng. rpm.	Eng. adv.	Eng. rpm.	Eng. adv.	Eng. rpm.	Eng. adv.	Eng. rpm.	Eng. adv.
.022*	31-34	600	1-5	800	6-10	1600	11-15	2200	15-19
.021**	31-34	600	1-5	800	6-10	1600	11-15	2200	15-19

- SIX (6) CYLINDER ENGINES, ONLY -

Point Opening (in.)	Dwell Angle (deg.)	Centrifugal Advance							
		START		INTERMEDIATE		INTERMEDIATE		MAXIMUM	
		Eng. rpm.	Eng. adv.	Eng. rpm.	Eng. adv.	Eng. rpm.	Eng. adv.	Eng. rpm.	Eng. adv.
.020*	28-32	600	1-5	800	6-10	1600	11-15	2200	15-19
.021**	22-26	600	1-5	800	6-10	1600	11-15	2200	15-19

N O T E

Time engine with timing light and tachometer at 400 engine RPM or below to the above specifications. The initial advance RPM range is 430 - 580. Distributor advance at 600 engine RPM should be 1° to 5° . Distributor rotation (as viewed from cap end) is counterclockwise.

When checking Distributor on a test stand, the above specifications are 1/2 that shown.

*..... Four (4) or Six (6) Cylinder Engine STANDARD Points.

**..... Four (4) or Six (6) Cylinder Engine HEAVY DUTY Points.



INDUSTRIAL TRUCK DIVISION



ADJUST TAPPETS TO THE STATIC COLD SETTINGS LISTED IN THE FOLLOWING CHART:

Engine Model	Intake	Exhaust	NOTE
Y-69	.014"	.014"	Static Cold Settings.
Y-91	.014"	.014"	Static Cold Settings.
Y-112	.014"	.014"	Static Cold Settings.
F-124	.016"	.018"	Static Cold Settings.
F-140	.016"	.018"	Static Cold Settings.
F-162	.016"	.018"	Static Cold Settings.
F-244	.016"	.018"	Static Cold Settings.
F-186	.016"	.018"	Static Cold Settings.
F-209	.016"	.018"	Static Cold Settings.
F-226	.016"	.018"	Static Cold Settings.
F-135	.012"	.020"	Static Cold Settings.
F-163	.012"	.020"	Static Cold Settings.
F-227	.012"	.020"	Static Cold Settings.
F-245	.012"	.020"	Static Cold Settings.

NOTE: Engine Nameplate Tappet Settings is for Hot Idle only.

FOR -- VEHICLES EQUIPPED WITH CONTINENTAL ENGINES.



INDUSTRIAL TRUCK DIVISION



SPECIFICATIONS FOR CF20 & 25

GENERAL

Type of vehicle Fork Lift Truck

Overall length with forks	<u>CF20</u>	<u>CF25</u>	
.....	99½	102¼	inches
Overall length without forks			
.....	67½	70¼	inches
Overall width.....	32	34	inches
Overall height with 130 MFH upright.....	83 inches		

Single Drive

Tread drive tires (Std.& HiLo Upr.).....			
.....	CF20	26	inches
Tread drive tires (T.S. Upr.)	29	1/8	inches
Tread drive tires (Std.& HiLo Upr.).....			
.....	CF25	28	inches
Tread drive tires (T.S. Upr.)	30	1/8	inches
Tread steer tires (CF20 & CF25).....			
.....	24	3/4	inches

Basic aisle for right angle stacking			
.....(add length of load)CF20	73	1/8	inches
.....(add length of load)CF25	75	7/8	inches

Turning radius, outside	CF20	61	inches
.....	CF25	63	1/2 inches

Turning radius, inside (CF20 & CF25) 1 1/2 inches

Ground clearance - under counterweight..3 inches

Ground clearance - under rear axle.. 2.65 inches

Ground clearance - under front axle 3.375 inches

Ground clearance - under upright 3 inches

Ground clearance between axles..... 3.87 inches

Grade clearance 36 1/2%

Draw bar pull (Loaded)(CF20)1900 (CF25)2075 lbs.
..... at 12 inch coupler height

Draw bar pull (Empty) (CF20)1300 (CF25)1000 lbs.
..... at 12 inch coupler height

Travel speeds:	<u>CF20</u>	<u>CF25</u>	
Loaded: 1st	5.47	5.14	MPH
2nd	10.89	10.23	MPH
Empty: 1st	5.47	5.23	MPH
2nd	10.89	10.39	MPH

Gradeability:

Loaded.....	CF20	30.5%	CF25	25.8%
Empty	CF20	22.5%	CF25	17.1%
.....	@ .9 coefficient of friction			

Lifting & Lowering Speeds:

Lift	STANDARD	HI-LO	TRIPLE STAGE
Loaded	83	62	59 FPM
Empty	94	70	67 FPM
Lower.....			
Loaded	65	65	65 FPM
Empty	80	80	80 FPM

ENGINE

Model..... Y112

Type Internal Combustion

Number of cylinders 4

Bore 3 3/16

Stroke 3 1/2

Displacement 112 cu. in.

Governed Speed (No Load)..... 2350 R.P.M.

Net Brake H.P. at Governed R.P.M. 16.3

Bare Engine H.P. at Governed R.P.M.
..... 32 @ 2200

Maximum torque 88 lb. ft.

Governor Setting (Loaded)..... 2,200 R.P.M.

Firing Order 1-3-4-2

Crankcase Capacity:
With Filter 4 1/2 quarts
Without Filter 4 quarts

Lubrication System.....Pressure lubricated
by submerged gear-type pump.

FUEL TANK CAPACITY 5.4 gallons

COOLING SYSTEM CAPACITY 9 quarts

FAN BELT DEFLECTION
..... 3/4" long span

CLUTCH

Outside diameter 10 inches

Clutch Pedal Free Travel
..... approx. 5/8 to 1 inch

Clutch throwout bearing.... Lubricated thru
use of a grease cup.



INDUSTRIAL TRUCK DIVISION



SPECIFICATIONS

(CONTINUED)

TRANSMISSION

Speeds 2 Forward 2 Reverse

Capacity 3 1/2 pints

STEER AXLE

Axle Alignment:

Toe-In 0 degrees

Camber Angle 1 degree

Caster 0 degrees

Left-hand Turning radius angle,

Left wheel 80 degrees

Right wheel 55 degrees

Right-hand Turning radius angle,

Left wheel 55 degrees

Right wheel 80 degrees

DRIVE AXLE

Differential Capacity
..... (Refer to Transmission Capacity)

Drive Wheel Bearings 1 oz. approx.
(each bearing)

WHEELS AND TIRES

(Non-directional)

Size...Front... 16 1/4 x 6 x 11 1/4 cushion
(CF25 Triple Stage Upright Only)..
..... 16 1/4 x 7 x 11 1/4 cushion

Size...Rear..... 13 x 4 1/2 x 8 cushion

SPLIT RIM WHEELS

Drive Wheel 150 ft. lbs. (Dry Thread)

Steer Wheel 75 ft. lbs. (Dry Thread)

Steering Gear Pitman Arm Lock Nut Torque.....
..... 100-125 foot pounds

Steering Gear Mounting Bolts and Clamp Bolt
Torque..... 90 foot pounds

HYDRAULIC SYSTEM

Sump Tank Capacity 3.1 gallons

Sump Tank Breather (Cleanable)... Hemp Hair

Sump Tank Strainer (Cleanable).... 100 mesh

Sump Tank Filter Attaching Bolts Torque....
..... 40 to 50 inch lbs.

Hydraulic Pumps

Main Pump:

Type Vane

Capacity

6 G.P.M. at 1450 engine R.P.M. 100 PSI

Hydraulic Valve

Pressure Relief Valve Setting 2000 PSI

BRAKE SYSTEM

Type Hydraulic

Brake Pedal Free Travel

(as measured from top pedal position -to-
where pedal meets resistance from master
cylinder) 3/16 to 1/2

(as measured from bottom of floor board
-to- top of brake lever arm)... 3/16 to 1/2

DISTRIBUTOR

Rotation (viewed from drive end).....
..... Clockwise

Point Opening022

Start Advance

R.P.M. (Dist.) 300

Degree (Dist.)5-2.5

Maximum Advance

R.P.M. (Dist.) 1100

Degree (Dist.) 7.5-9.5

Cam Angle Range 31° to 34°

Spring Tension (ounces)

..... 520 oz. per. in.

SPARK PLUGS

Gap

Standard025

Resistor035

STARTER RELAY

Point Opening020-.030

Opening Voltage6 Min.



INDUSTRIAL TRUCK DIVISION



SPECIFICATIONS

(CONTINUED)

CIRCUIT BREAKER
..... @ 125° F. Regulator Ambient Temp.

Armature Air Gap..... .020

Contact Point Gap020 ± 10% Min.

Contacts Close 11.8 to 13.5 Volts

VOLTAGE REGULATOR.....
..... @ 125° F. Regulator Ambient Temp.

Armature Air Gap075 ± 10%

Operating Voltages.....13.5 to 14.4 amps

CURRENT REGULATOR
..... @ 125° F. Regulator Ambient Temp.

Armature Air Gap075 ± 10%

Operating Amperage..... 31-35.5

BATTERY (Negative Ground)
..... (Volts) 12

Number of Cells 6

Number of Plates 66

20 Hour Rate A.H. 45

150 Amps., 0 Deg. F.

Total Min. 3.3

5 Sec. Volt. 8.4

Group S.A.E.

Model 3EM45-D

STARTING MOTOR

Brush Tension (oz.) 35

Lock Test

Draw Current (Amps) 435

Volts 5.8

Torque (Ft. Lbs.) 10.5

No Load Test

Draw Current (Amps)..... 49 to 76

Volts 10.6

Speed (R.P.M.).... 6200 Min. 9400 Max.

Teeth in Pinion 9

No Teeth in Ring Gear 142

Starter to Crankshaft Ratio.... 15.77 to 1

Starting Medium Solenoid

GENERATOR

Volts 12

Brush Spring Tension 24 to 28 oz.

Type Third Brush Control

Rated Output 25 Amps

Output Test @ 80° F.

14 Volts, 25 Amps @ 1970 R.P.M.

Charging Starts Cold 25 Amps.....
750 R.P.M. (Gen.)

Charging Starts Hot 25 Amps.....
2200 R.P.M. (Gen.)

dimensional
specifications

CLARKLIFT®

UPRIGHT DIMENSION TABLE

MFH			FREE LIFT		
STD HI-LO	TSU	OAHL	STD	HI-LO	TSU
70	—	53	18	—	—
76	—	56	18	—	—
82	—	59	18	—	—
88	—	62	18	—	—
94	135	65	18	45	12½
100	144	68	18	48	12½
*106	*153	71	18	51	12½
112	162	74	18	54	12½
118	*171	77	18	57	12½
124	180	80	18	60	12½
*130	189	83	18	63	12½
136	198	86	18	66	12½
142	207	89	18	69	12½
148	216	93	18	73	12½
*154	225	96	18	76	12½
160	—	99	18	79	12½
166	—	103	18	83	12½
172	—	106	18	86	12½
*178	—	109	18	89	12½

Intermediate heights available in increments of 3" MFH.



For overall height raised — add 21" to MFH.

* Indicates preferred standard sizes.

CLARKLIFT CF 20/25
DIMENSION TABLE

DIMENSION	CF 20	CF 25
A	67-1/2"	70-1/4"
B	17-3/8"	19-7/8"
C	38"	38"
D	12-1/4"	12-1/2"
E	32"	32"
F	1-1/4"	1-1/2"
G	20"	19-3/4"
H	61"	63-1/2"
I	73-1/8"	75-1/8"
J STD	26"	28"
J TSU	29-1/8"	30-1/8"
K	30"	30"
L STD	32"	34"
L TSU	35-1/8"	37-1/8"

CF 20/25





INDUSTRIAL TRUCK DIVISION



S P E C I F I C A T I O N S

L.P. Gas and Gasoline ENGINE TORQUE SPECIFICATIONS

Engines have many studs, bolts, and cap screws of special material and sizes and it is very important that care be exercised to torque all studs and bolts correctly.

The torque specifications, foot pounds, listed below MUST be followed in order to have the engine conform to the original specifications.

Size - Diameter	5/16"	3/8"	7/16"	1/2"	9/16"	5/8"
Cylinder Heads	-----	35-40	70-85	100-110	130-140	145-155
Manifolds	15-20	25-30	40-50	50-60	50-60	60-70
Gear Covers, Water Pumps, Front and Rear End Plates	15-20	25-30	50-55	80-90	-----	-----
Oil Pans	12-16	12-16	-----	-----	-----	-----



INDUSTRIAL TRUCK DIVISION



NEW MACHINE 50 HOUR SERVICE AND INSPECTION

Air Cleaner, Service	8H 403
Battery Test and Level Check.....	100H 603
Brake Master Cylinder Level Check	100H 303
Brake Pedal, Adjust	100H 302
Clutch Pedal, Adjust	100H 653
Cooling System, Inspect.....	100H 103
Cylinder Head, Tighten	1000H 003
Engine Crankcase, Drain and Refill.....	100H 003
Engine Oil Filter, Change.....	100H 003
Fan Belt, Adjust	100H 203
Fuel Pump Strainer, Clean or Replace	500H 002
Hand Brake, Adjust	1000H 1103
Hydraulic Oil Strainer, clean	500H 103
Intake and Exhaust Manifold, Tighten	500H 403
Lift Chains, Adjust	100H 403
Lubricate Machine	100H 703
Nuts, Bolts and Capscrews, Tighten	500H 403
Pressure Check Main Hydraulic System	1000H 1503
Steering Gear Level Check	100H 603
Transmission and Axle Adaptor Level Check	100H 002

N O T E

PERFORM THIS SERVICE AND INSPECTION AFTER THE
FIRST 50 HOURS OF OPERATION ON NEW MACHINES.

OPERATIONS




Plate 7448. Overall Controls




Plate 7449. Hydraulic Control Levers




Plate 7450. Directional Control Levers




Plate 6288. Oil Pressure Indicator

a. Oil Pressure Indicator. Oil pressure should be at least 7 pounds at idle (400 to 600 R.P.M.)

CAUTION

IF THE OIL PRESSURE IS ERRATIC OR FALLS BELOW THE ABOVE LIMIT, STOP THE ENGINE IMMEDIATELY AND FIND THE CAUSE OF THE TROUBLE. REFER TO TROUBLE SHOOTING SECTION FOR THIS INFORMATION.

CAUTION

ON NEW MACHINES, AFTER STARTING THE ENGINE RUN IT AT IDLE FOR FIVE MINUTES, THEN STOP ENGINE AND RECHECK OIL LEVEL IN CRANKCASE - BRING OIL LEVEL TO HIGH MARK, IF NECESSARY.




Plate 6287. Engine Coolant Temperature Indicator

NOTE

BEFORE PLACING MACHINE IN OPERATION RUN ENGINE A FEW MINUTES TO WARM OIL, ESPECIALLY IN COLD OPERATION CONDITIONS.

LOW OPERATING TEMPERATURES WASTES FUEL AND INCREASES ENGINE WEAR.

NOTE

THE COOLANT TEMPERATURE SHOULD REGISTER 185° TO 205° F. AFTER THE FIRST TEN OR FIFTEEN MINUTES OF OPERATION.

CAUTION

DO NOT IDLE THE ENGINE FOR LONG PERIODS, AS IT IS NOT ONLY DETRIMENTAL TO THE ENGINE BUT ALSO INCREASES THE OPERATING COSTS AS YOU ARE USING FUEL WITHOUT BENEFIT.



Plate 6418. Ignition Switch

STARTING

Place all transmission control levers in neutral position. Pull out on choke button and turn ignition switch key. The starter is engaged when the key is turned to start position.

CAUTION

DO NOT ENGAGE THE STARTER LONGER THAN 15 SECONDS WITHOUT A MINUTE OR SO INTERVAL BETWEEN TRIALS.

If the engine becomes overchoked or flooded; push choke button in, depress accelerator pedal fully and engage starter. If all necessary equipment is in correct working order, the engine will start.

After engine has started, make certain that the oil pressure indicator registers adequate pressure. If an abnormal reading is indicated, stop engine and correct the difficulty.

NOTE

RUN ENGINE A FEW MINUTES TO WARM OIL, BEFORE PUTTING MACHINE TO WORK ESPECIALLY IN COLD OPERATING CONDITIONS.

TO OPERATE MACHINE

1. Place transmission levers in neutral position and start engine.
2. Release hand brake and depress clutch pedal. Position shift levers for desired speed and direction.
3. Release clutch pedal slowly and at the same time accelerate as required.
4. Travel with the forks only high enough to clear any floor obstructions.

CAUTION

DO NOT ALLOW FOOT TO REST ON CLUTCH PEDAL WHILE DRIVING FROM POINT TO POINT. RIDING THE CLUTCH PEDAL WILL CAUSE SLIPPAGE OF THE DRIVEN DISC RESULTING IN UNNECESSARY WEAR OR DAMAGE TO THE CLUTCH COMPONENTS.

TO STOP MACHINE

Remove foot from accelerator pedal and depress clutch and brake pedal. If machine is to be parked, place transmission control levers in neutral position, apply hand brake and shut off engine.

CAUTION

IF THE ENGINE HAS BEEN OPERATING AT OR NEAR FULL LOAD, IT SHOULD BE ALLOWED TO RUN AT FAST IDLE (600 to 800 R.P.M.) FOR ONE OR TWO MINUTES AFTER LOAD IS REMOVED BEFORE BEING STOPPED. THIS ALLOWS INTERNAL ENGINE TEMPERATURES TO EQUALIZE.




Plate 7236. Manual Cut-in Valve

The auxiliary fuel reserve manual cut-in valve located at the fuel tank may be turned to the auxiliary position in the event that the main fuel tank supply becomes exhausted. The reserve fuel supply of approximately 1/2 gallon will in most

cases be adequate to allow the machine to be driven to its refueling location. After the fuel supply has been replenished the manual cut-in lever should be turned to the normal position.

(ON MACHINES SO EQUIPPED)



INDUSTRIAL TRUCK DIVISION



OPERATIONS

To Move A Load.

The forks should be adjusted sidewise on the fork bars to obtain firm support and maximum balance of the load. Raise or lower the forks to the proper level and engage the load by driving forward. Tilt the upright backward sufficiently to adequately cradle the load, and raise load sufficiently to clear obstructions, accelerating engine slightly at the same time. Back away from stack.

The operator should have clear vision ahead when moving in a forward direction. When this is not possible, the operator should drive in reverse and turn in his seat to obtain clear vision backward.

When the load is to be deposited, enter the area squarely, especially when placing one load on top of another, in order that all piles will be square and secure. Place load directly over desired area and slowly lower into position. Disengage forks from the load by using necessary lift-tilt and then back away.

Loads will vary in size, shape, method of packaging, stacking procedures, etc. The best way to handle a load will depend on these factors. If in doubt, consult with your supervisor.

I M P O R T A N T

EVERY 8 OPERATING HOURS (OR EVERY SHIFT) ELEVATE UPRIGHT TO THE UPPER LIMIT. THIS WILL PROVIDE LUBRICATION TO THE TOP PORTION OF THE LIFT CYLINDER. CHECK FOR NORMAL SEQUENCE OF OPERATION.

OPERATING SAFETY RULES AND PRACTICES.

1. Operators of powered industrial trucks should be physically qualified. An examination should be made on an annual basis and include such things as field of vision, hearing, depth perception and reaction timing.

2. Only trained and authorized operators should be permitted to operate a powered industrial truck. Methods should be devised to train operators in the safe operation of powered industrial trucks. It is recommended that badges or other visual indication of the operator's authorization should be displayed at all times during work period.

GENERAL.

1. Safeguard the pedestrians at all times. Do not drive a truck up to anyone standing in front of a bench or other fixed object.

2. Do not allow anyone to stand or pass under the elevated portion of any truck, whether loaded or empty.

3. Unauthorized personnel should not be permitted to ride on powered industrial trucks. A safe place to ride should be provided where riding of trucks is authorized.

4. Do not put arms or legs between the uprights of the mast or outside the running lines of the truck.

5. When leaving a powered industrial truck unattended, load engaging means should be fully lowered, controls should be neutralized, power shut off, brakes set, key or connector plug removed. Block wheels if truck is parked on an incline.

6. Maintain a safe distance from the edge of ramps or platforms and do not, while on any elevated dock or platform, push freight cars. Do not use trucks for opening or closing freight doors.

7. Have brakes set and wheel blocks in place to prevent movement of trucks, trailers, or railroad cars while loading or unloading. Fixed jacks may be necessary to support a semi-trailer during loading or unloading when the trailer is not coupled to a tractor. Check the flooring of trucks, trailers, and railroad cars for breaks and weakness before driving onto them.

8. Be sure of sufficient headroom under overhead installations, lights, pipes, sprinkler system, etc.

9. Use an Overhead Guard and Load Backrest Extension unless conditions prevent their use.

```
x x x x x x x x x x x x x x x x x x x x x
x
x           W A R N I N G           x
x
x AN OVERHEAD GUARD IS INTENDED TO OFFER x
x PROTECTION FROM THE IMPACT OF SMALL x
x PACKAGES, BOXES, BAGGED MATERIAL, ETC., x
x REPRESENTATIVE OF THE JOB APPLICATION, x
x BUT NOT TO WITHSTAND THE IMPACT OF A x
x FALLING CAPACITY LOAD. x
x
x x x x x x x x x x x x x x x x x x x x x
```

10. Use only approved industrial trucks in hazardous locations.



INDUSTRIAL TRUCK DIVISION



FUEL HANDLING AND STORAGE SAFETY

Liquefied Petroleum Gas Fuel (LPG Powered Trucks)

1. The storage and handling of liquefied petroleum gas (LP-Gas) should be in accordance with the Standard for Storage and Handling of Liquefied Petroleum Gases (NFPA No. 58, USA Standard Z106.1-1965).
2. Trucks using LP-Gas should be refueled only at locations designated for that purpose. Safe outdoor locations are preferable to indoor. Trucks should be refueled as provided in the Standard for the Storage and Handling of Liquefied Petroleum Gases (NFPA No. 58, USA Standard Z106.1-1965.)
3. Reasonable care should be exercised in handling of LP-Gas containers to avoid damage. Do not drop, throw, roll, or drag LP-Gas containers or any associated parts of the containers or fuel systems.
4. Do not over-fill LP-Gas containers.
5. Engine should be stopped and operator off the truck during refueling.
6. Trained and designated personnel should recharge or exchange LP-Gas containers.
7. Personnel engaged in recharging of LP-Gas containers should wear protective clothing such as face shield, long sleeves, and gauntlet gloves.
8. Never use a match or flame to check for leaks, use a soap solution.
9. LP-Gas powered trucks should not be refueled nor stored near underground entrances, elevator shafts nor any other place where LP-Gas could collect in a pocket causing a potentially dangerous condition.
10. Trucks equipped with permanently mounted LP-Gas containers should be refueled outdoors.
11. Exchange of removable LP-Gas containers preferably should be done outdoors, but may be done indoors. Means should be provided in the fuel system to minimize the escape of fuel when the containers are exchanged. This should be accomplished by either of the following methods:
 - A. Using an automatic quick closing coupling (a type closing in both directions when uncoupled) in the fuel line, or.....
 - B. Closing the valve at the LP-Gas container and allowing the engine to run until the fuel in the line is consumed.
12. When installing removable LP-Gas containers they should be so located on the truck that the safety pressure relief valve opening is always in contact with the vapor space (top) of the cylinder. This is accomplished by an indexing pin which, when the tank is properly installed, positions the container.
13. All reserve LP-Gas containers should be stored and transported with the service valve closed. Safety relief valves should have direct communication with the vapor space of the container at all times.
14. The careless handling of LP-Gas containers can result in a serious accident. Extreme care should be exercised when transporting containers so that they are not accidentally dropped or physically damaged. When it is necessary to move more than one container at one time, a proper carrying device should be provided.
15. Physical damage such as dents, scrapes, or gouges, may materially weaken the structure of the LP-Gas container and render it unsafe for use. All LP-Gas containers should be examined before recharging and again before reuse, for the following defects or damage:
 - A. Dents, scrapes, and gouges of the pressure vessel.
 - B. Damage to the various valves and liquid level gage.
 - C. Debris in the relief valve.
 - D. Indications of leakage at valves or threaded connections.
 - E. Deterioration damage or loss of flexible seals in the fill or servicing connections.All defective or damaged LP-Gas containers should be removed from service.
16. Smoking should be prohibited in the refueling area.
17. Whenever vehicles using LP-Gas as a fuel are parked overnight or stored for protracted periods of time indoors, with the fuel container in place, the service valve on the fuel container should be closed.

When checking or adjusting L.P. Gas equipment be sure to:

1. Properly ventilate work area.
2. Eliminate ignition sources (sparks, pilot lights etc.).
3. Prohibit smoking.
4. Have fire fighting equipment present.
5. Check all equipment, lines, connections with soapy water. NEVER USE A MATCH

OR FLAME WHEN CHECKING FOR LEAKS.

6. Check cylinder (container) for security of mounting.

7. Inspect hoses, grommets or whatever means is used to protect hoses from damage where they run through sheet metal etc. Replace any component that is unfit for further service.

8. Check all equipment for security of mounting.

9. Check the Solenoid Lock-Off Valve to be sure it is working. Upon turning off the ignition switch there should be an audible click indicating the valve has actuated shutting off the fuel flow at the valve. The valve should not open again until the ignition switch is turned on and the engine cranked. Cranking the engine provides oil pressure to the engine oil pressure sending unit which actuates completing an electrical circuit to the solenoid lock-off valve. The valve then opens allowing the L.P. Gas to pass through.




Plate 6031. Typical L.P. Gas Container




Plate 7405. Typical L.P. GAS Installation




Plate 7406. Typical L.P. GAS Installation



INDUSTRIAL TRUCK DIVISION



LUBRICATION AND PREVENTIVE MAINTENANCE INDEX

(8 HOURS)	Time Interval & (H=Hours)	Page Number (0000-)	(100 HOURS CONT'D)	Time Interval & (H=Hours)	Page Number (0000-)
Air Cleaner Service.....	8H	403	Hydraulic System, inspect.....	100H	403
Brake Pedal Operation.....	8H	303	Lift Brackets, inspect.....	100H	403
Brake Operation, Parking.....	8H	303	Lift Chain, adjust	100H	403
Clutch Pedal Free Travel, check	8H	605	Lubrication Chart	100H	703
Clutch Release Bearing lubricate	8H	605	Transmission & Differential Level check.....	100H	001
Crankcase Oil Level check....	8H	003	(500 HOURS)		
Engine Cooling System check..	8H	103	Fuel Pump	500H	001
Engine Coolant Temperature Indicator.....	8H	203	Fuel Pump Strainer.....	500H	001
Fuel Tank check.....	8H	001	Hydraulic Oil Strainer clean...	500H	103
Fuse, check	8H	001	Hydraulic Sump Tank drain and refill	500H	103
Horn.....	8H	001	Intake and Exhaust Manifold....	500H	403
Hydraulic Control Levers.....	8H	503	Nuts, Bolts & Capscrews, tighten.....	500H	403
Hydraulic Sump Tank Level check	8H	503	Steering Axle & Linkage adjustment	500H	302
Oil Pressure Indicator.....	8H	203	Steering Gear adjustment.....	500H	203
Tires Inspect.....	8H	603	(1000 HOURS)		
(100 HOURS)			Brake; adjust.....	1000H	1003
Battery Level and Test.....	100H	603	Brake System; test & bleed....	1000H	913
Brake Master Cylinder Level check	100H	303	Carburetor, adjust.....	1000H	403
Brake Pedal, adjust.....	100H	302	Compression test, Engine	1000H	103
Clutch, adjust	100H	653	Cooling System, inspect and clean	1000H	1202
Cooling System	100H	103	Crankcase Ventilation.....	1000H	003
Engine Breather.....	100H	003	Cylinder Head Tightening Sequence	1000H	003
Engine Crankcase	100H	003	Distributor, inspect and adjust	1000H	203
Engine Oil Filter.....	100H	003	Drive Wheel Bearings, clean and repack	1000H	805
Fan Belt, adjust	100H	203	Engine Tune-up	1000H	001
Fuel Tank and Lines	100H	001	Generator, inspect	1000H	703
Hydraulic Sump Tank Breather	100H	503	Governor, adjust	1000H	503



INDUSTRIAL TRUCK DIVISION



LUBRICATION AND PREVENTIVE MAINTENANCE INDEX CONTINUED


(1000 HOURS CONT'D)	Time Interval & Page Number (H=Hours) (0000-)	LUBRICATION & PREVENTIVE MAINTENANCE ILLUSTRATIONS		Time Interval & Page Number (H=Hours) (0000-)
Hand Brake, adjust.....	1000H 1103			
Ignition Timing.....	1000H 303	Description		
Intake and Exhaust Valve Clearance, adjust.....	1000H 003	Plate 7465	Lube. & Prev. Main. illus.	8H 000
Pressure checks (Main Hydraulic System).....	1000H 1503	Plate 7466	Lube. & Prev. Main. illus.	100H 000
Transmission & Differential drain and refill.....	1000H 1303		Lube. Instruction Diagram	100H 703
Spark Plugs, clean & adjust...	1000H 103	Plate 7467	Lube. & Prev. Main. illus.	500H 000
Starter, inspect	1000H 603			
Steer Wheel Bearings, inspect & adjust.....	1000H 803	Plate 7468	Lube. & Prev. Main. illus.	1000H 000
Upright & Lift Carriage Roller Adjustments checks.....	1000H 1803			
Regulator, inspect	1000H 704			
Wiring, inspect	1000H 704			

NOTE

WHEN PERFORMING THE 100, 500 OR 1000 HOUR LUBRICATION AND PREVENTIVE MAINTENANCE, ALWAYS INCLUDE THE PREVIOUS LUBRICATION AND PREVENTIVE MAINTENANCE SCHEDULES.

LUBRICATION AND PREVENTIVE MAINTENANCE

8 HOURS



NOTE

AFTER EACH 8 HOURS OF OPERATION, PERFORM THE ABOVE PREVENTIVE MAINTENANCE SERVICES.

Plate 7465. Lubrication and Preventive Maintenance Illustration




Plate 7452. Horn and Ignition Fuse

HORN

Check to be sure the horn is working properly.

FUSES

Check the electrical circuit fuses. The fuse holders are located beneath the dash. A red wire leads to the ignition fuse holder and a green wire leads to the horn fuse holder.

FUEL TANK

Check fuel supply and fill if necessary. Use a good grade of fuel.

Before filling full tank, make certain the filler cap screen is in place and not damaged (on machines so equipped).

WARNING

DO NOT FILL THE TANK WITH THE FILLER CAP SCREEN REMOVED.




Plate 6627. Fuel Tank Filler Cap and Screen

ENGINE CRANKCASE

Before attempting to start the engine, first make sure that it has sufficient oil. The oil filler pipe is located on the right side of the machine. The oil level stick is of the dipstick or bayonet type and is also located on the right side of the machine. Fill the crankcase reservoir through the filler pipe to the proper level as indicated on the dipstick.

CAUTION

NEVER PERMIT THE OIL LEVEL TO FALL BELOW THE "ADD" MARK ON THE DIPSTICK.

DO NOT OVERFILL THE CRANKCASE, AS TOO MUCH OIL WILL BRING THE LEVEL HIGH ENOUGH FOR THE CONNECTING RODS TO DIP, THUS CAUSING EXCESSIVE QUANTITIES OF OIL TO BE THROWN TO THE CYLINDER WALLS RESULTING IN OIL CONSUMPTION, SMOKING, EXCESSIVE CARBON DEPOSITS AND FOULED SPARK PLUGS.

NOTE

ON L.P. GAS MACHINES, USE A NON-DETERGENT OIL DURING BREAK-IN PERIODS.

Crankcase Capacity — Refer to Specifications

	Service "MS" Oils
S.A.E. 10W	0° to 32° F.
S.A.E. 20W	32° to 75° F.
S.A.E. 30	above 75° F.
or use	10W... 30 MULTI-GRADE OIL.




Plate 6629. Engine Crankcase Fill




Plate 3145. Crankcase Oil Check

ENGINE COOLING

Make sure that the radiator drain cock and the water drain in the cylinder block are closed Plate 7469. Check radiator coolant level and fill to within 1 inch of the top with clean water; or if operation is in cold weather, use a suitable anti-freeze solution.




Plate 7469. Cylinder Block Water Drain

It is recommended that a soluble oil in the proportion of 1 ounce per gallon of water be added to the Cooling System.

CAUTION

NEVER POUR COLD WATER OR COLD ANTI-FREEZE INTO THE RADIATOR OF AN OVERHEATED ENGINE. ALLOW THE ENGINE TO COOL AND AVOID THE DANGER OF CRACKING THE CYLINDER HEAD OR BLOCK. KEEP ENGINE RUNNING WHILE ADDING WATER OR ANTI-FREEZE.

CAUTION

WHEN PERMANENT ANTI-FREEZE OF THE ETHYLENE GLYCOL TYPE IS USED, THE COOLANT SOLUTION MUST CONTAIN AT LEAST 40% WATER.




Plate 6288. Oil Pressure Indicator




Plate 6287. Temperature Indicator

INSTRUMENT INDICATORS

a. Oil Pressure Indicator. Oil pressure should be at least 7 pounds at idle (400 to 600 R.P.M.) CAUTION: IF THE OIL PRESSURE IS ERRATIC OR FALLS BELOW THE ABOVE LIMIT, STOP THE ENGINE IMMEDIATELY AND FIND THE CAUSE OF THE TROUBLE. REFER TO TROUBLE SHOOTING SECTION FOR THIS INFORMATION.

CAUTION

ON NEW MACHINES, AFTER STARTING ENGINE -- RUN IT AT IDLE FOR 5 MINUTES, THEN STOP ENGINE AND RECHECK OIL LEVEL IN CRANKCASE - BRING OIL LEVEL TO HIGH MARK, IF NECESSARY.

b. Temperature Indicator. The water temperature should register 185° to 205° F. after the first ten or fifteen minutes of operation.

c. Ammeter. The ammeter is connected in the generator (or alternator if used) and battery circuit in such a manner as to indicate rate of charge or discharge. If the generator (or alternator) is functioning properly the ammeter should show a small amount of charge at engine idle. As engine R.P.M. increases the rate of charge also increases. When the battery becomes fully charged the circuit is regulated to reduce the rate of charge, and cause the ammeter needle to return to near neutral position, showing only a small amount of charge.

NOTE

BEFORE PLACING MACHINE IN OPERATION RUN ENGINE A FEW MINUTES TO WARM OIL ESPECIALLY IN COLD OPERATING CONDITIONS.

LOW OPERATING TEMPERATURES WASTES FUEL AND INCREASES ENGINE WEAR.




Plate 7042. Brake Pedal Free Travel

BRAKE PEDAL

1. Depress brake pedal by hand. When pedal meets resistance from the master cylinder, the distance traveled should be 3/16" to 5/16". If free travel is incorrect an adjustment should be made at the master cylinder linkage adjuster.

2. Depress foot pedal and hold for at least 10 seconds. Pedal must be solid, must not be spongy or drift under foot pressure.

PARKING BRAKE

The parking brake linkage should be adjusted so that the brake handle will have 2 inches of upward free travel, before resistance is noticed and the brake becomes applied.

The parking brake must be capable of holding the truck, with full rated load, on a 15% grade. This should be tested while occupying the driver's seat with the parking brake applied and truck out of gear.

If brake operation is not satisfactory, report to designated person in authority.




Plate 7482. Parking Brake

LUBRICATION AND PREVENTIVE MAINTENANCE

ENGINE AIR CLEANER (DRY TYPE)

Operating conditions determine the air cleaner service periods. The air cleaner should be checked every 8 operating hours and cleaned. This may be necessary more often under dusty operating conditions.

dirt from entering at these points. Periodically remove hoses and check interior for any signs of dirt or dust. If found, this indicates that more frequent cleaning intervals are necessary as the hose interior should be free of all dirt and dust.



Plate 7453. Typical Air Cleaner

Proper servicing means cleaning unit thoroughly and maintaining air-tight connections between the air cleaner and intake manifold so that all air entering the engine is filtered.

1. Remove air cleaner cartridge (2) and tap cartridge on a hard flat surface until all loose dirt is removed.
2. After cleaning by the above procedure, clean unit with filtered, moisture free, compressed air. Direct air stream from the inside, (thru cartridge) outward at the same time rotating cartridge by hand.

NOTE

IF FILTER CARTRIDGE CANNOT BE PROPERLY CLEANED, REPLACEMENT IS NECESSARY.

Check all hose connections to be sure they are tight thus preventing any air and



Plate 6980. Air Cleaner Components

NOTE

DEPENDING ON THE TYPE OF OPERATING THE MACHINE IS SUBJECTED TO WILL DETERMINE THE FREQUENCY OF AIR CLEANER MAINTENANCE. HAPHAZARD MAINTENANCE WILL LEAD TO SHORT ENGINE LIFE. AIR CLEANER MAINTENANCE MAY SEEM TRIVIAL, BUT IT CAN MEAN LONGER ENGINE LIFE, LESS ENGINE UPKEEP AND BETTER ECONOMY PROVIDED PROPER MAINTENANCE IS EXERCISED. CLOSE OBSERVANCE AND COMMON SENSE CAN BEST DETERMINE THE FREQUENCY OF AIR CLEANER MAINTENANCE.



Plate 7454. Sump Tank Breather

HYDRAULIC SUMP TANK

Check hydraulic sump tank fluid level in the following manner:

1. Lower upright.
2. Shut engine off.
3. Remove sump breather. Fluid level should be up to bottom of filler pipe.

If necessary, fill sump tank using MS 68 Hydraulic Oil. Start engine and operate valve control levers allowing any air in the lines to escape, then recheck sump tank fluid level before putting machine into operation.

HYDRAULIC CONTROL LEVERS

I M P O R T A N T

EVERY 8 OPERATING HOURS (OR EVERY SHIFT)

ELEVATE UPRIGHT TO THE UPPER LIMIT. THIS WILL PROVIDE LUBRICATION TO THE TOP PORTION OF THE LIFT CYLINDER.

Check lift and tilt operation. The lift and tilt cylinders should actuate when lift or tilt levers are moved either way from neutral position.




Plate 7449. Lift and Tilt Levers

When load is elevated and control lever returned to neutral position, load should remain in elevated position with no noticeable downward drift. If load drifts downward excessively, this may indicate lift cylinder U-Cup or seal damage -- report to designated person in authority.

With tilt lever in neutral position, upright should remain steady with no noticeable backward or forward drift. If upright drifts excessively either way, this may indicate tilt cylinder seal or U-Cup damage -- report to designated person in authority.

C A U T I O N

NEVER ALLOW LOADED OR UNLOADED LIFT CARRIAGE TO REMAIN IN AN ELEVATED POSITION FOR ANY PROLONGED PERIODS. LIFT CARRIAGE SHOULD BE LOWERED WHEN NOT IN USE.

DO NOT HOLD CONTROL LEVERS IN EXTREME POSITIONS AFTER A LOAD HAS REACHED ITS LIMITS. TO DO SO WILL RESULT IN HIGH OIL PRESSURE THAT MAY RESULT IN HEATING OF THE HYDRAULIC OIL.



INDUSTRIAL TRUCK DIVISION



LUBRICATION AND PREVENTIVE MAINTENANCE

TIRE AND RIM MAINTENANCE

1. Inspect tires regularly - remove all sharp objects picked up by treads before they have a chance to cut further into the rubber and cause chipping or possible separation of the rubber from the base metal.
2. Avoid overloading and do not allow vehicle to stand under heavy loads for prolonged periods as this will cause a "flat" spot on the tires.
3. Check steering axle alignment regularly to protect against fast, irregular tread wear and separation.
4. If rubber tires come in contact with oils, grease, and gasoline they should be wiped off without delay.
5. Regular lubrication of all wheel bearings will assure free-rolling and elimination of tire drag when stopping or starting.



Plate 7398. Clutch Release
Bearing Grease Cup

CLUTCH RELEASE BEARING LUBRICATION:

Rotate cup one complete turn every 8 operating hours.

Keep grease cup filled with Clutch Release Bearing high temperature grease. Use Shell 5A, Texaco 1199 or equivalent.





Plate 7048. Clutch Pedal
Free Travel Check

CLUTCH PEDAL FREE TRAVEL. Depress clutch pedal from the top position to a point where it meets resistance. This free travel should be approximately 5/8 to 1" inches from top pedal position.

100 HOURS

LUBRICATE MACHINE



NOTE

IN ADDITION TO THE ABOVE, PERFORM THE 8 HOUR PREVENTIVE MAINTENANCE SERVICES.

Plate 7466. Lubrication and Preventive Maintenance Illustration.




Plate 7455. Axle Adapter

TRANSMISSION AND AXLE ADAPTER

The transmission and axle adapter have a common lubrication system. Verify fluid level after removing level test plug located on the front side of the axle adapter. If lubricant is not to the height of this plug, remove the filler plug and add a sufficient quantity of straight mineral lube of S.A.E. 90 grade to bring level to the height of the level plug opening. Replace plugs and operate the machine in forward or reverse for 2 or 3 minutes to distribute lubricant throughout the system. Stop engine and again check level at the test plug. ADD or DRAIN lubricant as required.

C A U T I O N

DO NOT OVERFILL AS THE EXCESS QUANTITY WILL SERVE NO USEFUL PURPOSE. IF THE OIL LEVEL IS TOO HIGH, IT WILL CAUSE EXCESSIVE OIL CHURNING AND ATTENDANTLY HIGH OIL TEMPERATURE AND POSSIBLE LEAKAGE.




Plate 6627. Fuel Tank Filler Cap and Screen

AXLE ADAPTER BREATHER

Check breather to be sure it is free of any obstruction. Remove and clean in a Stoddard type cleaning solvent if necessary. Dry with compressed air before replacing breather on axle adapter.

FUEL LINES

Make certain that fuel line connections are secure. Check fuel lines for obstruction and leaks. Check screen in fuel filler cap to make certain that it is properly installed.

LUBRICATION AND PREVENTIVE MAINTENANCE

ENGINE CRANKCASE

Every 100 operating hours, drain and refill. (Drain at operating temperatures). Refill, then run engine a few minutes and add oil as necessary to bring oil level to full mark indicated on the dipstick.

Crankcase Capacity — Refer to Specifications Service "MS" Oils

S.A.E. 10W 0° to 32° F.

S.A.E. 20W 32° to 75° F.

S.A.E. 30 above 75° F.

or use 10W...30 MULTI-GRADE OIL.

ENGINE CRANKCASE VENTILATION PIPE

Check crankcase ventilation pipe for damage or obstructions. The pipe must be open to provide proper ventilation. Clean, repair or replace as required.




Plate 7470. Crankcase Vent Pipe

ENGINE OIL FILTER

The oil filter element is of the replaceable type. The element should be changed whenever the crankcase is drained. To remove the element, remove oil filter cover screw and gasket, oil filter cover, cover spring and cover gasket. Lift out oil filter element. Install new element after draining and thoroughly cleaning filter case. Install new gaskets and replace cover spring, oil filter cover and secure with oil filter cover screw.




Plate 6642. Engine Oil Filter

CAUTION

START ENGINE, RUN AT IDLE FOR A FEW MINUTES, CHECK COVER AND COVER SCREW FOR LEAKS.



Plate 6458. Radiator Pressure Cap

WARNING

USE EXTREME CARE IN REMOVING THE RADIATOR PRESSURE CAP. IN PRESSURE SYSTEMS, THE SUD- DEN RELEASE OF PRESSURE CAN CAUSE A STEAM FLASH AND THE FLASH, OR THE LOOSENED CAP CAN CAUSE SERIOUS PERSONAL INJURY. LOOSEN CAP SLOWLY AND ALLOW STEAM TO ESCAPE. THIS MACHINE IS EQUIPPED WITH A 7 LB PRESSURE CAP.

COOLING SYSTEM

Check radiator, hoses and water pump for leaks.

Add proper amount of water or anti-freeze solution to cooling system. If anti-freeze is not available and machine is to be at rest for an appreciable length of time, drain system when temperature is likely to be 32° F, or lower. If water is added to radiator containing anti-freeze solution, always test solution in radiator with a hydrometer to determine the degree of protection. For proper amount of anti-freeze solution required to protect the cooling system, refer to instructions on anti-freeze container.

NOTE

COOLING SYSTEM CAPACITY - REFER TO SPECIFICATIONS.

Accumulated foreign material should be blown from radiator fins with compressed air. Direct air stream through radiator fins towards engine to make this process effective.




Plate 6631. Generator Drive Belt Adjustment

FAN AND GENERATOR DRIVE BELTS

The drive belts should have finger pressure deflection of $3/4$ to 1 inch mid-way on long span. If belts require adjustment, use following procedure.

1. Loosen generator brace adjusting bolt and two lower mounting bolts, see Plate 6631.
2. Move generator toward cylinder block to loosen Generator Drive Belts and away from cylinder block to tighten belts. Tighten bolts when correct finger deflection is obtained.

C A U T I O N

EXERCISE CAUTION WHEN ADJUSTING BELTS. BELTS ADJUSTED TOO TIGHT WILL VERY LIKELY CAUSE




Plate 6632. Belt Deflection Check

BEARING DAMAGE. CONVERSELY, BELTS ADJUSTED TOO LOOSE WILL RESULT IN BELT WEAR AND HIGH ENGINE TEMPERATURE DUE TO BELT SLIP-PAGE.

N O T E

UPON REPLACEMENT OF DRIVE BELTS, IT WILL BE NECESSARY TO USE A MATCHED SET OF BELTS.

BRAKE PEDAL FREE TRAVEL

Using a rule, measure pedal free travel at either of the two places shown below.

Depress brake pedal by hand. When pedal meets resistance from the master cylinder, the distance traveled should be 3/16 to 1/2" — if free travel is incorrect, adjust as follows:

1. Loosen lock nut, see Plate 6633.
2. Rotate adjuster to obtain specified pedal free travel.
3. Tighten lock nut to hold adjustment.

ACTUATION STROKE

The Automatic Brake Adjustors will maintain pedal stroke, with little variation, until such time as the brake linings require replacement.

If the system has been properly bled and brake pedal travels beyond this point----- this indicates a malfunction in the brake system. Check the complete system and repair or replace the faulty components.

CLEARANCE - measured here -

TOP PEDAL POSITION -TO- WHERE PEDAL MEETS RESISTANCE FROM THE MASTER CYLINDER.




Plate 7042. Brake Pedal Check and Adjustment

LUBRICATION AND PREVENTIVE MAINTENANCE

LIFT AND TILT CYLINDERS

Check for drift, leakage at packings, damage and security of mountings (Anchor Pivot Pins, Flanges and Mounting Rings).

LIFT CHAINS

The lift chains are mounted to the chain anchors on the lift carriage and at the chain anchor rods near the lift cylinder piston head.

If it becomes necessary to adjust the lift chains place a capacity load on forks (or device if used) and adjust chains so center line of lower carriage roller is at least 1/2" above the bottom end of the innerslide channel. It is important that the chain adjustment be made with a capacity load. In this manner you will allow for chain stretch.

W A R N I N G

KEEP CLEAR OF LOAD DURING ADJUSTMENT TO AVOID INJURY IF ANY MALFUNCTION SHOULD OCCUR AND CAUSE LOAD TO FALL.




Plate 6884. Lift Chain Adjustment
(Place Maximum Load On Forks)

LUBRICATE MACHINE

C A U T I O N

WHEN LUBRICATING THE TRUCK, MAKE A VISUAL INSPECTION OF ALL HYDRAULIC LINES, FITTINGS AND ALL ELECTRICAL WIRING. LUBRICATE ALL MISCELLANEOUS LINKAGE WITH S.A.E. NUMBER 20 OIL.

HYDRAULIC CONTROL VALVE AND LINES

Inspect for damage, leakage and security of mounting.

LIFT BRACKET

Inspect for damage, bent forks etc.




Plate 6634. Lift Chain Adjustment
(Chain Anchor Rods)

**HYDRAULIC SUMP TANK BREATHER**

Check breather to be sure it is not dirty or clogged with foreign matter.

Rinse breather in a Stoddard type cleaning solvent each time the machine is lubricated. Re-oil breather with S.A.E. number 20 after washing.

Plate 7454. Hydraulic Sump Tank Breather

3. After one minute, and with the 10 ampere load still on the battery, check the individual cells with an expanded scale voltmeter.




Plate 8306.

4. Place the positive voltmeter prod on the positive side of the cell and the other prod on the negative side. A good battery, sufficiently charged will read 1.95 volts or more on each cell with a difference of less than .05 volt between highest and lowest cell.




Plate 8307.

5. If cells read both above and below 1.95 volts and the difference between highest and lowest cell is less than .05 volt, battery is good but requires charging.




Plate 8308.

6. If any cell reads 1.95 volts or more and there is a difference of .05 volt or more between the highest and lowest cell, the battery is defective.



Plate 8309.

7. If all cells read less than 1.95 volts, battery is too low to test accurately. Boost-charge and repeat light load test.





Plate 7481. Clutch Pedal Adjustment

The clutch pedal adjustment is necessary to compensate for clutch facing wear and provide clearance between the release bearing and pressure plate fingers. The adjustment is made beneath the floor plates.

1. Adjust the clevis on the clutch release rod until the pedal has $5/8$ " to 1" free travel. Test the amount of free travel by depressing pedal by hand rather than the foot since this is a sensitive adjustment. The specified clearance is the distance from the top pedal position (with floor plate installed) to a point where resistance is noticed from the release bearing making contact with the pressure plate release fingers. See Plate 7481.

2. After correct free travel is obtained adjust the clutch return spring (see Plate 7481) to a length of $6\ 1/8$ inches. This measurement is the length between the hooks on each end of the spring.

LUBRICATION AND PREVENTIVE MAINTENANCE



500 HOURS

STEAM CLEAN MACHINE

CHECK SECURITY OF MOUNTING
ON ALL NUTS, BOLTS AND
CAPSCREWS

SEDIMENT BOWL
CLEAN

FUEL PUMP
SCREEN CLEAN

INTAKE AND EXHAUST
MANIFOLD CHECK

EXHAUST SYSTEM
CHECK

STEERING GEAR
ADJUST

HYDRAULIC SUMP TANK
DRAIN - REFILL

SUMP TANK
STRAINER
CLEAN

STEERING AXLE
AND LINKAGE
CHECK-ADJUST

NOTE

IN ADDITION TO THE ABOVE, PERFORM THE 8 HOUR
AND 100 HOUR PREVENTIVE MAINTENANCE SERVICES.

Plate 7467. Lubrication and Preventive Maintenance Illustration

FUEL PUMP STRAINER

The fuel filter and sediment bowl should be cleaned every 500 operating hours. Remove and clean sediment bowl. If fuel strainer is dirty, install a new strainer assembly and gasket. Do not reuse old gasket.

FUEL PUMP

To determine if the fuel pump is defective, remove the fuel tank supply line at the pump and blow out line with compressed air to remove any possible obstructions. Reconnect fuel tank line and disconnect pump to carburetor line. Install a fuel pressure gauge, by placing a "T" in the line, and run engine at 1800 R.P.M. with all lines connected. Fuel pump pressure should be between 1 1/2 and 2 1/4 pounds. If the fuel pump pressure is not within this range the pump should be removed for repair or replacement.

C A U T I O N

TO AVOID CREATING A FIRE HAZARD CARE SHOULD BE TAKEN SO THAT GASOLINE IS NOT SPILLED DURING THESE OPERATIONS.




Plate 6638. Fuel Pump & Sediment Bowl

HYDRAULIC SUMP TANK AND SUMP OIL STRAINER

C A U T I O N

THE HYDRAULIC SYSTEM MUST BE KEPT CLEAN. IT MAY BE NECESSARY TO DRAIN, CLEAN AND REFILL SUMP TANK MORE OFTEN UNDER ADVERSE CONDITIONS. THIS IS BEST DETERMINED BY CHECKING CONDITION OF THE HYDRAULIC FLUID FOR EVIDENCE OF DIRT, SLUDGE OR ANY FOREIGN MATTER AT PERIODIC INTERVALS.

1. Lower upright and shut engine off.
2. Remove the pump pressure line at the hydraulic valve.
3. Place the unattached end of the hose in a large container and run engine at idle speed until the oil has been pumped from the sump tank. See Plate 3720.

C A U T I O N

DO NOT OPERATE ENGINE AFTER THE OIL HAS BEEN PUMPED FROM THE SUMP TANK AS THE HYDRAULIC PUMP WILL NOT BE LUBRICATED AND DAMAGE WILL RESULT.

4. Reinstall the pump pressure line to the hydraulic valve.



Plate 3720. Removing Hydraulic Sump Oil

SUMP TANK STRAINER

1. Remove suction line from bottom of sump strainer housing.
2. Remove strainer retaining bolts and pull strainer and housing out of sump tank.
3. Remove any remaining gasket material from mounting flange.
4. Rinse sump strainer in a Stoddard type cleaning solvent and dry with filtered compressed air.
5. Flush sump tank with 2 quarts of clean hydraulic oil. Be sure sump tank is absolutely clean. It is recommended that a new felt washer and gasket be used when installing the cleaned strainer.




Plate 7456. Sump Tank Strainer

6. Install sump housing retainer bolts, hose and connections.
7. Fill sump tank with MS68 hydraulic fluid until level reaches the bottom of the fill pipe.

C A U T I O N

START ENGINE AND OPERATE HYDRAULIC CONTROL LEVERS SEVERAL TIMES, CHECK OIL STRAINER FOR LEAKS, RECHECK OIL LEVEL AND FILL TO BOTTOM OF FILL PIPE IF NECESSARY.

STEERING GEAR

Steering gear adjustments must be made in the following manner (see Plates 6636 and 6637).

Always check worm bearing thrust adjustment, and adjust if necessary, before making sector gear lash adjustment.

Before making above adjustments, the following preliminary operations are necessary.

1. Disconnect steering drag link from pitman arm. Note relative position of drag link parts when disconnecting link so the parts may be re-assembled correctly.
2. Check lubricant level in steering gear housing. If low, add enough lubricant to bring level up to filler plug hole. (Use NLGI #1 Amolith grease EP #1 or its equivalent).
3. Tighten steering gear housing to frame side member bolts, see Plate 6636.
4. Determine straight-ahead position of steering mechanism by turning steering wheel to extreme right.




Plate 6636. Steering Gear Thrust Adjustment (Worm Bearings)

C A U T I O N

APPROACH EXTREME ENDS CAUTIOUSLY; WORM BALL NUT MUST NOT STRIKE ENDS WITH ANY DEGREE OF FORCE.

Then turn to extreme left, counting the exact number of turns from right to left end. Turn wheel back one-half number of wheel turns. Mark wheel with respect to steering column so center position may readily be found during adjustment procedures.

Worm Bearing THRUST Adjustment: Refer to Plate 6636 and proceed as follows:

1. Check tightness of cover bolts, see Plate 6636. Loosen lock nut and turn lash adjuster screw (Plate 6637) counterclockwise a few turns to provide clearance between sector gear and worm ball nut.




Plate 6637. Steering Gear Lash Adjustment (Sector Gear)

2. Turn steering wheel GENTLY to one extreme end. Turn wheel back one full turn. With spring scale on spoke of wheel, measure pull required to KEEP WHEEL MOVING. Pull on scale should be made at right angles to wheel spoke. If pull is within 1 1/2 to 2 pounds, proceed to lash adjustment in the following paragraphs. If pull is not within 1 1/2 to 2 pounds, adjust worm bearings. The pitman shaft adjustment must be made if worm bearing check is accomplished, or if the worm bearings are adjusted.

3. If it is necessary to adjust the worm bearings, loosen lock nut and then turn worm bearing adjuster nut clockwise until all end play is removed, see Plate 6636. Using



INDUSTRIAL TRUCK DIVISION



LUBRICATION AND PREVENTIVE MAINTENANCE

spring scale, as directed in Step 2, check pull and readjust as necessary; then tighten lock nut securely.

Sector Gear Lash Adjustment: Refer to Plate 6637 and proceed as follows:

1. Steering Gear Mechanism must be in straight ahead position as previously explained.
2. Turn lash adjuster screw clockwise to remove all lash between gear teeth. Tighten adjuster screw lock nut. Position spring scale on steering wheel so pull may be made at right angles to wheel spoke.
3. Measure pull while wheel is TURNED THROUGH CENTER POSITION. Readjust if reading is not within 2 1/2 to 3 pounds.
4. Tighten adjuster screw lock nut, check pull again.
5. After adjustments are made, install drag link on pitman arm.

N O T E

If steering linkage adjustment is necessary do not install drag link to pitman arm.




Plate 7419. Steering Linkage

STEERING AXLE AND LINKAGE ADJUSTMENTS

1. Raise the steering wheels far enough to clear the floor and place heavy blocking under the machine frame so it cannot accidentally become lowered during adjustments.

2. The steering wheels should track square with the drive wheels with no toe-in or toe-out. If adjustment is necessary loosen the lock nuts at the tie rod ends and turn each tie rod in a manner so they will be the same length when the correct adjustment is obtained. Tighten tie rod lock nuts to secure this adjustment.

3. Disconnect the drag link socket from the steering pitman arm noting the relative position of the socket parts so they may be re-installed correctly after

checking wheels for correct turning geometry.

4. Check wheels for correct turning geometry by turning the wheels all the way for a left turn - this should allow the left wheel to attain an angle of 80 degrees to the frame. If an adjustment is necessary, the axle stop on the left side should be turned in or out whichever is necessary to achieve the correct angle. Repeat this procedure in a right turn with the opposite wheel and adjust the right axle stop as required.

5. Turn Steering wheels to straight ahead position.

6. Determine center position of steering gear. (Refer to Steering Gear adjustments for correct procedure).



INDUSTRIAL TRUCK DIVISION



LUBRICATION AND PREVENTIVE MAINTENANCE


7. Adjust drag link socket so that the grease fitting lines up with the centerline of the pitman arm ball stud and secure with lock nut and cotter pin.

8. Turn the handwheel until wheels are in straight ahead position. Remove handwheel and replace on steering column with the center spoke aligned minus or plus 10 degrees with the center line of the machine, the center spoke pointing back.

N O T E

CHECK STEERING GEAR SUPPORT BOLTS FOR SECURITY OF MOUNTING. TIGHTEN MOUNTING BOLTS AND CLAMP BOLTS TO 90 FOOT POUNDS TORQUE.

9. Remove blocking from under frame and lower machine to the floor.



INTAKE AND EXHAUST MANIFOLDS


1. Inspect gaskets for leaks and inspect security of manifold nuts.
2. Inspect exhaust pipe and muffler for damage, leakage and security of mountings.

NUTS, BOLTS AND CAP SCREWS. Check security of mounting, tighten as required.

Plate 7470. Intake and Exhaust Manifolds

1000 HOURS

ENGINE TUNE-UP



NOTE
IN ADDITION TO THE ABOVE, PERFORM THE 8 HOUR
100 HOUR AND 500 HOUR PREVENTIVE MAINTENANCE
SERVICES.

Plate 7468. Lubrication and Preventive Maintenance Illustration

ENGINE TUNE-UP

Engine tune-up is the orderly and systematic process of checking the engine and accessory equipment to maintain or restore satisfactory engine performance. Engine tune-up must be accomplished semi-annually and more frequently if engine performance indicates the need for these services. Perform engine tune-up as follows:

1. AIR CLEANER. Be sure air cleaner has received proper service. Air cleaner must be installed before making engine tune-up.
2. FUEL PUMP. Be sure the fuel pump bowl and strainer has been properly serviced and the fuel pump is operating satisfactorily.




Plate 7453. Typical Air Cleaner





Plate 6638. Fuel Pump Strainer & Sediment Bowl

3. CYLINDER HEAD STUD NUTS. Check all stud nuts for correct torque, refer to specifications. Check cylinder head gasket for leaks.

CAUTION

THE SEQUENCE SHOWN ON PLATE 6281 MUST BE FOLLOWED. ALL CYLINDER HEAD CAP SCREWS OR NUTS MUST BE TIGHTENED EVENLY AND TORQUED IN ACCORDANCE WITH LIMITS LISTED IN SPECIFICATIONS.



ORDER OF TIGHTENING CYLINDER HEAD STUD NUTS




Plate 6281. Cylinder Head Stud Nut Tightening Sequence

4. INTAKE AND EXHAUST MANIFOLDS. Inspect for gasket leaks and security of mounting.

5. CRANKCASE VENTILATION. The crankcase vent pipe allows clean air to pass through the crankcase to help carry off corrosive gases (which are the by-products of combustion) that leak by the pistons and valve stems.

Check crankcase ventilation pipe for damage or obstructions. The pipe must be open to provide proper ventilation. Clean, repair, or replace as required, see Plate 7470.

6. INTAKE AND EXHAUST VALVE CLEARANCE ADJUSTMENTS. (PREFERRED METHOD).

a. Remove valve chamber cover mounting screws, and the valve chamber cover gasket.

b. With engine running at idling speed and at normal operating temperature, adjust intake valves as follows:

c. Check for proper 0.012 inch clearance by alternately passing a 0.011 inch and a 0.013 inch flat feeler gauge between head of adjusting screw and valve stem, see Plate 3223 on following page.

d. If a 0.011 inch feeler gauge moves freely back and forth in gap when valve is not being lifted and a 0.013 inch feeler gauge binds, at all times, clearance requires no adjustment.

e. If a 0.011 inch feeler gauge is gripped at all times, the clearance is insufficient.

f. Hold valve lifter with an open end wrench while using a second wrench to turn adjusting screw 1/4 to 1/2 turn clockwise. Repeat clearance check and adjustment, until proper clearance is obtained. The adjustable type valve lifters have self-locking adjusting screws that require no lock nuts.

g. If 0.013 inch feeler moves freely when valve is not being lifted, the clearance is too great. Hold valve lifter with an open end wrench while using a second wrench to turn valve lifter adjusting screw counterclockwise 1/4 to 1/2 turn. Repeat clearance check and adjustment until proper clearance is obtained.

h. Repeat clearance check and adjustment on remaining intake valves.

i. With engine running at slow idle and at normal operating temperature, adjust exhaust valves as follows:

j. Check for proper 0.012 inch clearance by alternately passing a 0.011 inch and a 0.013 inch flat feeler gauge between head of adjusting screw and valve stem, see Plate 3223.

k. If a 0.011 inch feeler gauge is gripped at all times, the clearance is insufficient. If a 0.013 inch feeler gauge moves freely when valve is not being lifted, the clearance is too great.

m. Turn adjusting screw in the direction necessary so that a 0.011 inch feeler gauge moves freely back and forth in gap and a 0.013 inch feeler is gripped at all times.

n. After adjustment is complete on all exhaust valves, install valve chamber cover using new cover gasket and replace cover retainment screws.

N O T E

DO NOT REUSE OLD GASKETS. THEY DO NOT AFFORD A POSITIVE SEAL.

o. Check valve chamber cover gasket for leaks.




Plate 3223. Adjusting Valve Clearance

6A. COLD SETTING. (ALTERNATE METHOD)

To adjust valve clearance when engine is at room temperature and not running, proceed in the following manner:

a. Remove distributor cap.

b. Crank engine until distributor rotor points to No. 1 cylinder position with the breaker points open. In this position the No. 1 piston is at the top of its compression stroke with both lifters on the base circle of the cam and both valves can be adjusted.

c. Adjust the valve clearance to 0.014 inch on the intake and 0.014 inch on the exhaust. The exhaust (E) and intake (I) valve arrangement on the four cylinder engine is: E-I-I-E-E-I-I-E.

d. The other valves may be adjusted by setting the engine with the distributor rotor pointing to the rest of the cylinder positions in the sequence of the firing order which is: 1-3-4-2.

7. COMPRESSION TEST

a. Test battery for full charge (specific gravity 1.280 temperature of 24°C (75° F). If battery is not fully charged, replace with fully charged battery.

b. Start engine and allow it to warm up until normal operating temperature is reached.

c. Turn off ignition.

d. Remove spark plug cables from spark plugs and remove spark plugs from cylinder head. Examine spark plugs for carbon deposits, defective insulation and general serviceability. All carbon or lead deposits must be removed from the insulation shell and electrodes. This can be done on a sand blast cleaner. Carbon deposits should be removed from the plug threads with a stiff brush. After cleaning, inspect plugs carefully for cracked or broken insulator, badly pitted electrodes or other signs of failure.

e. With all plugs removed, install compression gauge in front spark plug port. Operate starting motor until maximum reading on gauge is obtained, see Plate 3486. Record gauge reading. Repeat this operation on each remaining cylinder.

f. If readings are reasonably high (110 to 120) pounds and the readings do not vary more than about 10 pounds between cylinders, compression may be considered normal. Excessively low readings or readings that vary more than 10 pounds between cylinders indicate internal trouble to be corrected after further examination and testing.

g. Set the spark plug gap as specified, by bending side electrode only. The gap should be checked with a wire feeler gauge rather than a flat type gauge as it is better suited for this purpose.

h. Spark Plug Specifications:

- Standard Type - .025" Gap
- Resistor Type - .035" Gap

i. Replace spark plugs using new gaskets. Always replace spark plug gasket whenever a spark plug is removed from the engine. Before installing plugs, be sure that the spark plug seat in the cylinder head is clean and free from obstructions. The spark plug should be screwed into cylinder head (using a socket of proper size) sufficiently tight to fully compress the gasket. This is most important as a large percentage of troubles due to overheated spark plugs are caused by plugs being too loose in the cylinder head. Conversely, excessive tightening may change the gap between the electrodes or crack the insulator.




Plate 3486. Compression Test



Plate 3278. Check Spark Plug Gap

8. DISTRIBUTOR

Inspection: Remove distributor cap (without removing wires). Wipe cap with a clean cloth. Examine rotor and cap for chips, cracks, corroded terminals, carbon runners (paths which will allow high-tension leakage to ground) or if the vertical faces of the inserts are burned -- install a new cap and rotor, as this is due to the rotor being too short.




Plate 5933. Breaker Points

Check the centrifugal advance mechanism for "freeness" by turning the breaker cam in the direction of rotation and then releasing it. The advance springs should return the cam to its original position without sticking.

Inspect breaker points. If points are pitted, burned or worn to an unserviceable condition, install a new set of points.

The normal color of contact points should be a light gray. If the contact point surfaces are black, it is usually caused by oil vapor, or grease from the cam. If they are blue, the cause is usually excessive heating due to improper

alignment, high resistance or open condenser circuit.

Badly pitted points may be caused by a defective or improper condenser capacity.

If the condenser capacity is too high, the crater (depression) will form in the positive contact. If the condenser capacity is too low, the crater will form in the negative contact, see Plate 5933.

For a temporary repair, dress the contact points with a few EVEN strokes using a clean fine-cut contact file. DO NOT ATTEMPT TO REMOVE ALL ROUGHNESS OR DRESS THE POINT SURFACES DOWN SMOOTH. See Plate 7475.




Plate 7475. File Contact Points

CAUTION

NEVER USE EMERY CLOTH OR SANDPAPER TO CLEAN POINTS AS PARTICLES WILL EMBED IN THE POINTS AND CAUSE ARCING AND RAPID BURNING.

MEASURING ENGINE SPEED

1. Connect the test leads as shown.
2. Turn switch to the LOBE position corresponding to the number of cylinders.
3. Turn the other switch to the 1000 rpm position for all idle and low speed testing. Use the 5000 rpm position for all speeds over 1000 rpm.

DISTRIBUTOR RESISTANCE TEST

1. With test leads disconnected, turn switches to DWELL and CALIBRATE positions and adjust dwell calibrator until meter reads on the SET LINE.
2. Connect test leads as shown.
3. Turn ignition switch ON with engine stopped. If distributor resistance is not excessive, meter will read in the black bar marked DISTRIBUTOR RESISTANCE.

If meter does read within black bar, readjust dwell calibrator until meter again reads on the SET LINE before making the following tests.

If meter does not read within black bar, excessive resistance is indicated. To locate excessive resistance, trace the primary circuit through the distributor with the red test lead until point of high resistance is located. Excessive resistance must be eliminated and the dwell calibrator adjusted until the meter again reads on the SET LINE before proceeding with the following tests.

DWELL AND DWELL VARIATION TESTS

1. Turn switch to the proper LOBE position.
2. Operate engine at idle speed and note reading on dwell scale of meter. Refer to specifications for proper dwell.
3. Turn tachometer switch to the 5000 rpm position and increase speed to 1500 rpm.
4. Turn switch back to the DWELL position and again note dwell reading. Slowly reduce speed to idle while watching meter. Dwell should not change more than 3 degrees in either case.




Plate 6887 Tach Dwell Meter



INDUSTRIAL TRUCK DIVISION



SPECIFICATIONS

DISTRIBUTOR (All FOUR and SIX Cylinder Engines)

Heavy Duty Points

NOTE

Distributors are equipped with either Standard or Heavy Duty Points. Heavy Duty Points are thicker (have more contact material) than Standard Points.

Heavy Duty Points - All FOUR Cylinder Engines
Set Dwell Angle at..... 31° - 34°

Heavy Duty Points - All SIX Cylinder Engines
Set Dwell Angle at..... 22° - 26°

When connecting leads, terminals must be back to back (flat sides together). Push into slot between insulator and spring. (DO NOT push lever spring.) Then push other terminal in place between first terminal and insulator. See following illustration.

WHEN CONNECTING LEADS, THE TERMINALS MUST BE BACK TO BACK (flat sides together).....



- FOUR (4) CYLINDER ENGINES, ONLY -

Point Opening (in.)	Dwell Angle (deg.)	Centrifugal Advance							
		START		INTERMEDIATE		INTERMEDIATE		MAXIMUM	
		Eng. rpm.	Eng. adv.	Eng. rpm.	Eng. adv.	Eng. rpm.	Eng. adv.	Eng. rpm.	Eng. adv.
.022*	31-34	600	1-5	800	6-10	1600	11-15	2200	15-19
.021**	31-34	600	1-5	800	6-10	1600	11-15	2200	15-19

- SIX (6) CYLINDER ENGINES, ONLY -

Point Opening (in.)	Dwell Angle (deg.)	Centrifugal Advance							
		START		INTERMEDIATE		INTERMEDIATE		MAXIMUM	
		Eng. rpm.	Eng. adv.	Eng. rpm.	Eng. adv.	Eng. rpm.	Eng. adv.	Eng. rpm.	Eng. adv.
.020*	28-32	600	1-5	800	6-10	1600	11-15	2200	15-19
.021**	22-26	600	1-5	800	6-10	1600	11-15	2200	15-19

NOTE

Time engine with timing light and tachometer at 400 engine RPM or below to the above specifications. The initial advance RPM range is 430 - 580. Distributor advance at 600 engine RPM should be 1° to 5° . Distributor rotation (as viewed from cap end) is counterclockwise.

When checking Distributor on a test stand, the above specifications are 1/2 that shown.

- *..... Four (4) or Six (6) Cylinder Engine STANDARD Points.
- **..... Four (4) or Six (6) Cylinder Engine HEAVY DUTY Points.



INDUSTRIAL TRUCK DIVISION



ADJUST TAPPETS TO THE STATIC COLD SETTINGS LISTED IN THE FOLLOWING CHART:

Engine Model	Intake	Exhaust	NOTE
Y-69	.014"	.014"	Static Cold Settings.
Y-91	.014"	.014"	Static Cold Settings.
Y-112	.014"	.014"	Static Cold Settings.
F-124	.016"	.018"	Static Cold Settings.
F-140	.016"	.018"	Static Cold Settings.
F-162	.016"	.018"	Static Cold Settings.
F-244	.016"	.018"	Static Cold Settings.
F-186	.016"	.018"	Static Cold Settings.
F-209	.016"	.018"	Static Cold Settings.
F-226	.016"	.018"	Static Cold Settings.
F-135	.012"	.020"	Static Cold Settings.
F-163	.012"	.020"	Static Cold Settings.
F-227	.012"	.020"	Static Cold Settings.
F-245	.012"	.020"	Static Cold Settings.

NOTE: Engine Nameplate Tappet Settings is for Hot Idle only.

FOR -- VEHICLES EQUIPPED WITH CONTINENTAL ENGINES.

Contact Point Adjustment: The point opening of new points can be checked with a wire feeler gauge, but the use of a feeler gauge on older, rough points is not recommended, since accurate gauging cannot be done on such points. The gauge measures between high spots on the points instead of the true point opening. Point opening of used points can be checked with a Dwell Angle Meter. A meter of this type indicates the cam or contact angle. This angle is the number of degrees that the breaker cam rotates from the time the points close until they open again. The cam angle increases as the point opening decreases and it is reduced as the point opening is increased. Manufacturers of this type equipment furnish complete instructions as to their use.

NOTE
REFER TO SPECIFICATIONS FOR DWELL ANGLE AND CONTACT POINT OPENING.




Plate 7457. Contact Point Adjustment
To check point opening with a feeler gauge, insert a wire feeler gauge of proper size between the contact points. **MAKE CERTAIN THAT THE BUMPER BLOCK ON THE MOVABLE CONTACT IS AT THE HIGH POINT ON THE CAM.** If adjustment is necessary, loosen the lock screw, and insert a screw driver of

the proper size in the adjustment slot and move the stationary arm until the correct clearance is obtained. Tighten locking screw and recheck point gap. See Plate 7457.

9. IGNITION TIMING

- If the engine is out of time, the following procedure should be followed:
- Remove No. 1 spark plug which is the one nearest the radiator.
 - Press thumb over hold left vacant by removal of the spark plug.
 - With thumb pressed over hole, Plate 7476, turn engine over slowly with the starter until air is being forced up around the thumb.
 - Stop turning engine over at this point for it means that No. 1 piston is on the compression stroke and it is approaching top dead center.




Plate 7476. Ignition Timing

- Flash a light into the timing hole and continue to turn engine over slowly until the 2° after top D.C. marking on flywheel appears in timing hole, Plate 7476.
- The pointer (Plate 7476) should be centered on 2° after top D.C. marking.
- With breaker points set at proper gap, loosen distributor clamp plate screw and rotate distributor body until the contact points just start to open. This may be more accurately checked by means of a test lamp connected between the distributor primary lead and a ground. When points are closed the light will be "ON" and as soon as the points break the light will go "OFF". Tighten clamp plate screws before starting engine.

10. VACUUM TEST

Before making vacuum test, make certain cylinder head is securely tightened and that cylinder head gasket is not leaking. Air cleaner must be installed and must be clean to perform vacuum test. Manifold stud nuts must be tight and there must not be any leakage at gasket.




Plate 6643. Vacuum Test

(a) Remove plug at intake manifold and install vacuum gauge, see Plate 6443. Using the tachometer, set the engine idle speed at 450 to 500 RPM.

Idle Speed Adjustment: A stop screw controls action of the throttle valve. Turn screw clockwise for faster idle speed, or counterclockwise for slower idle speed. This adjustment should be made with a tachometer. Idling speed should be set for 450 to 500 revolutions per minute. Reset idle mixture screw if necessary, after throttle adjustment has been made, see Plate 6889.

(b) Check the vacuum gauge. A steady reading from 18" to 22" of mercury is a normal reading, indicating that valve and spark timing, valve seating, and piston ring sealing are all satisfactory.

(c) A steady but below normal reading indicates a condition common to all cylinders such as a leak at the carburetor gasket, late ignition or valve timing, or uniform piston ring and bore wear.

(d) A slowly fluctuating or drifting reading indicates that the fuel idle mixture is incorrect. Look for the cause in the fuel system.



Plate 6889. Idle Speed Adjustment

(e) A rhythmic pulsating reading is caused by a condition affecting one or more cylinders, but not all, and indicates leaky valve, gasket blow-by, restricted intake port, or an electrical miss.

(f) An intermittent pulsating reading is caused by an occasional malfunction, such as a sticking valve (all valves may be erratic in operation if the valve springs are weak), electrical miss caused by insufficient distributor point tension or low coil voltage coupled with inconsistent spark plug gaps or fouled plugs, or dirt in the fuel system finding its way into passages of critical size or valve seats in the carburetor.

(g) A normal reading that quickly falls off (with engine running at approx. 1860 RPM) indicates exhaust back pressure caused by a restriction in the exhaust system.

(h) Make indicated corrections to bring vacuum to 18" to 22" of mercury normal reading.

Idle Fuel Adjustment: The carburetor is controlled by the idle adjustment screw that regulates the fuel-air mixture, see Plate 6889. Turning the screw clockwise, towards the seat, cuts off air increasing the suction on the idle jet and making the mixture richer. Turning the idle adjusting screw counterclockwise, or away from seat, allows more air to be mixed with the fuel making a leaner mixture for idling.



Plate 6888. Idle Fuel Adjustment

Turn the screw until highest vacuum reading is obtained. If vacuum gauge needle cannot be held steady after these adjustments have been made, report condition to designated person in authority.

If a gauge is not used, set the screw to a range at which engine idles its smoothest.




Plate 7480. Governor Adjustment

11. Governor Adjustment

With timing set at 2 degrees after top dead center and the carburetor properly adjusted to idle at 500 R.P.M., proceed with the following:

A. Loosen governor surge screw jam nut and back surge screw out several turns.

B. With switch key "off" depress accelerator pedal to the floor plate. The bellcrank should have at least 3/8 inch clearance between it and the governor arm with accelerator depressed. See Plate 7480. Adjust the accelerator linkage clevis at the bellcrank to obtain this clearance.

C. With switch key "off" again depress accelerator pedal. This will allow the governor arm to move forward. There should be at least 3/32 inch clearance between the full throttle opening stop and the stop pin on the carburetor. If adjustment is necessary remove the clevis pin from the governor arm and adjust throttle arm clevis until the specified clearance (3/32 inch between stop and stop pin) is obtained. See Plate 7480. Reinstall the clevis pin making sure it is in the outer hole of the governor arm.

D. Push the governor arm rearward until the idle stop screw contacts stop pin on the carburetor. Rotate the governor surge screw inwards until screw comes



INDUSTRIAL TRUCK DIVISION



LUBRICATION AND PREVENTIVE MAINTENANCE

in contact with the governor shaft lever.
(When holding the governor arm rearward).
Do not rotate screw so far that the idle
stop screw moves away from stop pin. When
correct surge screw adjustment is obtained,
tighten jam nut.

E. With the use of an electric tach-
ometer, start engine (warm up to normal
temperature) and check for no-load 2350
R.P.M. If top R.P.M. is too high decrease
tension on the governor spring. If top
R.P.M. is too low increase tension on the
spring.

STARTING MOTOR

1. Remove end plate (or Brush Cover) from starter. Use a wire hook to lift a brush spring and remove brush from holder. Compare brush size with that of a new brush. If brush is worn beyond half the original size, or if brushes are jammed, chipped, or broken they must be replaced.

CAUTION

NEVER ALLOW SPRING TO SNAP DOWN ON BRUSHES.




Plate 6449 Checking Brush Spring Tension

2. Check for Brush Spring Tension, refer to Specifications. Refer to the following procedures for checking spring tension.

Measuring Brush Spring Tension - Reaction Type Brushes. Hook the scale under the brush spring near the end and push or pull on a line parallel to the sides of the brush. To assist in telling the exact instant that the pressure is relieved, a small strip of paper can be placed under the brush. Pull slightly on the paper and the paper will slip out at the correct instant for reading the spring scale.

Measuring Spring Tension - Swinging Type Brushes: Hook the spring scale under the brush screw tight

against the brush and push or pull on a line parallel to the sides of the brush. Take the reading just as the brush leaves the commutator. Pulling slightly on a strip of paper which has been placed under the brush will indicate when the brush leaves the commutator and the correct instant for reading the spring scale.

3. If commutator is glazed or dirty, clean with a strip of No. 00 sandpaper. Blow out all dirt and grit with compressed air.

CAUTION

DO NOT USE EMERY CLOTH TO CLEAN COMMUTATOR.




Plate 6450. Checking Brush Spring Tension

Condition Test: Use one of the two following methods to determine whether the starting motor should be removed from the engine for inspection, service or replacement.

1. First Method: Operate the starting motor by disconnecting the battery cable from the solenoid switch and holding the cable terminal firmly against the starting motor terminal, using a battery known to be fully charged and in good condition. To do this it will be necessary to remove the solenoid switch.

2. If the motor reacts correctly, and the drive mechanism engages and disengages each time the starting motor is operated, the starting motor is in good condition.

3. If motor does not react properly, it must be removed for inspection or replacement.

4. Second Method: Using a voltmeter and a battery (fully charged) that is in good condition, connect positive lead of test voltmeter to positive terminal of battery and negative lead of voltmeter to negative (grounded) terminal of battery. Record voltmeter reading. Now pull high-tension wire from ignition coil so engine will not start when starter is engaged. Connect positive lead of test voltmeter to ground and negative lead of test voltmeter to starter switch terminal. Turn ignition switch to start position and note voltmeter reading. Compare this reading with the previously recorded reading. If the voltage drop is more than 4 volts, or if the second reading is below 8 volts, the starting motor should be removed from the engine for further testing and repair, or replacement.




Plate 3436. Seating Brushes

NOTE

BLOW OUT ABRASIVE PARTICLES AFTER SEATING BRUSHES.

GENERATOR

1. Remove end plate (or Brush Cover) from generator. Use a wire hook to lift a brush spring and remove brush from holder. Compare brush size with that of a new brush. If brush is worn beyond half the original size, or if brushes are jammed, chipped, or broken they must be replaced.

CAUTION

NEVER ALLOW SPRING TO SNAP DOWN ON BRUSHES.

New brushes can be seated with a brush seating stone. When held against the revolving commutator, the abrasive material carries under the brushes, seating them in a few seconds. Blow out abrasive particles after seating brushes. See Plate 3436.

allel to the sides of the brush. To assist in telling the exact instant that the pressure is relieved, a small strip of paper can be placed under the brush. Pull slightly on the paper and the paper will slip out at the correct instant for reading the spring scale.

Measuring Spring Tension - Swinging Type Brushes: Hook the spring scale under the brush screw tight against the brush and push or pull on a line parallel to the sides of the brush. Take the reading just as the brush leaves the commutator. Pulling slightly on a strip of paper which has been placed under the brush will indicate when the brush leaves the commutator and the correct instant for reading the spring scale.

3. If commutator is glazed or dirty, clean with a strip of No. 00 sandpaper. Blow out all dirt and grit with compressed air.

CAUTION

DO NOT USE EMERY CLOTH TO CLEAN COMMUTATOR.




Plate 6451. Checking Brush Spring Tension

Using a spring scale, check for proper brush spring tension. Refer to Specifications. Refer to the following procedures for checking spring tension.

Measuring Brush Spring Tension - Reaction Type Brushes. Hook the scale under the brush spring near the end and push or pull on a line par-



Plate 6450. Checking Brush Spring Tension

NOTE

BLOW OUT ABRASIVE PARTICLES AFTER SEATING BRUSHES.

REGULATOR

Inspect regulator leads for frayed or worn condition. Check to make certain that leads are tight and securely mounted.

WIRING

Check all wires for loose or corroded connections and for fraying. Replace defective wires.




Plate 3436. Seating Brushes

CLEAN AND REPACK DRIVE WHEEL BEARINGS

Every 1000 operating hours, remove and repack the drive wheel bearings.

1. Tilt upright back. Place solid blocks under each upright rail. Tilt upright forward, until vertical to floor. This should allow the drive wheels to clear the floor. Remove drive wheels.



Plate 7477. Axle Hub

WARNING

ON PNEUMATIC TIRE MACHINES, DEFLATE TIRES BEFORE REMOVING WHEELS.

2. Remove axle cotter pin, nut and washer. Pull hub from axle.




Plate 7478. Seal Retainer and Shims

3. Remove the lockwire and capscrews used to secure the seal retainer. Pull retainer and shims from the axle shaft; noting, the number of shims used. (At reassembly the correct shims must be used so that bearings will be adjusted properly).

4. Pull the axle shaft from its housing see Plate 7479.



Plate 7479. Removing Axle Shaft

5. Clean the bearings and shaft in a Stoddard type cleaning solvent. After bearings are clean, blow them dry with compressed air. Direct air stream across bearings to prevent spinning. Slowly rotate bearings by hand to facilitate drying. Inspect bearings and races carefully to determine if they are in good condition and suitable for further service.

6. Repack bearing cones with Clark specification MS9C Wheel Bearing Grease. (Approximately 1 oz. each bearing).

7. If there is any doubt about the serviceability of the bearing seals it is more economical to install new ones to prevent a premature overhaul to replace these parts at a future time. Care should be taken when installing the axle shaft to prevent damage to the inner seal, located in the axle housing.

8. Reassemble all parts in the reverse order of disassembly.

NOTE

CHECK CONDITION OF BRAKE LININGS (SEE FOLLOWING PAGE.)



INDUSTRIAL TRUCK DIVISION



LUBRICATION AND PREVENTIVE MAINTENANCE

BRAKE LININGS

Observe the condition of the brake linings. If linings are worn to a point where they will not be serviceable until the next wheel bearing inspection and lubrication period, it is advisable to replace the linings at this time. If linings are glazed or oil soaked they should be replaced.



INDUSTRIAL TRUCK DIVISION



LUBRICATION AND PREVENTIVE MAINTENANCE

BRAKE BLEEDING PROCEDURE

Proper operation of the hydraulic brake system requires a solid column of fluid without air bubbles at all points in the pressure system. Under certain conditions it becomes necessary to bleed fluid from the system in order to expel air bubbles which have become mixed with the fluid. The necessity of bleeding is indicated by a soft or spongy pedal, or at any time a brake line is removed (or broken) the system must be bled.

Step 1. Tilt upright back. Place solid heavy blocks under each upright rail. Tilt upright forward until vertical to the floor. This should allow the drive wheels to clear the floor. Remove drive wheels.

NOTE

MACHINES EQUIPPED WITH PNEUMATIC TIRES,
DEFLATE TIRES BEFORE REMOVING DRIVE WHEELS
FROM MACHINE.

Step 2. Check the brake pedal free travel (Refer to Specifications). Clean dirt from around the filler cap of the master cylinder reservoir. Brake fluid should be within 1/4" of the top. With filler cap off the master cylinder, depress and release brake pedal. A small displacement of fluid should be noticed in the cylinder reservoir. If this happens, the brake pedal (upon being released) is returning the master cylinder piston to its normal position to open a master cylinder port. This port must be open. If fluid does not return to the reservoir (when releasing brake pedal), this indicates improper pedal free travel and a pedal adjustment is required.

Step 3. To properly bleed the system it is recommended that a pressure bleeder filled with about two quarts of SAE 70R3 heavy duty brake fluid be connected to the master cylinder reservoir. Pressure bleeder should then be pressurized to approximately 30 P.S.I.

Step 4. Loosen line connection at highest position on "T" block point "A" (Plate 6883) and allow fluid and air to escape. Tighten fitting at this point when escaping fluid is free of air bubbles.

Step 5. Install a bleeder hose on one of the wheel cylinder bleeder screws and submerge the unattached end of the hose in a clean transparent jar containing several inches of brake fluid. NOTE: DURING BLEEDING OF THE WHEEL CYLINDERS THE JAR SHOULD BE ELEVATED TO A POSITION HIGHER THAN THE BLEEDER SCREWS MAKING SURE THAT THE END OF THE HOSE REMAINS SUBMERGED IN THE FLUID AT ALL TIMES. Loosen bleeder screw "B" (Plate 6883) enough to allow fluid and air to escape. Tighten bleeder screw at this point when escaping fluid is free of air bubbles.

Step 6. Install bleeder hose on the remaining bleeder screw and proceed as in step five. After all bleeding has been completed close the pressure bleeder shut-off cock and loosen hose connection at master cylinder to allow pressure to escape. Replace master cylinder cap.

Step 7. Replace drive wheels. (Inflate tires if they are of the pneumatic type).

Step 8. Tilt upright back and remove blocking from under each upright rail.

If a pressure bleeder is unavailable the system may be bled manually by following steps four through eight. It must be remembered that the brake pedal should be depressed slowly and held to the floorboard until the line connections or bleeder screws are securely tightened. This prevents the possibility of air being drawn into the system during the bleeding operation. Check master cylinder reservoir level periodically during manual bleeding and fill to within 1/4 inch of the top as required.




Plate 7471. Automatic Brake Adjuster

AUTOMATIC BRAKE ADJUSTERS

When brakes are applied with the machine moving in the direction which permits the operating shoe to leave its anchor, the shoe movement causes a cable to pull on an adjuster lever in contact with the star wheel. When lining wear increase to the point that the lever rises above a particular tooth on the star wheel, it falls into engagement with the tooth. As the operating shoe returns to its anchor (upon release of brakes) an adjuster spring pulls the lever downward, advancing the star wheel one notch (tooth) to expand the shoes. Subsequent braking simply causes the adjuster lever to ride against the next tooth until lining wear

again increases enough for the lever to slip over the tooth and repeat the process.

NOTE

CHECK BRAKE LININGS FOR WEAR EACH TIME THE AXLE ENDS ARE REPACKED. REFER TO PAGE 1000H 805 FOR PROCEDURES AND ILLUSTRATIONS.

PARKING BRAKE ADJUSTMENT

The mechanical "V" block type parking brake operates on the transmission drive shaft brake drum. The only adjustment necessary during the useful life of the brake lining, is a periodic adjustment of the linkage.

To adjust the linkage, remove the floor plates, and adjust the clevis on the linkage, so that the brake handle has 2 inches of upward travel, before resistance is noticed and the brake becomes applied.

The parking brake must be capable of holding the truck, with full rated load, on a 15% grade. This should be tested with the drivers seat occupied, parking brake applied and the truck out of gear. If brake operation is not satisfactory report to designated individual in authority.




Plate 7482. Parking Brake

COOLING SYSTEM

Radiator Pressure Caps:

WARNING

USE EXTREME CARE IN REMOVING THE RADIATOR PRESSURE CAP. IN PRESSURE SYSTEMS, THE SUDDEN RELEASE OF PRESSURE CAN CAUSE A STEAM FLASH AND THE FLASH, OR THE LOOSENED CAP CAN CAUSE SERIOUS PERSONAL INJURY. LOOSEN CAP SLOWLY AND ALLOW STEAM TO ESCAPE.

1. Inspect pressure cap gasket and radiator filler neck to be sure they are providing a proper seal. If the rubber face of the valve is defective, a new cap should be installed.



Plate 6458. Radiator Pressure Cap

2. Inspect pressure cap for freedom of operation.

Pressure caps employ a spring loaded, rubber-faced valve which presses against a seat in the radiator top tank. Pressure caps employ either a vacuum valve held against its seat under spring pressure, or a weighted vacuum valve which hangs open until forced closed by a surge of vapor or coolant. Check to be sure components are free to operate.

NOTE

IF A NEW CAP IS REQUIRED, ALWAYS INSTALL A CAP OF THE SAME TYPE AND PRESSURE RATING. PRESSURE RATING 7 LB.

3. Inspect for dented or clogged overflow pipe. To remove clogged material, run a flexible wire through pipe until obstruction is removed.

When a pressure cap opens the sudden surge of vapor or liquid must pass thru the overflow pipe. If the pipe is dented or clogged, the pressure developed by the obstruction may cause damage to radiator or hoses.

Inspect and Clean Cooling System:

Check hose connections for coolant leaks as well as air leakage. Air leakage around hose connections allows oxygen into the system which is a major factor in corrosion.




Plate 6459. Pressure Cap Gasket, Valve and Valve Gasket

NOTE

EXHAUST GAS LEAKAGE BETWEEN CYLINDER HEAD AND GASKET ALSO RESULTS IN CORROSION. IF EXHAUST GAS DISCHARGES INTO COOLANT, THE COOLANT AND THE GAS COMBINE TO FORM A VARIETY OF ACIDS. IT IS THEREFORE IMPORTANT THAT CYLINDER HEAD STUD NUTS BE DRAWN DOWN TO SPECIFICATIONS AS INSTRUCTED IN "ENGINE TUNE-UP".

LUBRICATION AND PREVENTIVE MAINTENANCE

Using a washing soda solution, flush cooling system in the following manner:

1. Drain system.
2. Replace half of volume with fresh water. Refer to Specifications for capacity.
3. Boil other half of volume and add washing soda until no more will dissolve.
4. Add hot soda solution to cooling system, (fill up).
5. Operate engine normally for 24 hours.
6. Drain, flush, refill with clean water to which a soluble oil has been added in a proportion of 1 ounce per gallon of water.

Maintaining the cooling system efficiency is important, as engine temperatures must be brought up to and maintained within satisfactory range for efficient

operation; however, must be kept from overheating, in order to prevent damage to valves, pistons and bearings. Continued overheating may cause internal damage, while continuously low operating temperature wastes fuel, increases engine wear and causes oil sludge and corrosion of engine parts.

Overcooling may be caused by operating conditions such as excessive idling, low speeds and light loads during cold weather. Overheating may be caused by faulty thermostat, clogged radiator or an improperly adjusted fan belt.

CAUTION

NEVER POUR COLD WATER OR COLD ANTI-FREEZE INTO THE RADIATOR OF AN OVERHEATED ENGINE. ALLOW THE ENGINE TO COOL AND AVOID THE DANGER OF CRACKING THE CYLINDER HEAD OR BLOCK. KEEP ENGINE RUNNING WHILE ADDING WATER.



plate 6461 Typical Radiator

**TRANSMISSION AND AXLE ADAPTER
DRAIN AND REFILL**

The transmission and axle adapter have a common lubrication system and should be drained at operating temperatures, after each 1000 hours of operation.

It is necessary to remove both the axle adapter drain plug and the transmission drain plug, to facilitate complete draining.

After the transmission and axle adapter have completely drained, replace drain plugs and fill thru the axle adapter fill plug, until the lubricant reaches the height of the level test plug. See Plate 7455. Use a straight mineral gear lubricant of a S.A.E. number 90 grade. Replace plugs and operate the machine in forward or reverse for a short time to distribute the lubricant throughout the system. Stop engine and again check level of lubricant at the test plug. Add or drain lubricant as required.

C A U T I O N

DO NOT OVERFILL AS THE EXCESS QUANTITY WILL SERVE NO USEFUL PURPOSE. IF THE OIL LEVEL IS TOO HIGH, IT WILL CAUSE EXCESSIVE OIL CHURNING AND ATTENDANTLY HIGH OIL TEMPERATURE AND POSSIBLE LEAKAGE.




Plate 7455. Axle Adapter

AXLE ADAPTER BREATHER

Check breather to be sure it is free of any obstruction. If breather is dirty remove and clean in a Stoddard type cleaning solvent. Dry breather with compressed air before replacing on axle adapter.




Plate 6662. Main Hydraulic System Pressure Check

Provide a means for connection of a hydraulic pressure gauge at the pressure outlet of the hydraulic pump. One method is to place a "T" in the pressure line leading to the valve as shown in Plate 6662.

C A U T I O N

WITH GAUGE CONNECTED IN THE PRESSURE LINE THERE MUST BE A COMPLETED CIRCUIT TO THE VALVE TO ALLOW THE PRESSURE RELIEF VALVE TO OPERATE.

System pressure should be checked with engine operating at governed 2350 R.P.M. Move lift lever to "raise" position. When lift cylinder reaches maximum height, check gauge reading. Pressure should be reasonably close to the factory preset pressure of 2000 P.S.I.




Plate 7449. Hydraulic Control Levers

LUBRICATION AND PREVENTIVE MAINTENANCE

LIFT CARRIAGE AND UPRIGHT
ROLLER ADJUSTMENTS

To maintain top performance from the upright it may be necessary, from time to time, to adjust the rollers located on the Lift Carriage and Upright Assembly. These adjustments may be accomplished as follows:

Before checking for proper roller clearance, check to be sure the Inner Slide contacts with

both Fabreeka (Stop) Pads at the same time when lowering the Inner Slide.

If adjustment is required, add or remove shims between Fabreeka (Stop) Pads located on the Outer Rail Tie Bar Assembly.

NOTE: More shims may be required on one side than the other in order to allow the Inner Slide to come in contact with both Fabreeka (Stop) Pads at the same time when lowering the Inner Slide.





Plate 6619. Inner Slide Must Contact Both Fabreeka (Stop) Pads
At The Same Time When Lowering Inner Slide

OUTER RAIL ROLLERS SHOULD BE CHECKED FOR ROLLER CLEARANCE THE FULL LENGTH OF THE INNER SLIDE RAIL.

LIFT CARRIAGE ROLLERS SHOULD BE CHECKED FOR ROLLER CLEARANCE THE FULL LENGTH OF THE INNER SLIDE RAIL.

CHECK INNER SLIDE BOTTOM ROLLER IN THIS 10 TO 20 INCH SECTION OF THE OUTER RAIL.

OUTER RAIL ROLLERS SHOULD BE CHECKED FOR ROLLER CLEARANCE THE FULL LENGTH OF THE INNER SLIDE RAIL.



NOTE
ROLLER CLEARANCE SHOULD NOT EXCEED 1/32 INCH.

NOTE

IF UPRIGHT RAILS ARE COCKED IN POSITION AS SHOWN, AND IF CLEARANCE IS CHECKED ON THIS SIDE, CLEARANCE IS MEASURED BETWEEN THE UPPER EDGE OF THE ROLLER RIM AND CORRESPONDING RAIL.

NOTE

IF UPRIGHT RAILS ARE COCKED IN POSITION AS SHOWN, AND IF CLEARANCE IS CHECKED ON THIS SIDE, CLEARANCE IS MEASURED BETWEEN THE LOWER EDGE OF THE ROLLER RIM AND CORRESPONDING RAIL.

UPRIGHT ROLLER ADJUSTMENTS.

NOTE

THE UPRIGHT OUTER RAIL ASSEMBLY IS MANUFACTURED WITH A SLIGHT TAPER, THE BOTTOM BEING 1/16 INCH WIDER THAN THE TOP. EXTEND THE UPRIGHT TO THE UPPER LIMIT. CHECK TO BE SURE THERE IS NO BIND. LOWER UPRIGHT. IF THERE IS A BIND, THE INNER SLIDE WILL HESITATE OR REMAIN AT THE UPPER LIMIT. AS THE LIFT CYLINDER BEGINS TO RETRACT, THE INNER SLIDE WILL BREAK FREE AND THEN LOWER. THIS INDICATES IMPROPER ADJUSTMENT, OR THIS MAY INDICATE A DAMAGED ROLLER WHICH WILL NOT ROTATE. RAISE AND LOWER CARRIAGE AND CHECK TO BE SURE ALL ROLLERS ROTATE FREELY.

1. Because of the 1/16 inch taper in the Outer Rail Assembly, the rollers may bind when upright is extended if roller adjustment is made with the upright lowered; therefore, the upright must be extended to the upper limit (with no backward or forward tilt) before making any adjustments.

2. Insert pry bar between bottom end of either right or left Inner Slide (Rail), and Outer Rail, refer to Plate 6891.




Plate 6325. Upright Roller

3. Move Inner Slide sideways to remove all clearance at opposite rail.

4. When checking clearance on the side that pry bar was installed, there must be some clearance between the Outer Rail and the bottom roller at the lower edge of the Roller Rim. THIS CLEARANCE SHOULD NOT EXCEED 1/32 INCH. If clearance is checked on opposite side, clearance should be checked between Outer Rail and bottom roller at the upper edge of Roller Rim, refer to Plate 6891 and 6325.

NOTE

THE BOTTOM ROLLERS OF THE INNER SLIDE, MUST BE CHECKED FOR CLEARANCE IN A 10 TO 20 INCH SECTION STARTING AT TOP OF OUTER RAIL ASSEMBLY, SEE Plate 6572.

5. Check clearance between Outer Rail Upper Rollers and Inner Slide. ROLLER CLEARANCE SHOULD BE CHECKED THE FULL LENGTH OF THE INNER SLIDE ASSEMBLY. Refer to Step 4 for Roller Clearance Specifications.

6. If adjustment is required, proceed as follows:

7. Disassemble upright.




Plate 6572. Outer Rail Roller Clearance Check



INDUSTRIAL TRUCK DIVISION



LUBRICATION AND PREVENTIVE MAINTENANCE

8. Remove rollers from shafts and add or remove shims to acquire the clearance previously stated.

N O T E

THE ROLLER SHAFTS ARE WELDED TO THE RAIL ASSEMBLIES. TO REMOVE ROLLERS, MERELY PULL ROLLERS FREE OF ROLLER SHAFTS.

9. Reassembly upright.

10. Follow Steps 1 thru 5 and recheck clearance.




Plate 7000. Lift Carriage

LIFT CARRIAGE ROLLER ADJUSTMENTS

CARRIAGE MUST BE ADJUSTED SO IT IS HORIZONTAL AND CENTERED IN THE UPRIGHT FRAME. ROLLER CLEARANCE SHOULD BE CHECKED THE FULL LENGTH OF THE RAILS. ROLLERS SHOULD HAVE CLEARANCE OF NOT MORE THAN 1/32 INCH AT EACH SIDE.

Carriage Rollers are adjusted with shims placed on roller shaft between roller and carriage frame.

NOTE

CARRIAGE ROLLERS SHAFTS ARE WELDED TO CARRIAGE FRAME. TO REMOVE ROLLERS MERELY PULL ROLLER FREE OF SHAFT.

If adjustment is necessary refer to Steps 4 and 8.

Outer Side Thrust Rollers

The Outer Side Thrust Rollers do not require adjustment. These should be replaced in the event of wear or damage. The maximum clearance is 1/16 inch at each side.

Tighten the Outer Side Thrust Roller Shafts to 150 pound feet torque. The end of these shafts have a machined groove. Stake with a punch at each end of groove as shown in Plate 7000 This will secure shaft to lift carriage.

Inner Side Thrust Rollers

1. Check the clearance between the Inner Side Thrust Rollers and Inner Rails. Maximum allowable clearance is 1/32 inch

or 1/64 inch at each side. Rollers must be free to rotate without binding. See Plate 7000.

If adjustment is required, proceed as follows:

2. Elevate carriage and place a suitable support under the carriage. Plate 8623.




Plate 8623. Carriage Support

3. Remove carriage lift chain pins & replace with similar sized bolts. Plate 8599.

4. Remove carriage support, lower carriage to bottom, and tilt upright a little forward of vertical till carriage rests on the floor.

5. Remove bolts, raise channel, and back away from carriage. Plate 8922.

6. Add or remove shims as required to obtain correct clearance. Plate 8923.

7. Reinstall carriage by reversing steps 2-5.




Plate 8599. Carriage Pin Replacement




Plate 8922. Carriage Removed




Plate 8923. Shim Adjustment



Plate 6323. Upright Roller




Plate 6328. Roller Bearing Lubrication

UPRIGHT AND CARRIAGE ROLLER LUBRICATION

The manufacturer does not recommend removing a bearing seal for periodic lubrication.

Bearings are generally provided with four openings (on the bearings front face, between the waffle pattern) for lubrication with an Injection Needle.

This needle is a standard hypodermic type needle and can be purchased in drug stores, refer to Plate 6328.

A good light petroleum base oil should be used.



INDUSTRIAL TRUCK DIVISION



TROUBLE SHOOTING GUIDE

ENGINE

TROUBLE	PROBABLE CAUSE	REMEDY
Starting motor will not crank engine.	<p>Battery discharged</p> <p>Battery cable terminals loose or corroded. Ignition Fuse blown.</p> <p>Starting motor drive gear jammed in flywheel teeth.</p> <p>Improper oil.</p> <p>Battery cable terminal broken.</p> <p>Poor starting switch contacts.</p> <p>Faulty Neutral Starting Switch.</p>	<p>Recharge or replace battery.</p> <p>Remove and clean, reinstall and tighten cables. Replace fuse.</p> <p>Loosen starting motor and free-up gear.</p> <p>Change oil to proper grade.</p> <p>Replace cable.</p> <p>Replace switch.</p> <p>Refer to Starting Motor.</p>
Starting motor operates, but fails to crank engine when switch is engaged.	<p>Starting motor gear does not engage flywheel.</p> <p>Starting motor or drive gear defective.</p>	<p>Remove starting motor, and clean drive mechanism.</p> <p>Replace starting motor.</p>
<u>Engine will not start.</u> No spark. Ammeter shows no discharge (Zero reading) with ignition switch "on".	<p>Ignition switch partly "on".</p> <p>Ignition switch defective.</p> <p>Ignition primary wires or starting motor cables broken or connections loose.</p> <p>Ignition coil primary winding open.</p> <p>Distributor points dirty.</p> <p>Distributor points not closing.</p> <p>Loose or corroded ground, or battery cable connections.</p>	<p>Turn switch "on" fully.</p> <p>Replace switch.</p> <p>Repair, or replace and tighten.</p> <p>Replace coil.</p> <p>Clean and adjust points.</p> <p>Adjust or replace points.</p> <p>Remove and clean, reinstall and tighten cables.</p>
<u>Engine will not start.</u> Ammeter showing abnormal discharge with ignition switch "on".	<p>Defective condenser.</p> <p>Short-circuited or burned distributor cap or rotor.</p> <p>Short-circuited wire between ammeter and ignition switch.</p> <p>Short-circuited primary winding in ignition coil.</p> <p>Distributor points not opening.</p>	<p>Replace condenser.</p> <p>Replace parts.</p> <p>Repair or replace wire.</p> <p>Replace coil.</p> <p>Clean or replace, and adjust points.</p>
Weak spark.	<p>Distributor points pitted or burned.</p> <p>Distributor condenser weak.</p> <p>Ignition coil weak.</p>	<p>Clean or replace, and adjust points.</p> <p>Replace condenser.</p> <p>Replace coil.</p>



INDUSTRIAL TRUCK DIVISION



TROUBLE SHOOTING GUIDE

ENGINE (Continued)

TROUBLE	PROBABLE CAUSE	REMEDY
<p><u>Engine will not start.</u> Weak spark (continued)</p>	<p>Primary wire connections loose.</p> <p>High-tension, spark plug wires, or distributor cap wet.</p> <p>High-tension, spark plug wires, or distributor cap damaged.</p> <p>Distributor cap or rotor burned or broken.</p> <p>Spark plug gap incorrect.</p> <p>Short-circuited secondary circuit in coil.</p>	<p>Tighten.</p> <p>Dry thoroughly.</p> <p>Replace defective parts.</p> <p>Replace defective parts.</p> <p>Reset gaps.</p> <p>Replace coil.</p>
<p>Good spark.</p>	<p>Fuel tank empty.</p> <p>Dirt or water in carburetor, or float stuck.</p> <p>Carburetor and engine flooded by excessive use of choke.</p> <p>Fuel does not reach carburetor.</p> <p>Dirt in fuel lines or tank.</p> <p>Fuel line pinched.</p> <p>Ignition wires incorrectly installed in distributor cap.</p> <p>Ignition timing incorrect.</p> <p>Fuel Strainer Clogged.</p> <p>Fuel pump does not pump.</p> <p>Lack of engine compression.</p>	<p>Refill tank.</p> <p>Drain and clean carburetor.</p> <p>Depress accelerator pedal fully, crank engine with starting motor, when engine starts, reset throttle and leave choke control "in".</p> <p>Inspect for damaged or leaky lines or air leak into line between tank and fuel pump.</p> <p>Disconnect lines, drain tank, and blow out lines.</p> <p>Repair or replace line.</p> <p>Install wires correctly.</p> <p>Reset timing.</p> <p>Remove and clean strainer.</p> <p>Clean screen, replace pump if defective.</p> <p>Report to designated individual in authority.</p>
<p>Backfiring.</p>	<p>Ignition out of time.</p> <p>Spark plug wires incorrectly installed distributor cap or at spark plugs.</p> <p>Distributor cap cracked or shorted.</p> <p>Valve holding open.</p>	<p>Reset timing.</p> <p>Install wires correctly.</p> <p>Replace cap.</p> <p>Report to designated individual in authority.</p>

TROUBLE SHOOTING GUIDE

ENGINE (Continued)

TROUBLE	PROBABLE CAUSE	REMEDY
Engine operates, but backfires and spits.	Improper ignition timing.	Reset timing.
	Spark plug wires incorrectly installed in distributor cap.	Install wires correctly.
	Dirt or water in carburetor.	Drain and clean carburetor.
	Carburetor improperly adjusted.	Clean and adjust carburetor.
	Carburetor float level low.	Report to designated individual in authority.
	Valve sticking or not seating properly, burned or pitted.	Report to designated individual in authority.
	Excessive carbon in cylinders.	Remove carbon from cylinders.
	Valve springs weak.	Report to designated individual in authority.
	Heat control valve not operating.	Free-up, and adjust valve.
	Fuel pump pressure low.	Clean screen; replace pump, if defective.
	Fuel strainer clogged.	Remove and clean strainer.
	Partly clogged or pinched fuel lines.	Clean and repair lines.
	Intake manifold leak.	Inspect gaskets and tighten manifold stud nuts.
Distributor cap cracked or shorted.	Replace cap.	
Engine stalls on idle.	Carburetor throttle valve closes too far, or idle mixture incorrect.	Adjust carburetor.
	Carburetor choke valve remains closed.	Free-up and lubricate valve.
	Dirt or water in idler passages of Carburetor.	Clean or replace carburetor.
	Air leak at intake manifold.	Inspect gaskets and tighten manifold stud nuts.
	Heat control valve defective.	Free-up and adjust valve.
	Spark plugs defective, gaps incorrect.	Clean or replace spark plugs, set gap clearance.
	Ignition timing early.	Reset timing.
	Low compression.	Report to designated individual in authority.
Water leak in cylinder head or head gaskets.	Replace gasket; report cylinder head leak to designated individual in authority.	



INDUSTRIAL TRUCK DIVISION



TROUBLE SHOOTING GUIDE

ENGINE (Continued)

TROUBLE	PROBABLE CAUSE	REMEDY
Engine misfires on one or more cylinders.	<p>Dirty spark plugs.</p> <p>Spark plug gap incorrect.</p> <p>Cracked spark plug porcelain.</p> <p>Spark plug wires grounded.</p> <p>Spark plug wires incorrectly installed in cap or at spark plugs.</p> <p>Distributor cap or rotor burned or broken.</p> <p>Valve tappet holding valve open.</p> <p>Low engine compression.</p> <p>Leaky cylinder head gasket.</p> <p>Cracked cylinder block, broken valve tappet or tappet screw.</p>	<p>Clean, adjust, or replace plugs.</p> <p>Reset gap.</p> <p>Replace spark plug.</p> <p>Replace wires.</p> <p>Install wires correctly.</p> <p>Replace defective parts.</p> <p>Report to designated individual in authority.</p> <p>Report to designated individual in authority.</p> <p>Replace gasket.</p> <p>Report to designated individual in authority.</p>
Engine does not idle properly.	<p>Ignition timing.</p> <p>Dirty spark plugs, or gaps too close.</p>	<p>Reset timing.</p> <p>Clean and adjust spark plugs.</p>
Engine misses at high speeds.	<p>Ignition coil or condenser weak.</p> <p>Distributor points sticking, dirty or improperly adjusted.</p> <p>Distributor rotor or cap cracked or burned.</p> <p>Leaky cylinder head gaskets.</p> <p>Uneven cylinder compression.</p> <p>High-tension or spark plug wires leaky, cracked insulation.</p> <p>Carburetor choke not adjusted.</p> <p>Carburetor accelerating pump system defective, dirt in metering jets or float level incorrect.</p> <p>Fuel pump defective, causing lack of fuel.</p> <p>Air cleaner dirty.</p> <p>Heat control valve defective.</p>	<p>Replace defective parts.</p> <p>Clean, adjust, or replace points.</p> <p>Replace defective parts.</p> <p>Replace gaskets.</p> <p>Report to designated individual in authority.</p> <p>Replace defective parts.</p> <p>Adjust choke.</p> <p>Report to designated individual in authority.</p> <p>Clean screen, replace defective pump.</p> <p>Clean complete air cleaner and refill oil cup.</p> <p>Free-up and adjust</p>



INDUSTRIAL TRUCK DIVISION



TROUBLE SHOOTING GUIDE

ENGINE (Continued)

TROUBLE	PROBABLE CAUSE	REMEDY
Engine misses at high speeds. (continued)	<p>Valves sticking, weak or broken valve springs.</p> <p>Fuel strainer clogged.</p> <p>Weak distributor bracket arm spring</p> <p>Excessive play in distributor shaft bearing.</p> <p>Spark plugs defective, dirty or gap incorrectly set.</p>	<p>Report to designated individual in authority.</p> <p>Remove and clean strainer.</p> <p>Replace point set.</p> <p>Replace distributor.</p> <p>Clean, adjust or replace spark plugs.</p>
Engine pings (Spark Knock).	<p>Ignition timing early.</p> <p>Distributor automatic spark advance stuck in advance position, or spring broken.</p> <p>Excessive carbon deposit in cylinders.</p> <p>Incorrect fuel.</p>	<p>Reset timing.</p> <p>Replace distributor.</p> <p>Remove cylinder head and clean.</p> <p>Drain, use correct fuel.</p>
Engine lacks power.	<p>Ignition timing late.</p> <p>Incorrect fuel.</p> <p>Leaky cylinder head gasket.</p> <p>Excessive carbon formation.</p> <p>Engine runs cold.</p> <p>Insufficient oil, or improper grade oil.</p> <p>Oil system failure.</p> <p>Air Cleaner dirty.</p> <p>Spark plug gaps too wide.</p> <p>Choke valve partially closed, or throttle does not open fully.</p> <p>Manifold heat control inoperative.</p> <p>Exhaust pipe, muffler or tail pipe obstructed.</p> <p>Low compression, broken valve springs, sticking valves.</p>	<p>Reset timing.</p> <p>Use correct fuel.</p> <p>Replace gasket.</p> <p>Remove cylinder head, and clean cylinder head, piston heads, cylinder block, and valves.</p> <p>Test thermostat; in cold weather, cover radiator.</p> <p>Lubricate in accordance with lubrication section.</p> <p>Report to designated individual in authority.</p> <p>Clean complete air cleaner, change oil in cup.</p> <p>Reset gaps.</p> <p>Adjust valve or throttle.</p> <p>Free-up and adjust control.</p> <p>Service or replace obstructed parts.</p> <p>Report to designated individual in authority.</p>



INDUSTRIAL TRUCK DIVISION



TROUBLE SHOOTING GUIDE

ENGINE (Continued)

TROUBLE	PROBABLE CAUSE	REMEDY
Engine lacks power. (Continued)	Improper tappet adjustment. Lack of fuel.	Adjust tappets. Clean filter, inspect fuel pump, inspect carburetor for water or dirt and clean if necessary.
Engine overheats.	Cooling system deficient. Water low, air flow through radiator core restricted. Clogged radiator core (Clogged internally). Cylinder head gasket leaking. Radiator or water pump leaking. Damaged or deteriorated hose or fan belt. Loose fan belt. Cylinder block or head leaking. Ignition timing incorrect. Damaged muffler, bent or clogged exhaust pipe. Excessive carbon in cylinders. Insufficient oil, or improper grade. Air Cleaner restricted. Inoperative thermostat. Water pump impeller broken. Poor compression. Valve timing incorrect.	Clean radiator core from engine side with compressed air or water, or fill radiator to proper level. Clean by flushing radiator. Tighten cylinder head stud nuts and/or replace gasket. Repair or replace defective parts. Replace defective parts. Adjust fan belt tension. Report to designated individual in authority. Reset timing. Service or replace defective parts. Remove cylinder head, and clean cylinder head, piston heads cylinder block, and valves. Refer to Lubrication Instructions. Clean complete change oil in cup. Replace thermostat and gasket. Replace pump. Report to designated individual in authority. Reset timing.
High fuel consumption.	High engine speeds (Excessive driving in lower gear range). Air cleaner clogged. Carburetor float level too high, accelerating pump not properly adjusted. Fuel line leaks.	Correct driving practice. Clean complete air cleaner and change oil in cup. Report to designated individual in authority. Correct leaks, replace lines.



INDUSTRIAL TRUCK DIVISION



TROUBLE SHOOTING GUIDE

ENGINE (Continued)

TROUBLE	PROBABLE CAUSE	REMEDY
High fuel consumption. (Continued)	<p>Overheated engine.</p> <p>Carburetor parts worn or broken.</p> <p>Fuel pump pressure too high, or leaky diaphragm.</p> <p>Engine running cold.</p> <p>Ignition incorrectly timed.</p> <p>Spark advance stuck.</p> <p>Leaking fuel pump bowl gasket.</p> <p>Low compression.</p> <p>Carburetor controls sticking.</p> <p>Engine idles too fast.</p> <p>Spark plugs dirty.</p> <p>Weak coil or condenser</p> <p>Clogged muffler, or bent exhaust pipe.</p> <p>Loose engine mounts, permitting engine to shake and raise fuel level in carburetor.</p>	<p>See "Engine overheats".</p> <p>Replace fuel carburetor.</p> <p>Replace fuel pump.</p> <p>Inspect thermostat, cover radiator in winter.</p> <p>Reset timing.</p> <p>Replace distributor.</p> <p>Replace gasket.</p> <p>Report to designated individual in authority.</p> <p>Free-up and lubricate controls.</p> <p>Adjust carburetor throttle stop screw.</p> <p>Clean or replace spark plugs.</p> <p>Replace coil or condenser.</p> <p>Service or replace defective parts.</p> <p>Tighten; if damaged, replace defective mounts.</p>
High oil consumption.	<p>High engine speeds, or excessive driving in low gear range.</p> <p>Oil leaks.</p> <p>Improper grade oil, or diluted oil.</p> <p>Overheating of engine causing thinning of oil.</p> <p>Oil filter clogged.</p> <p>Defective piston or rings, excessive side clearance of intake valves in guides, cylinder bores worn (scored, out-of-round, tapered); excessive bearing clearance, misaligned connecting rods.</p>	<p>Correct driving practice.</p> <p>Replace leaking gaskets.</p> <p>Use new oil of proper grade.</p> <p>See "Engine overheats".</p> <p>Clean filter case thoroughly and replace element.</p> <p>Report to designated individual in authority.</p>



INDUSTRIAL TRUCK DIVISION



TROUBLE SHOOTING GUIDE

ENGINE (Continued)

TROUBLE	PROBABLE CAUSE	REMEDY
Low oil pressure.	<p>Insufficient oil supply.</p> <p>Improper grade of oil, or diluted oil foaming at high speeds.</p> <p>Oil too heavy (funneling in cold weather).</p> <p>Oil pump screen clogged.</p> <p>Oil leaks.</p> <p>Faulty oil pump, pressure regulator valve stuck or improperly adjusted, or spring broken.</p>	<p>Fill crankcase to prescribed level.</p> <p>Change oil, inspect crankcase ventilator, inspect for water in oil.</p> <p>Change to proper grade oil. (Refer to Lubrication Instructions.)</p> <p>Remove oil pan and clean pump screen.</p> <p>Report to designated individual in authority.</p> <p>Report to designated individual in authority.</p>
Defective valves.	<p>Incorrect tappet adjustment.</p> <p>Other valve troubles.</p>	<p>Adjust tappets.</p> <p>Report to designated individual in authority.</p>
Abnormal engine noises.	<p>Loose fan, fan pulley or belt, heat control valve.</p> <p>Leaking intake or exhaust manifold or gaskets, cylinder head gasket, or spark plugs.</p> <p>Overheated engine, clogged exhaust system.</p> <p>Other abnormal engine noises.</p>	<p>Tighten or correct conditions as required.</p> <p>Tighten loose components or replace defective gaskets.</p> <p>Remove obstruction from exhaust system. Inspect for further serviceability.</p> <p>Report to designated individual in authority.</p>
Poor compression.	<p>Incorrect tappet adjustment.</p> <p>Leaking, sticking, or burned valves; sticking tappets; valve spring weak or broken; valve stems and guides worn; piston ring grooves worn or rings worn, broken, or stuck; cylinder bores scored or worn.</p>	<p>Adjust tappets.</p> <p>Report to designated individual in authority.</p>



INDUSTRIAL TRUCK DIVISION



TROUBLE SHOOTING GUIDE

FUEL SYSTEM

TROUBLE	PROBABLE CAUSE	REMEDY
Fuel does not reach carburetor.	No fuel in fuel tank. Fuel pump inoperative. Fuel line air leak between tank and fuel pump. Fuel line clogged. Fuel tank cap vent clogged.	Fill fuel tank. Replace pump. Repair or replace line. Disconnect and blow out lines. Clean vent.
Fuel reaches carburetor, but does not reach cylinders.	Choke does not close. Fuel passage in carburetor clogged. Carburetor float valve stuck closed.	Free-up and lubricate, inspect for proper operation. Clean or replace carburetor. Report to designated individual in authority.
High fuel consumption.	Lubricant in power train too heavy. Incorrect adjustment of carburetor. Vehicle overloaded. Tires improperly inflated. Tight brakes.	Use correct lubricant. Adjust carburetor. Reduce loads to specified maximum capacity. Inflate tires properly. Adjust brakes.
Low fuel pressure.	Air leak in fuel lines. Fuel pump defective, diaphragm broken; valves leaking, linkage worn. Fuel lines clogged.	Tighten connections, repair lines if damaged. Replace fuel pump. Clean or replace lines.
Engine idles too fast.	Improper carburetor throttle stop adjustment. Carburetor control sticking. Control return spring weak.	Adjust throttle stop screw. Free-up and lubricate control. Replace spring.
Fuel gauge does not register.	Loose wire connection at instrument panel or tank unit. Instrument panel unit or tank unit inoperative.	Tighten connections. Replace unit.



INDUSTRIAL TRUCK DIVISION



TROUBLE SHOOTING GUIDE

CLUTCH

TROUBLE	PROBABLE CAUSE	REMEDY
Clutch slips.	<p>Improper pedal adjustment.</p> <p>Release linkage binding.</p> <p>Clutch facings burned or worn, torn loose from plate, or oil soaked.</p> <p>Weak pressure spring.</p> <p>Sticking pressure plate.</p> <p>Weak or broken retractor springs.</p> <p>Damaged pilot or clutch release bearing.</p>	<p>Adjust pedal free travel.</p> <p>Free-up and lubricate linkage.</p> <p>Report to designated individual in authority.</p> <p>Report to designated individual in authority.</p> <p>Report to designated individual in authority.</p> <p>Replace. Report to designated individual in authority.</p> <p>Replace. Report to designated individual in authority.</p>
Clutch grabs or chatters.	<p>Control linkage binding.</p> <p>Loose engine mounting.</p> <p>Facings burned, worn, or loose on driven plate; driven plate crimped, flattened out, worn, or binding on splined shaft.</p> <p>Pressure plate or clutch adaptor face scored or rough; pressure plate broken.</p> <p>Excessive looseness in power train.</p> <p>Oil on facings, or excessively worn disc surfaces.</p> <p>Sticking pressure plate.</p>	<p>Free-up and lubricate linkage.</p> <p>Tighten engine mounts.</p> <p>Report to designated individual in authority.</p> <p>Report to designated individual in authority.</p> <p>Report to designated individual in authority.</p> <p>Report to designated individual in authority.</p> <p>Report to designated individual in authority.</p>
Clutch drags.	<p>Excess pedal free play.</p> <p>Driven plate warped, facings torn or loose.</p> <p>Pressure plate warped or binds, improper clutch lever adjustment.</p>	<p>Adjust pedal free play.</p> <p>Report to designated individual in authority.</p> <p>Report to designated individual in authority.</p>
Clutch rattles.	<p>Clutch pedal return spring broken or disconnected.</p>	<p>Replace or connect spring.</p>



INDUSTRIAL TRUCK DIVISION



TROUBLE SHOOTING GUIDE

CLUTCH (Continued)

TROUBLE	PROBABLE CAUSE	REMEDY
Clutch rattles. (Continued)	Release fork loose on ball stud. Worn pressure plate, or broken return springs at driving lugs; worn driven plate hub on splined shaft, worn release bearings, pilot bushing worn.	Adjust clutch pedal free travel to one inch. Report to designated individual in authority.



INDUSTRIAL TRUCK DIVISION




TROUBLE SHOOTING GUIDE

COOLING SYSTEM

TROUBLE	PROBABLE CAUSE	REMEDY
Overheating.	Unusual operating conditions of high temperature.	Inspect. (Refer to "Engine overheats".)
Loss of cooling solution.	Loose hose connections. Damaged or deteriorated hose. Leaking radiator.	Tighten hose connections. Replace hoses. Repair or replace radiator.
Engine operates too cool.	Thermostat sticking. Low air temperature.	Replace thermostat and gasket. Cover radiator.
Noises.	Frayed or loose fan belt. Water pump defective.	Replace or adjust belt. Replace pump.

THE ENGINE COOLING SYSTEM

Trouble spots resulting from service neglect



- ① External Leakage
- ② Internal Leakage
- ③ Rust Deposits
- ④ Heat Cracks
- ⑤ Exhaust Gas Leakage
- ⑥ Air Suction
- ⑦ Clogged Air Passages
- ⑧ Stuck Thermostat
- ⑨ Sludge Formation in Oil
- ⑩ Transmission Oil Cooler
- ⑪ Heat Damage
- ⑫ Hose Failure
- ⑬ Worn Fan Belt
- ⑭ Pressure Cap Leakage
- ⑮ Temperature Control Fan Drive

The cooling system depicted here does not represent that of any particular make of car, it incorporates features used by many different manufacturers.

All Rights Reserved.
No Part of This Chart May Be Reproduced Without Permission From Union Carbide Corporation.

Cooling System Care Pays!

This chart is distributed as a public service by
UNION CARBIDE CONSUMER PRODUCTS COMPANY

 Division of Union Carbide Corporation



INDUSTRIAL TRUCK DIVISION



TROUBLE SHOOTING GUIDE

IGNITION SYSTEM

TROUBLE	PROBABLE CAUSE	REMEDY
Ignition system troubles.	<p>Weak spark.</p> <p>Timing incorrect.</p> <p>Moisture on distributor wires, coil, or spark plugs.</p> <p>Ignition switch inoperative.</p> <p>Primary or secondary wiring loose, broken, or grounded.</p> <p>Coil defective.</p> <p>Distributor defective.</p> <p>Spark plug defective.</p>	<p>Refer to "Engine will not start".</p> <p>Retime ignition.</p> <p>Clean and dry thoroughly.</p> <p>Replace switch.</p> <p>Service.</p> <p>Refer to "Ignition coil troubles", below.</p> <p>Refer to "Distributor troubles", below.</p> <p>Refer to spark plug troubles below.</p>
Ignition coil.	<p>Connections loose; dirty or broken external wire, wet.</p> <p>Coil defective.</p>	<p>Clean and tighten, or repair, dry thoroughly.</p> <p>Replace coil.</p>
Distributor troubles.	<p>Distributor breaker points dirty or pitted, point gaps incorrect.</p> <p>Distributor breaker point arm spring weak.</p> <p>Distributor breaker points sticking.</p> <p>Distributor automatic advance defective.</p> <p>Distributor cap or rotor shorted, cracked or broken.</p> <p>Distributor rotor does not turn.</p> <p>Condenser defective.</p>	<p>Clean, adjust or replace breaker points.</p> <p>Replace breaker point arm.</p> <p>Free-up breaker points.</p> <p>Lubricate and free-up. If seized, replace distributor.</p> <p>Replace defective parts.</p> <p>Report to designated individual in authority.</p> <p>Replace condenser.</p>
Spark plug troubles.	<p>Cracked, broken, leaking, or improper type.</p> <p>Spark plug wires incorrectly installed on plugs or in distributor cap.</p> <p>Spark plugs dirty; gap incorrect.</p> <p>Spark plug porcelain cracked or broken.</p>	<p>Replace spark plug.</p> <p>Install wires correctly.</p> <p>Clean, set gaps, or replace plugs.</p> <p>Replace plug.</p>



INDUSTRIAL TRUCK DIVISION



TROUBLE SHOOTING GUIDE

STARTING MOTOR

TROUBLE	PROBABLE CAUSE	REMEDY
Starting motor cranks engine slowly.	<p>Engine oil too heavy.</p> <p>Battery charge low.</p> <p>Battery cell shorted.</p> <p>Battery connections corroded, broken, or loose.</p> <p>Dirty commutator.</p> <p>Insufficient brush surface contact.</p> <p>Defective starting motor.</p> <p>Starting switch defective.</p>	<p>Change to proper grade oil.</p> <p>Recharge or replace battery.</p> <p>Replace battery.</p> <p>Clean and tighten, or replace cables.</p> <p>Clean commutator.</p> <p>Free-up or replace brush.</p> <p>Replace starting motor.</p> <p>Replace switch.</p>
Starting motor does not crank engine.	<p>Engine oil too heavy.</p> <p>Starting motor, Solenoid, or cables defective; loose connections.</p> <p>Starting motor pinion gear jammed in flywheel drive gear.</p> <p>Dirty drive mechanism.</p> <p>Faulty Relay Switch.</p> <p>Ignition Fuse Blown.</p> <p>Faulty Ignition Switch.</p> <p>Faulty Neutral Starting Switch.</p>	<p>Change to proper grade oil.</p> <p>Replace or tighten loose connections.</p> <p>Remove starting motor and reinstall. Replace defective driving gear.</p> <p>Clean and lubricate drive mechanism.</p> <p>Replace Relay Switch.</p> <p>Replace Fuse.</p> <p>Replace Switch.</p> <p>Replace Switch.</p> <p>NOTE: The INDEX of this manual will list an ADJUSTABLE Neutral Starting Switch if your machine is so equipped.</p>



INDUSTRIAL TRUCK DIVISION



TROUBLE SHOOTING GUIDE

GENERATOR TROUBLES

TROUBLE	PROBABLE CAUSE	REMEDY
No output.	Regulator defective.	Replace regulator.
Low or fluctuating output.	Loose fan belt. Insufficient brush surface contact. Weak brush springs. Worn commutator. Broken or loose connections. Dirty commutator. Regulator defective. Loose or dirty connections in charging circuit.	Adjust belt. Free-up or replace brush. Replace spring. Report to designated individual in authority. Repair, tighten or replace. Clean commutator. Replace regulator. Clean and tighten connections.
Excessive output.	Short circuit between field coil and armature leads. Regulator defective.	Replace generator. Replace regulator.
Noisy.	Loose pulley or generator mounting. Defective bearings, or armature rubbing on field poles. Improperly seated brushes.	Tighten. Replace generator. Seat brushes.
Generator regulator troubles.	Loose connections or mountings. Defective regulator.	Clean and tighten. Replace regulator.

TROUBLE SHOOTING GUIDE

BATTERY, LIGHTS AND HORN

TROUBLE	PROBABLE CAUSE	REMEDY
Battery discharged.	<p>Battery solution level low.</p> <p>Short in battery cell.</p> <p>Generator not charging.</p> <p>Loose or dirty connections; broken cables.</p> <p>Excessive use of starting motor.</p> <p>Idle battery, or excessive use of lights with engine at idle.</p> <p>Short circuits.</p>	<p>Add distilled water to bring level above plates; inspect for cracked case.</p> <p>Replace battery.</p> <p>Inspect generator, fan belt, and regulator.</p> <p>Clean and tighten connections; replace cables.</p> <p>Tune up engine; charge battery.</p> <p>Recharge or replace battery. Use lights sparingly.</p> <p>Replace defective wiring.</p>
Battery (other troubles)	<p>Overheated battery.</p> <p>Case bulged (or out of shape).</p>	<p>Inspect for short circuit or excessive generator charge.</p> <p>Inspect for overcharging and over-tightening of hold-down screws.</p>
Light switch.	<p>Loose or dirty connections; broken wire.</p> <p>Defective switch.</p>	<p>Clean and tighten; replace broken wire.</p> <p>Replace switch.</p>
Wiring.	<p>Loose or dirty connections; broken wire or terminal.</p>	<p>Clean, tighten, repair or replace. Wire or terminal.</p>
Lights do not light.	<p>Switch not fully "on".</p> <p>Loose or dirty connections; broken wire.</p> <p>Wiring circuit short-circuited, or open.</p> <p>Light burned out.</p>	<p>Turn switch "on" fully.</p> <p>Clean and tighten; replace or repair wire or terminal.</p> <p>Correct short circuit or replace defective parts.</p> <p>Replace light.</p>
Lights dim.	<p>Loose or dirty connection.</p> <p>Wiring short-circuited.</p> <p>Defective switch.</p>	<p>Clean and tighten connections.</p> <p>Correct short circuit or replace defective parts.</p> <p>Replace switch.</p>



INDUSTRIAL TRUCK DIVISION



TROUBLE SHOOTING GUIDE

BATTERY, LIGHTS AND HORN (Continued)

TRUCK LIGHTS AND HORN

TROUBLE	PROBABLE CAUSE	REMEDY
Horn troubles.	Loose or dirty wiring connections.	Clean and tighten connections.
Horn sounds continuously.	Short-circuit in wiring between horn and horn button.	Replace wire.
Improper tone.	Loose or dirty wiring connections. Cover or bracket screws loose. Points adjusted improperly.	Clean and tighten connections. Tighten. Adjust points.
Horn will not operate.	Horn Fuse Blown. Open Circuit. Faulty Horn Relay.	Replace Fuse. Trace, repair or replace as required. Replace relay.



INDUSTRIAL TRUCK DIVISION



TROUBLE SHOOTING GUIDE

TRANSMISSION

TROUBLE	PROBABLE CAUSE	REMEDY
Excessive noise.	Incorrect driving practice. Insufficient lubricant. Gears or bearings broken or worn; shift fork bent, gears worn on splines. Overheated transmission.	Correct practice. Add lubricant. Replace transmission. Inspect lubricant grade and supply.
Hard shifting.	Clutch fails to release. Clutch driven plate binds, or pressure plate is defective. Gearshift binding in housing. Shift rods binding in case. Transmission loose on bell housing. Clutch shaft pilot bearing binding, or shift housing damaged.	Adjust clutch pedal free travel. Report to designated individual in authority. Lubricate and free-up. Report to designated individual in authority. Tighten transmission mounting bolts. Report to designated individual in authority.
Slips out of gear.	Weak or broken rail spring. Transmission gears or bearing worn. Shifting fork bent, causing partial gear engagement. Transmission loose on bell housing. Damaged bell housing. Damaged mainshaft pilot bearing.	Report to designated individual in authority. Replace transmission. Report to designated individual in authority. Tighten transmission mounting bolts. Report to designated individual in authority. Report to designated individual in authority.
Loss of lubricant.	Worn or damaged seals or gaskets.	Report to designated individual in authority.



INDUSTRIAL TRUCK DIVISION



TROUBLE SHOOTING GUIDE

DRIVE AXLE

TROUBLE	PROBABLE CAUSE	REMEDY
Continuous Axle Noise.	Badly worn parts. Unevenly worn tires. Improperly adjusted wheel bearing. Lack of lubricant.	Replace worn parts with new. Replace tires. Adjust correctly. Add sufficient lubricant of correct grade.
Axle Noise on Drive or on Coast Only.	Differential pinion gear and ring gear out of adjustment or worn excessively.	Adjust, repair or replace entire unit if conditions warrants.
Excessive Backlash in Axle Driving.	Loose axle shaft drive flange cap screws. Flange loose on axle shaft. Worn splines on axle shaft at differential end. Differential drive pinion gear and ring gear out of adjustment or worn excessively.	Tighten cap screws. Reweld flange to shaft. Replace drive flange and shaft assembly. Adjust or replace as condition warrants.
Complete Failure to Function.	Broken axle shaft. Broken teeth on ring gear or pinion gear.	Replace axle shaft. Replace ring gear and pinion and other parts of differential necessary. Adjust ring gear and pinion gear correctly.



INDUSTRIAL TRUCK DIVISION



TROUBLE SHOOTING GUIDE

STEERING AXLE

TROUBLE	PROBABLE CAUSE	REMEDY
Trouble.	Damaged axle. Lubrication leaks. Incorrect caster or camber. Uneven tire wear.	Replace axle. Replace oil seals. (Refer to Lubrication Section). Report to designated individual in authority. Report to designated individual in authority. Inflate tires properly. Check wheel alignment.




INDUSTRIAL TRUCK DIVISION



TROUBLE SHOOTING GUIDE

STEERING

TROUBLE	PROBABLE CAUSE	REMEDY
Steering difficult.	Lack of lubrication Tight steering system connections. Tight steering gear; misaligned wheels. Bent steering connecting linkage or arm. Misaligned steering gear mounting.	Lubricate. Lubricate and adjust linkage. Report to designated individual in authority. Straighten or replace linkage. Adjust mounting.
Wander or weaving.	Improper toe in camber or caster (axle twisted). Steering system connections or king pin bearings not properly lubricated. Loose wheel bearings. Steering gear worn or maladjusted. Steering gear mountings loose.	Report to designated individual in authority. Lubricate. Adjust wheel bearings. Report to designated individual in authority. Tighten mounting bolts.
Low speed shimmy or wobble.	Loose steering connections. Steering gear worn, or adjustment too loose. Loose wheel bearings.	Adjust and tighten linkage. Report to designated individual in authority. Adjust wheel bearings.
Vehicle pulls to one side.	Odd size, or new and old tires on opposite wheels. Tight wheel bearings. Bent steering arm or connection.	Match tires. Adjust. Lubricate wheel bearings. Straighten or replace bent linkage.



BRAKES

TROUBLE	PROBABLE CAUSE	REMEDY
Brakes drag.	Improper pedal adjustment. Brake pedal return spring broken or weak. Brakes improperly adjusted. Brake shoe anchor pin tight in shoe. Brake shoe return spring broken or weak. Loose or damaged wheel bearings. Insufficient brake shoe clearance, or improper brake anchor pin adjustment. Brake backing plate loose. Grease on linings. Dirt imbedded in lining. Drums scored or rough.	Adjust brake pedal free travel. Replace spring. Adjust brakes. Free-up pin and lubricate lightly. Replace spring. Adjust or replace wheel bearings. Adjust brakes. Tighten plate. Correct grease leakage; clean or install new shoes and lining assemblies. Clean lining with wire brush. Replace drum and brake shoe and lining assemblies.
Severe brake action on light pedal pressure.	Brake shoes improperly adjusted. Grease on linings. Loose brake shoe anchor.	Adjust brakes. Correct grease leakage; clean or install new shoes and lining assemblies. Adjust and tighten.
Brake locked.	Brake pedal lacks free travel. Brakes frozen to drums (cold weather).	Adjust pedal free travel. Break loose by driving vehicle.
Brake noisy or chatters.	Brake lining worn. Grease on linings. Dirt embedded in linings. Improper or loose linings. Brake shoe or drum distorted.	Replace shoe and lining assemblies. Correct leakage; clean or replace shoe and lining assemblies. Clean lining with wire brush. Replace shoe and lining assemblies. Straighten or replace.



INDUSTRIAL TRUCK DIVISION



TROUBLE SHOOTING GUIDE

BRAKES (Continued)

TROUBLE	PROBABLE CAUSE	REMEDY
Excessive pedal travel.	Lining worn. Brake improperly adjusted. Scored brake drums.	Adjust or replace shoe and lining assemblies. Adjust brake. Repair or replace drums.
Excessive pedal pressure.	Grease on linings; worn or glazed lining. Warped brake shoes, or defective brake linings. Shoes improperly adjusted. Brake drum scored or distorted. Shoes improperly adjusted. Insufficient fluid in master cylinder.	Correct grease leakage; clean up and replace shoe and lining assemblies. Replace shoe and lining assemblies. Adjust brakes. Repair or replace drums. Adjust brakes. Fill master cylinder to within 1/4 inch of the top.
Wheel troubles.	Wheel wobbles; bent. Wheel loose on hub. Wheel out of balance. Wheel bearings run hot.	Inspect mounting on hub, spindles, and drive axle; replace defective wheel or mounting. Tighten. Balance wheel. Adjust, lubricate wheel bearings.



INDUSTRIAL TRUCK DIVISION



TROUBLE SHOOTING GUIDE

HYDRAULIC SYSTEM

TROUBLE	PROBABLE CAUSE	REMEDY
Pump not delivering oil.	<p>Wrong direction *of rotation.</p> <p>Tank oil level low.</p> <p>Oil intake pipe or suction filter plugged.</p> <p>Air leak in suction line.</p> <p>Oil viscosity too heavy to pick up prime.</p> <p>Broken pump shaft or gear.</p>	<p>Must be reversed immediately to prevent seizure and breakage of parts due to lack of oil.</p> <p>Add recommended oil.</p> <p>Replace filter cartridge, clean strainer if so equipped.</p> <p>Will prevent priming, or cause noise and irregular action of control circuit.</p> <p>Thinner oil should be used, per recommendations for given perature and service.</p> <p>Report to designated individual in authority.</p>
Pump not developing pressure.	<p>Pump not delivering oil for any of the above reasons.</p> <p>Relief valve setting not high enough.</p> <p>Relief valve sticking open.</p> <p>Leak in hydraulic control system (cylinders or valves).</p> <p>Partially clogged intake line, intake filter or restricted intake pipe.</p>	<p>Check oil circulation by watching oil in tank.</p> <p>Refer to relief valve instructions.</p> <p>Dirt under pressure adjustment valve. Refer relief valve instructions.</p> <p>Find leak and correct.</p> <p>Pump must receive intake oil freely or cavitation will take place.</p>
Pump making noise.	<p>Small air leak at pump intake piping joints.</p> <p>Air leak at pump shaft packing.</p> <p>Tank air vent plugged.</p> <p>Too high oil viscosity.</p> <p>Shaft packing worn.</p> <p>Oil filter dirty.</p>	<p>Test by pouring oil on joints while listening for change in operation. Tighten as required.</p> <p>Repair or replace.</p> <p>Must be open thru breather opening or air filter.</p> <p>Use recommended oils.</p> <p>Replace shaft packing per preceding instructions.</p> <p>Replace filter element.</p>
Forks do not lift to maximum height.	<p>Hydraulic Oil level low.</p>	<p>Fill sump tank.</p>



INDUSTRIAL TRUCK DIVISION



TROUBLE SHOOTING GUIDE

HYDRAULIC SYSTEM CONTINUED

TROUBLE	PROBABLE CAUSE	REMEDY
Lift or tilt action fails.	Loss of oil pressure.	Report to designated individual in authority.
Oil leak at top of lift cylinder assembly.	Worn or damaged lift piston seal. Scored cylinder wall. Plugged vent line.	Replace seal. Replace cylinder. Clean out vent line. Replace if collapsed.
Oil leak around piston rod at tilt cylinder.	Worn seal. Scored piston rod.	Replace seal. Replace rod and eliminate cause of scoring which may be caused by misalignment, worn bearing or foreign matter.
With load centered on lift forks load is lifted unevenly.	Lift chains out of adjustment.	Adjust chains.