


○ **CLARK[®]**



Operator's Manual

INTERNAL COMBUSTION LIFT TRUCKS

Part No. 2806350
Book No. OM-598

**Do not remove this manual
from the truck.**

Record the following information pertaining to your truck.

Model No. _____

Serial No. _____

Customer Truck Identification No. _____

Truck Weight, Empty _____

Truck Rated Capacity _____

Truck Gross Weight _____

Truck Gross Weight, Loaded w/Rated Load _____

Special Equipment or Attachments _____

IMPORTANT

Do not expose this manual to hot water or steam.

The following warning is provided pursuant to
California Health & Safety Code Sections 25249.5 et. seq.



WARNING

California Proposition 65

This product contains and emits
chemicals known to the State of
California to cause cancer, birth defects
and other reproduction harm.

CALIFORNIA

Proposition 65 Warning

Diesel engine exhaust and some
of its constituents are known to
the State of California to cause
cancer, birth defects, or other
reproductive harm.



WARNING

This engine exhaust from this product
contains chemicals known to the State
of California to cause cancer, birth
defects and other reproductive harm.

Operator's Manual

You must be trained and authorized to operate a lift truck.

YOU can prevent accidents

First: Learn safe operating rules and your company rules.


Next: Read your Operator's Manual. If you do not understand it, ask your supervisor for help.

Learn about the unit you operate.

KNOW YOUR TRUCK

Then: Practice operating your truck safely.

And: Keep your truck in safe operating condition with correct and timely maintenance.



Breaking these rules will cause serious or fatal injury to yourself and others.



A Message to CLARK Lift Truck Operators

Lift trucks are specialized machines with unique operating characteristics, designed to perform a specific job. Their function and operation is not like a car or ordinary truck. They require specific instructions and rules for safe operation and maintenance.

Safe operation of lift trucks is of primary importance to CLARK. Our experience with lift truck accidents has shown that when accidents happen and people are killed or injured, the causes are:

- **Operator not properly trained**
- **Operator not experienced with lift truck operation**
- **Basic safety rules not followed**
- **Lift truck not maintained in safe operating condition**

For these reasons, CLARK wants you to know about the safe operation and correct maintenance of your lift truck.

This manual is designed to help you operate your lift truck safely. This manual shows and tells you about safety inspections and the important general safety rules and hazards of lift truck operation. It describes the special components and features of the truck and explains their functions. The correct operating procedures are shown and explained. Illustrations and important safety messages are included for clear understanding. A section on maintenance and lubrication is included for the lift truck mechanic.



The operator's manual is not a training manual. It is a guide to help trained and authorized operators safely operate their lift truck by emphasizing and illustrating the correct procedures. However, it cannot cover every possible situation that may result in an accident. You must watch for hazards in your work areas and avoid or correct them. It is important that you know and understand the information in this manual and that you know and follow your company safety rules! Be sure that your equipment is maintained in a safe condition. Do not operate a damaged or malfunctioning truck. Practice safe operation every time you use your lift truck. Let's join together to set high standards in safety.

Remember, before you start operating this lift truck, be sure you understand all driving procedures. It is your responsibility, and it is important to you and your family, to operate your lift truck safely and efficiently. Be aware that the Federal Occupational Safety and Health Act (OSHA) and state laws require that operators be completely trained in the safe operation of lift trucks; it is also an OSHA requirement that a machine inspection be performed before every shift. If you think you need training in operating or inspecting your lift truck, ask your supervisor.

CLARK lift trucks are built to take hard work, but not abuse. They are built to be dependable, but they are only as safe and efficient as the operator and the persons responsible for maintaining them. Do not make any repairs to this truck unless you have been trained in safe lift truck repair procedures and are authorized by your employer.



Contents of this Manual

A Message to CLARK Lift Truck Operators.....	ii
Introduction	vi
How to Use this Manual	viii
Safety Signs and Safety Messages	x
Section 1. General Safety Rules	1-1
Section 2. Operating Hazards	2-1
Section 3. Operator Compartment and Controls	3-1
Section 4. Operating Procedures	4-1
Section 5. Operator Maintenance and Care	5-1
Section 6. Emergency Starting and Towing	6-1
Section 7. Planned Maintenance and Lubrication	7-1
Section 8. Specifications	8-1
Index	Index-1



Introduction

CLARK welcomes you to the growing group of professionals who own, operate, and maintain CLARK lift trucks. We take pride in the long tradition of quality products and superior value the CLARK name represents. This manual familiarizes you with safety, operating, and maintenance information about your new lift truck. It has been specially prepared to help you use and maintain your CLARK lift truck in a safe and correct manner.

Your CLARK lift truck has been designed and built to be as safe and efficient as today's technology can make it. As manufactured, it meets all the applicable mandatory requirements of ASME B56.1 Safety Standard for Powered Industrial Trucks. Each truck is also furnished with equipment to help you operate safely; for example, load back rest, parking brake and horn are standard equipment.

Safe, productive operation of a lift truck requires both skill and knowledge on the part of the operator. The operator must know, understand, and practice the safety rules and safe driving and load handling techniques described in this manual. To develop the skill required, the operator must become familiar with the construction and features of the lift truck and how they function. The operator must understand its capabilities and limitations, and see that it is kept in a safe condition.

Routine Servicing and Maintenance

Regular maintenance and care of your lift truck is not only important for economy and utilization reasons; it is essential for your safety. A faulty lift truck is a potential source of danger to the operator, and to other personnel working near it. As with all quality equipment, keep your lift truck in good operating condition by following the recommended schedule of maintenance.



Operator Daily Inspection — Safety and Operating Checks

A lift truck should always be examined by the operator, before driving, to be sure it is safe to operate. The importance of this procedure is emphasized in this manual with a brief illustrated review and later with more detailed instructions. CLARK dealers can supply copies of a helpful “Drivers Daily Checklist.”

Planned Maintenance

In addition to the daily operator inspection, CLARK recommends that a planned maintenance and safety inspection program (PM) be performed by a trained and authorized mechanic on a regular basis. The PM will provide an opportunity to make a thorough inspection of the safety and operating condition of your lift truck. Necessary adjustments and repairs can be done during the PM, which will increase the life of components and reduce unscheduled downtime and increase safety. The PM can be scheduled to meet your particular application and lift truck usage.

The procedures for a periodic planned maintenance program that covers inspections, operational checks, cleaning, lubrication, and minor adjustments are outlined in this manual. Your CLARK dealer is prepared to help you with a Planned Maintenance Program by trained service personnel who know your lift truck and can keep it operating safely and efficiently.

How to Use this Manual

This manual is a digest of essential information about the safe operation, the features and functions and explains how to maintain your lift truck. This manual is organized into eight major parts:

Section 1, General Safety Rules, reviews and illustrates accepted practices for safe operation of a lift truck.

Section 2, Operating Hazards, warns of conditions that could cause damage to the truck or injury to the operator or other personnel.

Section 3, Operator Compartment and Controls, describes the operating components, systems, controls, and other features of your truck and tells how they function.

Section 4, Operating procedures, discusses specific instructions on the safe, efficient operation of your lift truck.

Section 5, Operator Maintenance and Care, presents details on how to perform the operator's daily safety inspection and refuel the lift truck.

Section 6, Emergency Starting and Towing, gives instructions for towing your truck in an emergency and for using battery jumper cables to start your truck in an emergency.

Section 7, Planned Maintenance and Lubrication, describes the PM program.

Section 8, Specifications, provides reference information and data on features, components, and maintenance items.

Also, the **Index** helps you locate information about various topics.

NOTICE: The descriptions and specifications included in this manual were in effect at the time of printing. CLARK Material Handling Company reserves the right to make improvements and changes in specifications or design, without notice and without incurring obligation. Please check with your authorized CLARK dealer for information on possible updates or revisions.

The examples, illustrations, and explanations in this manual should help you improve your skill and knowledge as a professional lift truck operator and take full advantage of the capabilities and safety features of your new lift truck.

The first Section of the manual is devoted to a review, with illustrations and brief messages, of general safety rules and the major operating hazards you can encounter while operating a lift truck. Next, you will find descriptions of the components of your specific lift truck model and how the instruments, gauges, and controls operate. Then, you will find a discussion of safe and efficient operating procedures, followed by instructions on how to tow a disabled lift truck. The later sections of the manual are devoted to maintenance and truck specifications.

Take time to carefully read the “Operator Compartment and Controls” section. By acquiring a good basic understanding of your truck’s features, and how they function, you are better prepared to operate it both efficiently and safely.

In “Planned Maintenance,” you will find essential information for correct servicing and periodic maintenance of your truck, including charts with recommended maintenance intervals and component capacities. Carefully follow these instructions and procedures.

Each major Section has its own table of contents, so that you can find the various topics more easily. If you cannot find a topic in the table of contents, check the index at the back of the manual.

We urge you to first carefully read the manual from cover to cover. Take time to read and understand the information on general safety rules and operating hazards. Acquaint yourself with the various procedures in this manual. Understand how all gauges, indicator lights, and controls function. Please contact your authorized CLARK dealer for the answers to any questions you may have about your lift truck’s features, operation, or manuals.

Operate your lift truck safely; careful driving is your responsibility. Drive defensively and think about the safety of people who are working nearby. Know your truck’s capabilities and limitations. Follow all instructions in this manual, including all IMPORTANT, CAUTION, WARNING, and DANGER messages to avoid damage to your lift truck or the possibility of any harm to yourself or others.

This manual is intended to be a permanently attached part of your lift truck. Keep it on the truck as a ready reference for anyone who may drive or service it. If the truck you operate is not equipped with a manual, ask your supervisor to obtain one and have it attached to the truck. And, remember, your CLARK dealer is pleased to answer any questions about the operation and maintenance of your lift truck and will provide you with additional information should you require it.



Safety Signs and Safety Messages

Improper operation can cause accidents. Don't take chances with incorrect or damaged equipment. **Read** and **understand** the procedures for safe driving and maintenance outlined in this manual. Don't hesitate to ask for help. **Stay alert!** Follow safety rules, regulations, and procedures. Avoid accidents by recognizing dangerous procedures or situations before they occur. **Drive and work safely** and follow the safety signs and their messages on the truck and in this manual.

Safety signs and messages are placed in this manual and on the truck to provide instructions and identify specific areas where potential hazards exist and special precautions should be taken. Know and understand the meaning of these instructions, signs, and messages. Damage to the truck, death, or serious injury to you or other persons may result if these messages are not followed. If warning decals are damaged, they must be replaced. Contact your CLARK dealer for replacements.

NOTICE

This message is used when special information, instructions or identification are required relating to procedures, equipment, tools, pressures, capacities and other special data.

IMPORTANT

This message is used when special precautions should be taken to ensure a correct action or to avoid damage to or malfunction of the truck or a component.



CAUTION

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.



WARNING

Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.



DANGER

Indicates an imminently hazardous situation which, if not avoided, will result in death or injury



General Safety Rules

Contents

Contents	1-1
Daily Inspection	1-2
Do's and Don'ts	1-3
Seat Belts	1-4
No Riders	1-5
Pedestrians	1-6
Operator Protection	1-7
Fork Safety	1-8
Pinch Points	1-9
Travel	1-10
Grades, Ramps, Slopes, and Inclines	1-11
Surface and Capacity	1-12
Tip-Over	1-13
What to do in Case of a Tip-over	1-14
Parking	1-15
General Tire Maintenance, Inspection, and Repair	1-16



Daily Inspection

CLARK Material Handling Company
OPERATORS' DAILY CHECKLIST
 Check Each Item Before Start Of Each Shift

Date: _____

Check one: Gas/LPG/Diesel Truck Electric Sit-down Electric Stand-up Electric Pallet

Truck Serial Number: _____ Operator: _____ Supervisor's OK: _____

Hour meter reading: _____

Check each of the following items before the start of each shift. Let your supervisor and/or maintenance department know of any problem. DO NOT OPERATE A FAULTY TRUCK. Your safety is at risk. After checking, mark each item accordingly. Explain below as necessary.

Check boxes as follows: OK NG, needs attention, or repair. Circle problem and explain below

OK	NG	VISUAL CHECKS	OK	NG	OPERATIONAL CHECKS
<input type="checkbox"/>	<input type="checkbox"/>	Tires/Wheels: wear, damage, nuts tight	<input type="checkbox"/>	<input type="checkbox"/>	Engine: runs rough, noisy, leaks
<input type="checkbox"/>	<input type="checkbox"/>	Head/Tail/Working Lights: damage, mounting, operation	<input type="checkbox"/>	<input type="checkbox"/>	Steering: loose/binding, leaks, operation
<input type="checkbox"/>	<input type="checkbox"/>	Gauges/Instruments: damage, operation	<input type="checkbox"/>	<input type="checkbox"/>	Service Brake: linkage loose/binding, stops OK, grab
<input type="checkbox"/>	<input type="checkbox"/>	Operator Restraint: damage, mounting, operation, oily, dirty	<input type="checkbox"/>	<input type="checkbox"/>	Parking Brake: loose/binding, operational, adjustment
<input type="checkbox"/>	<input type="checkbox"/>	Warning Decals/Operators' Manual: missing, not readable	<input type="checkbox"/>	<input type="checkbox"/>	Seat Brake (if equipped): loose/binding, operational, adjustment
<input type="checkbox"/>	<input type="checkbox"/>	Data Plates: not readable, missing	<input type="checkbox"/>	<input type="checkbox"/>	Horn: operation
<input type="checkbox"/>	<input type="checkbox"/>	Overhead Guard: bent, cracked, loose, missing	<input type="checkbox"/>	<input type="checkbox"/>	Backup Alarm (if equipped): mounting, operation
<input type="checkbox"/>	<input type="checkbox"/>	Load Back Rest: bent, cracked, loose, missing	<input type="checkbox"/>	<input type="checkbox"/>	Warning Lights (if equipped): mounting, operation
<input type="checkbox"/>	<input type="checkbox"/>	Forks: bent, worn, stops OK	<input type="checkbox"/>	<input type="checkbox"/>	Lift/Lower: loose/binding, excessive drift, leaks
<input type="checkbox"/>	<input type="checkbox"/>	Engine Oil: level, dirty, leaks	<input type="checkbox"/>	<input type="checkbox"/>	Tilt: loose/binding, excessive drift, "chatters," leaks
<input type="checkbox"/>	<input type="checkbox"/>	Hydraulic Oil: level, dirty, leaks	<input type="checkbox"/>	<input type="checkbox"/>	Attachments: mounting, damaged, operation, leaks
<input type="checkbox"/>	<input type="checkbox"/>	Radiator: fluid level, dirty, leaks	<input type="checkbox"/>	<input type="checkbox"/>	Battery Test (electric trucks only): indicator in green while holding full forward tilt
<input type="checkbox"/>	<input type="checkbox"/>	Fuel level, leaks	<input type="checkbox"/>	<input type="checkbox"/>	Control Levers: loose/binding, freely return to neutral
<input type="checkbox"/>	<input type="checkbox"/>	Battery: connections loose, charge, electrolyte low	<input type="checkbox"/>	<input type="checkbox"/>	Directional Control: loose/binding, find neutral OK
<input type="checkbox"/>	<input type="checkbox"/>	Covers/Sheetmetal: damaged, missing			
<input type="checkbox"/>	<input type="checkbox"/>	brakes: linkage, reservoir fluid level, leaks, debris on floor			

Explanation of problems marked above:

59-770-2937 Jan 1996

At the beginning of each shift, inspect your truck and fill out a daily inspection sheet.

Check for damage and maintenance problems.

Have repairs made before you operate the truck.



CAUTION

DO NOT MAKE REPAIRS YOURSELF. Lift truck mechanics are trained professionals. They know how to make repairs safely. (See Section 5)

Do's and Don'ts




Don't mix drugs or alcohol with your job.

Do watch for pedestrians.



Don't block safety or emergency equipment.

Do wear safety equipment when required.




Don't smoke in "NO SMOKING" areas or when refueling.

Seat Belts



ALWAYS BUCKLE UP



Seat belts can reduce injuries.

No Riders



The operator is the only one who should be on a truck.



Never transport personnel on the forks of a lift truck.

Pedestrians




Watch where you are going. Look in the direction of travel. Pedestrians may use the same roadway you do. Sound your horn at all intersections or blind spots. Watch for people in your work area even if your truck has warning lights or alarms. People may not watch for you.



Make people stand back, even when you are parked.

Operator Protection



**Keep under the overhead guard.
Always keep your body within the confines of the truck.**

Fork Safety

Never allow anyone to walk under raised forks.




DANGER

There is special equipment to raise people for overhead work. **DO NOT USE LIFT TRUCKS.**



Pinch Points



WARNING

Keep hands, feet and legs out of the upright.



WARNING

Don't use the upright as a ladder.




CAUTION

Never try to repair the upright, carriage, chain, or attachment yourself! Always get a trained mechanic.

Travel

Travel with the load near the floor/ground with upright tilted back to cradle the load whenever possible.

Never lift or lower the load when the truck is in motion.



When handling bulky loads that restrict your vision operate your truck in reverse to improve visibility.

Be sure to pivot in the seat to give maximum visibility.



Unstable loads are a hazard to you and to your fellow workers.

Always make certain that the load is well stacked and evenly positioned across both forks.

Never attempt to lift a load with only one fork.




Right



Wrong

Grades, Ramps, Slopes, and Inclines




Unloaded
Forks Downgrade



WARNING


Never turn on a grade, either loaded or unloaded.



Loaded
Forks Upgrade



Surface and Capacity



Avoid these conditions. They can cause a truck to tip over or lose traction for braking or driving.




WARNING

Know the weight of your truck and load. Especially when using elevators. Know the capacity of the elevator you intend to use. Do not overload.

IMPORTANT


Seat belts can reduce injuries.
ALWAYS BUCKLE UP



Tip-Over


Lateral Tip-over

- Lateral tip-over can occur with a combination of speed and sharpness of turn. This combination will exceed the stability of the truck. This condition is even more likely with an unloaded truck.
- With the load or upright raised, lateral tip-over can occur while turning and/or braking when traveling in reverse or accelerating and turning while traveling forward.
- Lateral tip-over can occur loaded or unloaded by turning on an incline or ramp.



Longitudinal Tip-over

- Longitudinal tip-over can occur with a combination of overloading and load elevated also with capacity load and elevated. This combination will exceed the stability of the truck. This condition is even more likely with excessive forward tilt, braking in forward travel or accelerating rearward.
- Longitudinal tip-over can occur by driving with the load down slope on a steep grade.



Lateral and longitudinal tip-over can occur if the truck is driven over objects on the floor or ground, off the edge of improved surfaces, or into potholes in the road surface, or by running into overhead objects or collisions.

An off dock type of tip-over can occur if the truck is steered too close to the dock edge, driven off the edge of the dock or ramp, or if the highway truck or trailer rolls away from the dock or is driven away during loading.



WARNING

The conditions listed above can be further aggravated by overloading, excessive tilt, or off center loads.

IMPORTANT

Lift truck tip-over can cause serious injury or death if the operator is trapped between the truck and the ground.



What to do in Case of a Tip-over

If your truck starts to tip over,

⚠ WARNING
DO NOT JUMP!!!

IMPORTANT

Your chances for survival in a tip-over are better if you stay with the truck, in your seat.

Brace yourself as illustrated below!

1. Make sure your seat belt is fastened securely.
2. Stay in your seat.
3. Grip the wheel.
4. Brace your feet.



Parking


- Never park on a grade.
- Always come to a complete stop before leaving truck.




- Be sure travel control is in NEUTRAL.
- Lower forks fully to floor and tilt forward.



- Set parking brake.



- Turn key to OFF position.




General Tire Maintenance, Inspection, and Repair

1. Park the truck as described on page 1.15 and check for correct tire inflation air pressure. See specifications in this OM for correct tire pressure for your truck.



CAUTION

Check tire pressure from a position facing the tread of the tire, not the side. Use a long-handled gauge to keep your body away from the side.



- If tires are low, do not add air. Have the tire and wheel inspected by a person trained and authorized to do tire and wheel maintenance. The tire may require removal and repair.
- Incorrect (low) tire pressure can reduce the stability of a lift truck and cause it to tip over.

IMPORTANT

Check wheels and tires for damage every time you check tire pressure. Make repairs when needed. Dirt can get into cuts and cause damage to the tire cord and tread. Remove debris from all cuts.



CAUTION

Multiple wheel assemblies. Do not loosen or remove wheel assembly nuts before fully deflating tire. Have only a trained and authorized mechanic make repairs. See *Service Manual* for more detailed information.

Operating Hazards

Contents

Loose Loads	2-2
Long and Wide Loads / Rear Swing	2-3
Low Overhead Clearance	
Fast Turns and High Loads	2-4
Drop-Offs	2-5
Right-Angle Stacking	2-6
Chain Slack	2-7
Pallets and Skids	2-8

This Section shows some of the hazards that may cause you, or someone around you, to be killed or badly hurt. As the operator, you must look for other hazards. Get your supervisor to help you identify and avoid those hazards.




Loose Loads




WARNING

Loose or unbalanced loads are dangerous. Observe these precautions.


Never carry loose or uneven material.



Center wide loads.



Stack and band loose material.




Long and Wide Loads / Rear Swing

 **WARNING**

With long or wide loads, you need more room. So slow down and watch your clearance.


A long load reduces the capacity of the truck. Know and understand your truck load rating.

When extra-long material makes it necessary to travel with the load elevated, do so with extreme care and be alert to load end-swing when turning.



 **WARNING**

When turning, be sure the rear end of the truck does not swing into racks, posts, etc. Watch for pedestrians beside the truck.



Low Overhead Clearance Fast Turns and High Loads




WARNING

Know the height of your truck, with and without a load.

Check your clearances.


Keep the load low and tilted back.



WARNING

Watch overhead clearance:

Moving into overhead structures can tip a truck over, or spill a load.



WARNING

Slow down before turning. The truck can tip over.

Turn too sharp with a raised load and your truck can tip even at slow speeds.

Travel with a load raised only when removing or depositing a load.



Drop-Offs



WARNING


To avoid these hazards, you must:

- Talk to the truck driver yourself; make sure the driver does not move the trailer until you are done!
- Apply trailer brakes.
- Use wheel chocks.
- Use trailer-to-dock locking system if available.

The impact of moving in and out of a trailer may cause the trailer to creep or move.



Right-Angle Stacking




SLOWLY



WARNING

When right-angle stacking or moving with a raised load to clear low objects, avoid sharp turns and move slowly.


Chain Slack



WARNING

Slack chains mean rail or carriage hang-up. Raise the forks before you move, or broken chains can result.

Pallets and Skids



WARNING

Do not move or store materials on damaged pallets or skids. Items can fall through them causing severe injury or death!

Be sure the pallet or skid you are using is in good condition and does not have defective or missing components and fasteners.


Operator Compartment and Controls

Contents

Truck Description	3-2
CMC/CMP Operator Compartment	3-3
CMC/CMP Instrument Panel	3-4
CMC/CMP Instrument Panel Symbols	3-5
CMP 50,60,70,75S EGS	3-6
CGC/CGP Operators Compartment	3-7
CGC/CGP	3-8
CGC/CGP Dash Pod Symbols	3-9
CGC/CGP Hydrostatic Operators Compartment ..	3-10
CGC/CGP Hydrostatic Controls	3-12
Operator Controls	3-14




Truck Description



1. Steering Handwheel
2. Overhead Guard
3. Seat and Seat Belt
4. Counterweight
5. Steer Axle, Wheels/Tires
6. Upright and Carriage
7. Load Backrest
8. Forks
9. Drive Axle, Wheels/Tires

The truck shown above is a typical representation of a Clark internal combustion lift truck. Your model may vary slightly.

CMC/CMP Operator Compartment




1. Steering Handwheel
2. Forward/Reverse Lever
3. Brake Fluid Reservoir
4. Parking Brake
5. Inching Pedal
6. Service Brake Pedal
7. Seat Adjustment Lever
8. Horn Button
9. Hazard Light Switch
10. Head Light Switch
11. Turn Signal Lever
12. Lift Control Lever (CMC15-20S, CMP15-30)

13. Tilt Control Lever (CMC15-20S, CMP15-30)
14. Side Shifter Control Lever (CMC15-20S, CMP15-30)
15. Accelerator Pedal
16. Key Switch
17. Steer Column Tilt Lever

Deck Mntd Levers (CMP 40-75S)

18. Side Shifter Lever
19. Tilt Lever
20. Lift Lever

CMC/CMP Instrument Panel



CMC/CMP Instrument Panel Symbols



Turn Signal Lamps: Blink when the turn signal indicating lever turned to either direction.



LPG Warning Lamp (Dual fuel option for CMP15-30G): This symbol displays when the LPG fuel bottle reaches a minimum allowable limit.



Ammeter: This symbol displays when the alternator is not charging the battery.



Engine Oil Pressure: This symbol displays when the engine oil pressure reaches the minimum allowable limit. The indicator will also display along with the automatic engine shutdown in case of low oil pressure. If this symbol is displayed, **STOP** the truck immediately and check transmission.



Fuel Level: This symbol displays when the LPG fuel bottle reaches a minimum allowable limit.



Glow Plug Preheat: When the ignition switch is turned to the "ON" position, a timer is set. This symbol displays until the timer cycle is completed. The engine may then be started.



Parking Brake: This symbol displays when the parking brake is engaged.



Transmission Oil Temperature: During operation, glowing of this symbol indicates when the transmission oil temperature is too high. If this symbol is displayed, **STOP** the truck immediately and check transmission.




Panel Check Switch: Turns on all the pilot and warning symbols on the instrument panel. This switch is designed to the operator know that all symbols and switches are working properly.

AUTO MANUAL



Auto/Manual Switch: In normal condition set this switch to "AUTO", and in emergency condition (*AUTO failure*), SET to "MANUAL" to operate.



Emergency FWD/REV Switch (for manual): In emergency condition (*AUTO failure*), while the Auto/Manual switch is set "MANUAL", you can control the forward/reverse operation by use of this switch.


CMP 50,60,70,75S EGS

Electronic Gear Shift (E.G.S.)

Push the direction control lever forward, center it, or pull it back for FORWARD, NEUTRAL, or REVERSE, respectively. Traction is disabled in NEUTRAL.


If you are traveling forward, push the direction control lever forward and twist the hand grip up and forward to shift from neutral into first gear. Then twist up and forward again to shift from first gear to second gear and once more to shift to third gear.

To down shift, twist hand grip down and backward. The same procedure applies while traveling in reverse, except you pull the direction control lever backwards (toward the operator).



Display Arrangement


- 1) Lamps 1-3: Indicate the selected lever position/direction (color)
Indicate the selected transmission gear/direction (color)



- 2) Lamp N: On if the transmission is place in neutral
- 3) Lamp T: Used in self diagnostic modes and or fault signalling.
- 4) Lamp W/7: Blinks red when downshift is inhibited or during a direction change.
- 5) Lamp S/8: Used to indicate "standstill" or a possible speed sensor problem.


After the initial start up both the N and T lamp are ON. However, if the EGS controller is malfunctioning both lamps are ON or blink simulta-neously.

CGC/CGP Operators Compartment



Steering Column Pylon


The steering wheel can be tilted forwards and backwards in small discrete movements. Push and hold pylon lock, move the wheel to the desired position and release lock.



Dash Pod Display

Familiarize yourself with the dash display and its warning indicators.


Make viewing the indicators part of your normal operating routine. If any of these indicator lights show an irregularity or when they are not working properly, have them checked immediately.



LPG Truck Dash Display



Diesel Truck Dash Display



Gasoline Truck Dash Display

CGC/CGP Dash Pod Symbols



Ammeter: This symbol displays when the alternator is not charging the battery.



Engine Oil Pressure: This symbol displays when the engine oil pressure reaches the minimum allowable limit. The indicator will also display along with the automatic engine shutdown in case of low oil pressure. An alarm will also sound.



Fuel Filter: This symbol displays when the restriction level reaches the maximum allowable limit.



Fuel Level: This symbol displays when the LPG fuel bottle reaches a minimum allowable limit.



Glow Plug Preheat: When the ignition switch is turned to the "ON" position, a timer is set. This symbol displays until the timer cycle is completed. The engine may then be started.



Engine Diagnostic: This symbol displays at the start up of the truck. A mechanic should be called if it displays at any other time. A mechanical problem could be present.



Seat Belt: At start up this symbol displays along with an audio alarm for 10 seconds. This display reminds you to fasten your seat belt.

IMPORTANT

You should always have your seat belt securely fastened when operating your lift truck.



Air Filter: This symbol displays when the restriction level in the air cleaner reaches the maximum allowable limit.



Transmission Oil Temperature: This symbol displays when the transmission oil temperature reaches the maximum allowable limit. The indicator will also display together with the automatic engine shutdown in case of high oil temperature. An alarm will also sound.




Hydraulic Oil Filter: This symbol displays when the hydraulic filter restriction level reaches the maximum allowable limit.




Parking Brake: This symbol displays when the parking brake is engaged.


CGC/CGP Hydrostatic Operators Compartment



Standard Operating Controls



Two Pedal Controls



Unitrol Pedal Controls

- | | |
|----------------------------|---|
| 1. Steering Handwheel | 11. Direction Control (standard) |
| 2. Key Switch | 12. Parking Brake Release |
| 3. Lift Control Lever | 13. Hood Release |
| 4. Tilt Control Lever | 14. Parking Brake Pedal |
| 5. Auxiliary Control Lever | 15. Seat Adjustment Lever |
| 6. Brake Pedal | 16. Direction and Speed Control Pedal (REV) |
| 7. Accelerator Pedal | 17. Direction and Speed Control Pedal (FWD) |
| 8. Pylon Lock | 18. Unitrol Pedal |
| 9. Horn Button | |
| 10. Dash Display | |

IMPORTANT

Familiarize yourself with the controls and follow safe operating procedures.

Two Pedal Control


In the case of two pedal operation there is no forward/reverse lever. The direction of travel and speed of truck is determined by the forward or reverse pedals.

- **Forward:** To move forwards depress the right pedal. The farther you push down on the pedal the faster the truck will move.

- **Reverse:** To move in reverse depress the left pedal.

The farther you push down on the pedal the faster the truck will move.

- **Neutral:** Release both pedals and transmission is in "neutral".




Unitrol Pedal

With the Clark Unitrol, the directional control lever is no longer located on the steering pylon. The direction of travel and speed of truck is determined by the Unitrol pedal.

- **Forward:** To select and move the truck in the forward direction you must push down on the (FWD arrow) left side of the Unitrol pedal. The farther the pedal is depressed the faster the lift truck will go in forward.

- **Reverse:** To select and move the truck in the forward direction you must push down on the (REV arrow) right side of the Unitrol pedal. The farther the pedal is depressed the faster the lift truck will go in reverse.

- **Neutral:** The unitrol pedal activates only FWD and REV. Neutral is activated only when the parking brake is set.



IMPORTANT

For safety reasons, your CLARK forklift truck is fitted with a neutral start switch. The purpose of this is to prevent the engine from being started while the transmission is in gear. Thus the engine may only start when the direction control lever is in the neutral position.



CAUTION

If the truck will start with the direction control in either forward or reverse, there is a problem with the neutral start switch and it must be repaired.

CGC/CGP Hydrostatic Controls

Brake Pedal/Pedals

The hydrostatic lift truck can be configured three ways:

- Standard, automotive or common lift truck = 2 brake pedals
- Two Pedal, forward and reverse pedals = 1 brake pedal
- Unitrol, one pedal controls FWD and REV = 2 brake pedals

CAUTION

On ramps or inclines the brake pedal should be used. The lift truck could move involuntarily backwards or forwards.

Releasing the travel pedals will cause the truck to decelerate and stop.


The preferred method of braking is to lift your foot from the direction or ground speed pedal, the truck will then come to a stop.

IMPORTANT


The Clark Hydrostatic Lift Truck uses the pump for dynamic braking to slow down and stop the trucks direction of travel. The brake pedal can still be used in extreme conditions.

CAUTION


Stop the lift truck as gradually as practical. Hard braking and wheel sliding are dangerous, increase wear can cause you to lose a load and damage the lift truck. Hard braking can also cause tip-over.



Standard Control



Two Pedal Control



Unitrol Pedal Control

Ground Speed Control (acceleration)


With the parking brake released and the direction control in FWD or REV, put your foot on the pedal (depending on configuration), push down smoothly until the truck is moving at the desired speed.

Stopping the Truck

IMPORTANT

The preferred method of braking is to lift your foot from the direction or ground speed pedal, the truck will then come to a stop.

The conventional brake pedal can be used to stop the truck if necessary. The brake pedal should be used to hold the truck on a ramp or incline.



Preferred Method of Inching


Hydraulic lever functions (lift, tilt and aux.), when actuated, will automatically raise the engine RPM. This feature helps provide increased function or hydraulic speed without the need for "conventional inching". The raised engine speed due to the hydraulics being actuated will not effect the trucks ground speed.

IMPORTANT

Ground speed is controlled by the accelerator pedal only.

Optional Hydraulic Control Levers (Deck Mounted)

The deck mounted levers are mounted on the seat deck to the right of the operator. The levers of the control valve activate the lift, tilt functions as and any other hydraulic devices which are installed on the truck.



Operator Controls


Key/Start Switch

The Key/Start Switch:

- Turns the truck electrical system on and off.
- Connects and tests the warning indicator lights.
- Connects the starter motor circuit when engine is to be started.

The Key/Start Switch has three positions.

When the key is in the vertical "OFF" position, all truck electrical circuits are off, and the key can be removed. From the "OFF" position, the key can be turned clockwise to the "START" position, where the starter motor is engaged and part of the truck electrical system is energized.



When the key is released from the "START" position, it automatically returns to the "RUN" position, where the starter is disengaged and the entire truck electrical system is on.

The key switch has a mechanical "anti-restart" feature, which prevents the engine starter from being engaged and damaged if the operator attempts to start the engine when it is already running. The key switch cannot be turned to the "START" position from the "RUN" position without returning the key to the "OFF" position. If the engine stops running, the key switch must be turned to the "OFF" position before it can be restarted.

Cold Start Preheating (Diesel Only)

With the switch in the "ON" position the warning indicator will light up then the glow plugs are pre-heating automatically. The engine can then be started. To repeat the preheating process turn the key to the "OFF" and then into the "ON" position.

Engine Stop

Run the engine at idling speed briefly before shutting it off. Turn the key switch to the "OFF" position to shut the engine down.

Operator Controls

Cold Start Preheating CDP 20-35 (Diesel Only)



With the switch in the "ON" position the warning indicator will light up then the glow plugs are pre-heating automatically, after 6 seconds the indicator light will go out.

The Engine can be started.

For improved starting, pre-heating is continued for about 5 seconds after the indicator light has gone out. To repeat the preheating process turn the key to "OFF" and then into "ON" position.

Engine Stop

Run the engine at idling speed briefly before shutting it off. Turn the key switch to the "OFF" position to shut the engine down.

Cold Start Preheating CDP 40-55 /CDC 60-70 (Diesel Only)



Turn the starter key to position "ON". With lighting up of the warning lighting the preheating automatic (flame glow plug) will be activated. An electrically operated flame glow plug which ignites a specific amount of diesel fuel in the induction manifold in order to heat the induction air. The end of preheating will be indicated if the warning lights go out. Now turn the key immediately to start position.

Release the key immediately when the engine has started.

IMPORTANT


Repeated preheating without starting the engine isn't allowed. Only with starting idle it is possible to fill the fuel line with diesel, where the flame glow plug is installed. Therefore repeat preheating with starting the engine.

Engine Stop

Run the engine at idling speed briefly before shutting it off. Turn the key switch to the "OFF" position to shut the engine down.

Seat Adjustment

The fore and aft adjustment lever is located on the front under the seat. To unlock, pull the lever to the left and adjust the seat, release the lever. Be sure that the seat locking mechanism is engaged. The back declining adjustment lever is located on the right side of seat cushion. Pull the lever up and adjust the back, release the lever.



Be sure that the back locking mechanism is engaged.



CAUTION

Never adjust driver's seat while truck is moving, to avoid the possibility of loss of control and of personal injury.


Parking Brake

The parking brake pedal or lever (*depending on your model*) mechanically operates the parking brake.

Parking Brake Pedal


To apply the parking brake push the pedal down with your left foot until pedal stops. The parking brake release is located just above the brake pedal as shown. To release the parking brake pull toward you.

Parking Brake Release



Parking Brake Lever

Pull the lever toward the the operator to apply the parking brake. The lever should snaplock easily into applied position, when correctly adjusted. Push the lever forward (away from the operator) to release the parking brake.



CAUTION

Always apply parking brake before leaving truck.




WARNING

Never operate your lift truck with a defective parking brake.


Hour Meter

Starting the engine also starts the operating hour meter. Use the hour meter reading to perform prescribed maintenance.



Steering System

The steering handwheel operates a steering control valve that directs the oil flow to the steering cylinder connected to the steer axle. The steering control valve can also act as a pump to provide manual steering if the hydraulic pump stops.



Horn Button

The horn button is located in the center hub of the steering handwheel.

Brake Pedals

The left hand brake pedal (inching pedal) has two functions in order to improve handling and efficiency. While pressing the inching pedal the first part of its movement interrupts the power from the engine to the transmission. The level of disengagement is dependent on the movement of the pedal. The last part of the travel applies the brake system. In this way you are able to lift a load rapidly with full engine RPM while controlling slow driving speed with the inching pedal like a clutch. This is very useful in confined level working spaces.

On ramps or inclines the right hand brake pedal only should be used. When using the inching pedal on slopes the lift truck could move backwards or forwards unintentionally.

Direction Control Lever

This lever is typically on the left side of the steering column. When changing the direction of travel, make sure that your lift truck has come to a complete stop before moving the lever to the other position.

IMPORTANT

For safety reasons, every CLARK forklift truck is fitted with a neutral start switch. The purpose of this is to prevent the engine from being started while the transmission is in gear. Thus the engine may only start when the direction control lever is in the neutral position.



CAUTION


If the truck will start with the direction control lever in either forward or reverse, there is a problem with the neutral start

Hydraulic Control Levers

The levers of the control valve activate the lift and tilt cylinders as well as any other hydraulic devices which are installed on the truck.


IMPORTANT

The hydraulic levers shown are typical representations of a Clark internal combustion lift truck. Your model may vary slightly.



Lift Control Function


With the lift control lever, you are able to raise and lower the fork carriage on the upright. The lifting and lowering speeds are controlled through the main hydraulic valve by varying the lever position (from the center or neutral positions).



When the lift control lever is pushed forward, the fork carriage is lowered. When the lift control lever is pulled back the fork carriage is raised. You can also lower the fork carriage even if the key switch is OFF.

Tilt Control Lever

With the tilt control lever, you are able to control the tilting or vertical positioning of the upright and the angle of the forks. When the lever is pulled back, the upright and forks tilt backward. Push the lever forward to tilt the up-right and forks forwards.



Auxiliary Control Lever (Optional)


An auxiliary control lever is mounted to the right of the tilt control lever. If your lift truck is equipped with an optional attachment, this lever lets you control the flow and direction of the hydraulic oil to the attachment.

Auto Choke Control (*Gasoline Only*)

Depending on the atmosphere temperature, the engine “Choke” valve plate in the carburetor works automatically rotating. At this time, engine may be higher than low setting and it goes down to normal when engine reach normal operating temperature.

Steering Column Pylon

The steering wheel can be tilted forwards and backwards in small discrete movements. Push and hold pylon lock, move the wheel to the desired position and release lock.



Truck Data and Capacity Plate

- Truck model number or registered name.
- Truck serial number—An identification number assigned to this particular truck and should be used when requesting information or ordering service parts for this truck from your authorized CLARK dealer. The serial number is also stamped on the frame.
- Attachment description (if any installed)—The user must see that the truck is marked to identify the attachment(s), including the weight of the truck/attachment combination and truck capacity with the attachment.
- Capacity rating, load center, and lifting height data—Shows the maximum load capacity of this truck with relation to load centers and fork heights (see diagram on plate). Personal injury and damage to the truck can occur if these capacities are exceeded. **Do not exceed the maximum capacity specified.**
- Truck weight—The approximate weight of the truck without a load on the forks. This weight plus the weight of the load must be considered when operating on elevators, elevated floors, etc. to be sure they are safe.

CLARK From the factory this truck meets ASME B56.1

Model: Type: Serial No.:

Attachments:

	A	B	C
1A	in		
1B			
2A	in		
2B			
3A	in		
3B			
4A	in		
4B			
5A	in		
5B			
6A	in		
6B			

Capacities are with attachment or forks with weight in vertical position.
 Capacities are for centered loads only.

Truck Weight: lb or kg / Max Battery: lb or kg
 Max Battery: lb or kg / Max Battery: lb or kg
 Max Amp. hrs. Volts No.

Made in Korea For other capacities contact Clark Material Handling Co., Springfield, CT 2820012



CAUTION

When attachments are added or if the truck is modified, the capacity of the truck may be affected. Contact your authorized CLARK dealer for a new nameplate showing the revised capacity.

IMPORTANT

OSHA requires prior written approval from the manufacturer before any modifications affecting capacity or safety may be made.

Operator Safety Warning Decal



IMPORTANT

Safety and warning decals are placed in conspicuous locations on the truck to remind you of essential procedures or to prevent you from making an error that could damage the truck or possibly cause personal injury. You should know, understand, and follow these instructions. Safety and warning decals should be replaced immediately if missing or defaced (damage or illegible). Refer to your Service Manual for location of all decals.

Operator/Tip-Over

This decal is located on the front right hand leg of the driver's overhead guard. It is to remind the operator that staying in the seat provides the best chance of avoiding injury in the event of a tip-over or off the dock mishap.


Lift trucks can be tipped over if operated improperly. Analysis of lift truck accidents has shown that the driver cannot react quickly enough to jump clear of the truck and overhead guard as the truck tips. To protect operators from severe injury or death in the event of a tip-over, it is best to be held securely in the seat. So, please, always buckle up when driving your lift truck. (see page 1.13)





Upright Warning Decal

This safety decal is on the upright to warn of the danger of injury from movement between rails, chains, sheaves, fork carriage, and other parts of the upright assembly. Do not climb on or reach into the upright. Personal injury will result if any part of your body is put between moving parts of the upright.



Keep Away from Forks Decal

This safety decal is placed on the upright to warn of the danger of injury from forks when they are in the raised position. Do not ride on or stand under forks or attachments. The forks can fall and cause injury or death. Always make sure that the forks are in the fully lowered position when they are not being used to handle a load.





Operating Procedures

Contents


Before Operating the Truck	4-2
Starting from a Safe Condition	4-3



Before Operating the Truck

Be sure that you have read and understand the information in this Operator's Manual before operating the lift truck.

The Operator's Manual Holder is located on the back of the seat.



WARNING

- This equipment can be dangerous if not used properly. Safe operation is the responsibility of the operator.
- Do not start or operate the truck, or any of its functions or attachments, from any place other than the designated operator's position.




CAUTION

- Inspect your lift truck before operating at the start of the day or shift. Before putting your truck to use, check the operation of the controls and all systems.
- Protect yourself. Do not operate truck without a driver's overhead guard unless conditions prevent its use. Do not remove overhead guard unless specifically authorized. Use special care if operation without this safety device is required.


Starting from a Safe Condition

Always start from a safe condition. Before operating a lift truck, make sure that:

1. Parking brake is applied.
2. Forks are fully lowered to the floor or ground.
3. You are familiar with how all the controls function and have read the Operator Manual.
4. All controls are in neutral or other correct position.
5. Truck has received its daily inspection and is ready and safe to operate.




Put the direction control lever in the **NEUTRAL position**, before turning the key switch to ON.



Adjusting the Seat

Adjust the seat to a comfortable position for you. Adjust the seat by moving and holding the release lever at the front under of the seat. Put the seat in a position that will provide easy reach to all controls. Release the seat lever. Make sure that the seat locking mechanism is engaged.




CAUTION

Never adjust the driver's seat while the truck is moving, to avoid the possibility of loss of control and of personal injury.

Buckling Up

Buckle up. Be sure that you put on the seat belt. Connect and adjust the seat belt strap to a snug, comfortable position.



WARNING

Always wear your seat belt when operating a lift truck.


Starting the Truck

Before you start the truck, make sure that you have taken all the above-mentioned precautions and that the directional control is in NEUTRAL. To start the truck, turn the key switch clockwise to the ON position.

Positioning Forks and Upright

When driving, with or without a load, it is good practice to have the forks slightly raised and tilt the upright (forks) backward. Having the forks raised and tilting back prevents the fork tips from catching on possible obstructions and reduces the wear on the fork blades from striking or dragging on the floor or ground. See the NOTICE and CAUTION below.

Pull back on the lift control lever and raise the forks 6 to 8 inches (152 to 203 mm) above the floor. Then, using the tilt control, tilt the upright back slightly to raise the fork tips.



NOTICE

When the upright (carriage and/or load) is raised, the stability of the truck is reduced. Some of the other conditions that may affect stability are: ground and floor conditions, grade, speed, loading, dynamic and static forces and the judgement exercised by the operator. Trucks equipped with attachments behave as partially loaded trucks even when operated without a load on the attachment. Also, improper operation, faulty maintenance or poor house-keeping may contribute to a condition of instability.



CAUTION

For stability reasons, do not travel with the load or carriage in a highly elevated position. Travel with the lift mechanism raised only enough to clear the ground or obstacles.



WARNING


If your truck starts to tip over, **DO NOT JUMP!** Your chances for survival in a tip-over are better if you stay with the truck, in your seat. **BRACE YOURSELF!** Make sure your seat belt is fastened securely. Stay in your seat. Grip the wheel. Brace your feet. See *page 1.14*

Controlling Speed

With the direction control in FORWARD or REVERSE, the parking brake released, put your foot on the accelerator pedal and push down smoothly until the truck is moving at the desired speed.

Braking

To stop the truck, lift your foot from the accelerator pedal and put it on the brake pedal. Push down on the brake pedal in a smooth, firm motion until the truck is stopped.



IMPORTANT

Stop a lift truck as gradually as practical. Hard braking and wheel sliding are dangerous and can cause tip-over or the truck could lose its load. Also, hard braking can increase wear and can be harmful to the lift truck.

Operating Safely

IMPORTANT

Safe operation is the responsibility of the operator. Watch where you are going. Don't go if you can't see.

Before driving, check all around to be sure that your intended path of travel is clear of obstructions and pedestrians.

While driving, be alert for pedestrians, other vehicles or obstructions in your path of travel.



Watch people. Do not allow anyone to stand or pass under the load or raised forks. Watch for people in your work area even if your truck has warning lights or alarms. They may not watch for you.

Sound horn at intersections and wherever vision is obstructed. Do not drive a truck up to anyone standing in front of an object.


Protect yourself and those around you...

Operate the truck only from the designated operator's position. Stay within the confines of the lift truck profile dimensions. Keep arms, legs and hands inside the operator's compartment and away from the danger of passing obstructions. Keep under the overhead guard.

NOTICE

An overhead guard is intended to offer protection to the operator from falling objects, but cannot protect against every possible impact. Therefore, it should not be considered a substitute for good judgement and care in loading, handling, storage, etc..

Keep clear of the upright and lift mechanism. NEVER reach into or put hands, arms, legs or head into or through the upright structure or near the carriage or lift chains. Never put any part of your body between the upright and the truck. Don't use the upright as a ladder.



Keep all other persons clear of the load and upright mechanism while attempting to handle a load.

No riders...

Do not carry passengers. The operator is the only one who should be on the truck.

Always be in full control of your lift truck...

Never operate a lift truck or its attachments if you are not in the designated operator's position.

Never operate a lift truck when your hands are wet or greasy.

Always pick the smoothest travel route for your lift truck. Avoid bumps, holes, slick spots, and loose objects or debris in your path that may cause the truck to swerve or tip. If these conditions are unavoidable, slow down and carefully drive past them. Slow down for wet or slippery surfaces.

Avoid any sudden movement. Start, stop, travel, steer, and brake smoothly.

Operate your lift truck under all conditions at a speed that will permit it to be brought safely to a stop.



WARNING

Travel slowly when turning. Use special care when traveling without a load because the risk of tipping over is greater with an empty truck, especially at high speed and when cornering.

Travel with the fork carriage tilted back and raised only enough to fully clear the ground or obstacles. When the carriage (load) is elevated, the stability of the truck is reduced.

Do not elevate the load except during stacking.

Grades, ramps, and inclines...

Use special care when operating on ramps, inclines, and uneven areas. Travel slowly. Travel straight up and down. Do not turn or drive at an angle across an incline or ramp.

When the truck is loaded, travel with the load upgrade. When the truck is empty, travel with lifting mechanism (upright) downgrade.

Practice safe operation every time you use your truck...

Careful driving and operation is your responsibility. Be completely familiar with all the safe driving and load handling techniques in this operator's manual. Use common sense. Drive carefully; do not indulge in stunt driving or horseplay. Observe traffic rules. Watch for people and hazards. Slow down. Be in full control of your lift truck at all times.

Follow the instructions in this manual to avoid damage to your truck or the possibility of injury to yourself or others.

During your work, observe all functions of your lift truck. This allows you to immediately recognize a problem or irregularity that could affect the safe operation of your truck.


Periodically check the gauges and warning indicator lights in the instrument panel to be sure they indicate a normal condition. If an abnormal condition appears, shut off the key switch immediately and report the problem.

IMPORTANT

Do not continue to operate a truck that has a malfunction. Stop and have it fixed.

IMPORTANT

Always wear your seat belt when operating your lift truck.




CAUTION


Operate your lift truck only in areas that have been approved for your lift truck type designation. Certain areas contain flammable gases, liquids, dust, fibers, or other hazardous materials. Lift truck operations in these areas must have special approval. These areas must be designated to show the type of lift truck approval required for operation in the area. Be aware that changes to special equipment or poor maintenance can cause the lift truck to lose its special approval. Be sure that your truck is the correct fire safety type for the area in which you are working. The proper type designation for this truck is listed on the nameplate. In areas classified as hazardous, use only trucks approved for use in those areas. If you are unsure of the classification of the area you wish to enter, check before entering.

Adjusting the Load Forks

The load forks are adjustable on the hanger shaft. Forks should be spaced as far apart as the load being carried will allow. Both forks should always be the same distance from the center of the fork carriage. To adjust the forks, raise the carriage slightly. Tilt the upright fully forward to reduce friction and make the forks slide easier. Unlock the fork locking pins. Position the forks. Secure the fork locking pins.



Forks are heavy, keep fingers clear. Move forks by pushing with one foot while holding on to the load back rest with hands. Be sure to have firm footing before attempting to move forks. Do not attempt this where the floor is slippery or wet.



Load Handling

Handle only loads that are within the truck rated capacity as shown on the nameplate. This rating specifies the maximum load that should be lifted. However, other factors such as special load handling attachments, loads having a high center of gravity, or uneven terrain may dictate that the safe working load be less than the rated capacity. Under these conditions, the operator must reduce the load carried so that the lift truck remains stable.

Handle only stable or safely arranged loads. Do not handle loads made up of loose, unevenly stacked or unstable items that can easily shift and fall. Take the time to correctly stack and band loose items. Center the load on the forks.

Do not lift anything that might fall on the operator or a bystander.

Do not handle loads that are higher than the fork carriage unless the load is secured so that no part of it can fall backwards.

Keep the load back against the carriage. Loads placed out on the ends of the forks can make the lift truck less stable and more likely to tip up.

Lift and lower with the upright mast vertical or tilted slightly back — **never tilted forward.**

Operate lift and tilt controls slowly and smoothly. Never tilt forward when carriage (load) is raised, except to pick up or deposit a load over a rack or stack.




WARNING

Slack chains mean rail or carriage hang-up. Raise the upright before you move. If the upright malfunctions in any way or becomes stuck in a raised position, operate the lift control to eliminate any slack chains. DO NOT go under a raised upright or forks to attempt repairs. DO NOT reach into or climb on upright to free hang-up.

Remember, your lift truck is designed to carry loads forward of the front wheels so that the weight of the load is counter-balanced by the weight of the truck.

The farther the load is carried from the pivot point (center of front wheels), the greater will be the uplift at the rear of the truck. Therefore, always carry the load as close to the front wheels as possible (back and flush against the face of the forks).



The capacity load shown on the nameplate is represented by a cube in which the weight is evenly distributed, with the center of gravity located a standard distance from the face of the forks. If the weight of the actual load to be handled is not evenly distributed, put the heaviest part closest to the carriage.

Traveling with a Load

Travel with load or carriage as low as possible and tilted back. Never travel with the load or carriage raised (elevated) in a high position. Do not elevate the load except during stacking.

Observe all traffic regulations and watch for other traffic, pedestrians, and safe clearances. Always look in the direction of travel. Keep a clear view of the path of travel, and when the load blocks your visibility, travel in reverse with load trailing (except when climbing an incline).

Avoid sudden movements when carrying a load—start, stop, travel, steer, and brake smoothly. Steer clear of bumps, holes, and loose materials or debris on the ground. Lift and tilt slowly and smoothly. Go slowly when turning. Cross railroad tracks slowly at an angle wherever possible.

Use special care when handling and traveling with long, high, or wide loads—to avoid losing the load, striking bystanders or obstructions, or tipping the truck.


Watch clearances around the truck and load as you travel. Raise the forks or attachment only to pick up or stack a load. Look out for obstructions, especially overhead.

Be aware that exaggerated tail swing, when turning while traveling forward, is a characteristic of lift trucks that are steered by the rear wheels. Accordingly, you need to become accustomed to tail swing and always check the tail swing area of the counterweight to be sure it is clear before you turn.

Always be concerned about the stability of your lift truck. When attachments are used, extra care should be taken in securing, manipulating, positioning, and transporting the load. Because attachments generally add extra weight and complexity to the truck, operate trucks equipped with attachments as partially-loaded trucks when not handling a load.

Picking Up and Moving Loads

When picking up a load from the ground, approach the load slowly and carefully align the truck square with the load. The forks should be adjusted to fit the load or pallet being handled and spread as wide as possible to provide good stability and balance. Before lifting, be sure the load is centered and the forks are fully under and supporting the load. Fork length should be at least $\frac{2}{3}$ of load length. With the lift and tilt controls, adjust the forks to the correct height and angle for freely engaging the load pallet. Move forward until the forks are squarely and completely under the load.



NOTICE

Be sure that the forks do not extend beyond the load, causing damage or tipping of other adjacent loads or materials behind the load being moved.

If the forks are longer than the load, move the tips partially under the load without extending beyond the load. Raise the load to clear the floor. Back out several inches, or whatever distance is necessary, then set the load down and move forward until the load is positioned against the carriage.

Raise the load from the floor or stack by tilting the upright back just enough to lift the load from the surface. When stacking or tiering, use only enough backward tilt to stabilize the load.

Then raise the load to traveling height and tilt fully back to travel (except for loads that must be transported as level as possible).

Unloading

To deposit a load on the floor after being moved into the correct position, tilt the upright forward to a vertical position and lower the load.

Adjust the fork height and tilt the upright forward slightly, as necessary, for smooth removal of the forks from the load (pallet).


Carefully back away to clear the forks from the load.

Raise the forks to traveling height and tilt fully back.


Stacking

To put a load on a stack:


1. Approach slowly and align the lift truck and load squarely with the stack.




2. Raise (elevate) the load as the lift truck is nearing the stack.



3. Move forward, slowly, until the load is almost touching the stack. The leading edge and sides of the load pallet should be lined up exactly with the near edge and side of the load or rack on which you are stacking.




4. Stop close to the stack and further lift (raise) the load high enough to clear the top surface of the stack. Slowly move the load into position. Be careful not to damage or move adjacent loads.




5. When the load is aligned with the stack beneath it, tilt the upright to the vertical position and carefully lower the load onto the top surface of the stack.

- Lower (drop) the forks slightly to clear (disengage) the load pallet. Tilt the forks forward slightly, if necessary.



- Check your travel path, then carefully back away until the forks are clear of the stack. Stop and lower the forks to the travel position (6 to 8 inches above the ground), then tilt back to travel.



To move a load from a stack:

Approach the stack carefully, truck lined up squarely with the load. With the truck just in front of the stack and the upright mast vertical, raise the forks to the correct height for freely engaging the load pallet. Adjust fork angle as necessary to fit squarely under the load. Move forward until the forks are under the load.

Be sure that the forks do not extend beyond the load, causing damage or tipping of other adjacent loads or materials behind the load being moved. If the forks are longer than the load, move the tips partially under the load without extending beyond the load. Raise the load to clear the undersurface. Back out several inches, then set the load down and move forward until the front face of the forks contacts the load.

Raise the load from the stack by tilting the upright back just enough to lift the load from the surface. Or, with the mast still vertical, raise the forks until they begin to lift the load. At this point, apply the minimum back tilt that will stabilize the load.

Check your travel path, slowly back off until clear of the stack, stop, and then lower the load to the travel position (6 to 8 inches off the ground). Tilt full back to travel (except for certain loads that may have to be transported as level as possible). Be sure the load is back flush against the carriage or front face of the forks.

NOTICE

Certain loads may have to be transported as level as possible.



After Operating the Truck

Always leave your lift truck in a safe condition. When you leave your truck, or park it, follow these safety rules:

- Park in a safe area away from normal traffic.
- Never park on a grade.
- Never park in areas that block emergency routes or equipment, access to fire aisles, or stairways and fire equipment.



Before leaving the operator's position:

1. Bring truck to complete stop.
2. Put the directional control lever in the NEUTRAL position.
3. Apply the parking brake.
4. Turn the key switch to the OFF position.
5. Lower the lift mechanism fully.

If you are going to leave the truck unattended:

6. Remove the key.
7. Block the wheels if the truck has any possibility of moving.

Operator Maintenance and Care

Contents

Daily Safety Inspection	5-2
Fuel Safety Practices	5-5
Refueling LPG Tanks	5-6

NOTICE

The Occupational Safety and Health Act (OSHA) requires that truck users examine their trucks before each shift to be sure they are in safe working order. Defects when found shall be immediately reported and corrected. The truck shall be taken out of service until it has been restored to safe operating condition.



Daily Safety Inspection

Before using a lift truck, **it is the operator's responsibility** to check its condition and be sure it is safe to operate.

Check for damage and maintenance problems; have repairs made before you operate the truck. Unusual noises or problems must be reported immediately to your supervisor or other designated authority.

Do not make repairs yourself unless you are trained in lift truck repair procedures and authorized by your employer. Have a qualified mechanic make repairs using genuine CLARK or CLARK-approved parts.



CAUTION

Do not operate a truck if it is in need of repair. If it is in an unsafe condition, remove the key and report the condition to the proper authority. If the truck becomes unsafe in any way while you are operating it, stop operating the truck, report the problem immediately, and have it corrected.

Lift trucks should be inspected every eight hours, or at the start of each shift. In general, the daily inspection should include the **visual** and **functional checks** described on the following pages.

As an aid in carrying out this inspection, CLARK has prepared a form called the **"Driver's Daily Checklist."** We recommend that you use this form to make a daily record of your inspections and truck condition. You may obtain copies of this form from your CLARK dealer.



WARNING

Leaking hydraulic oil may be hot or under pressure. When inspecting a lift truck, wear safety glasses and do not check for leaks with bare hands.

Visual Checks

First, perform a visual inspection of the truck and its major components:

1. Walk around your lift truck and take note of obvious damage that may have been caused by operation during the last shift.
2. Check that all capacity, safety, and warning plates or decals are attached and legible.
3. Check before and after starting engine for leaking fuel, engine coolant, transmission fluid, etc.
4. Check for hydraulic oil leaks and loose fittings.



CAUTION

Do not use bare hands to check. Oil may be hot or under pressure.

5. Be sure that the driver's overhead guard, load back rest and all other safety devices are in place, securely fastened and undamaged. Inspect for damaged or missing parts, corrosion, cracks, breaks etc.
6. Check all of the critical components that handle or carry the load.
7. Look the upright and lift chains over. Check for obvious wear and maintenance problems such as damaged or missing parts, leaks, slack or broken chains, rust, corrosion, bent parts, cracks, etc.
8. Carefully inspect the load forks for cracks, breaks, bending, twists, and wear. Be sure that the forks are correctly installed and locked in their proper position.
9. Inspect the wheels and tires for safe mounting, wear condition, and air pressure.
10. Check the hydraulic sump oil level, engine oil level, and fuel level.

Functional Checks

Check the operation of the truck as follows.

NOTICE

Before performing these checks, familiarize yourself with the starting, operating, and shutdown procedures in Section 4 of this manual. Also, know the safety rules given in Section 1 of this manual.

1. Test warning devices, horn, lights, and other safety equipment and accessories.
2. Start the engine and be sure all controls and systems operate freely and return to neutral properly. Check the:
 - Gauges, meters, and indicator lights
 - Service brakes, inching pedal, and parking brakes
 - Hydraulic controls: lift, tilt, and auxiliary (if installed)
 - Accelerator
 - Directional control
 - Steering system
 - Lift mechanism and any attachments.

When the functional checks are completed, follow the **standard shut-down procedures** given in Section 4, "Operating Procedures."


Concluding the Inspection

Make a record on the "Driver's Daily Checklist" of all the problems that you find. Review the checklist to be sure it has been completed and turn it in to the person responsible for lift truck maintenance. Be sure any unusual noises or problems are investigated immediately.

Do not operate a lift truck that has a maintenance problem or is not safe to operate.



Instead, remove the key from the ignition switch and put an "Out of Service" tag on the truck.

If all of the Daily Inspection checks were normal or satisfactory, the truck can be operated.



Fuel Safety Practices


Refueling Gasoline and Diesel Trucks



Refueling LPG Tanks

When changing liquefied petroleum gas (LPG), tanks follow these basic rules:

- Change only in well ventilated areas.
- Never allow open flames.
- Turn the ignition switch to the OFF position.
- Check for leaks.
- Check condition of the O-ring.
- Make sure tank is on locating pin.
- Make sure tank latches are securely fastened.
- Store tanks according to local fire codes



Typical Illustration

If you refill LPG tanks:

- Make sure you know and understand the proper procedure for filling an LPG tank.
- If you have any questions on refilling LPG tanks, please ask your supervisor.

DANGER

LPG IS HEAVIER THAN AIR. It settles on your clothes and the ground around you, displacing oxygen vital for breathing. Open flame can cause flash fires.

IMPORTANT

Check all connections for damage or leaks. If the truck will not start after you change tanks, get a qualified mechanic to check the truck.

RECOMMENDED SAFETY MAINTENANCE PROCEDURES FOR LPG FUELED LIFT TRUCKS



WARNING

LPG is a combustible fuel that is heavier than air. Escaping gas may accumulate in low areas. The fuel cylinder should be mounted so that it does not extend outside the truck and should also be properly positioned by using the locating pin or key way.

The fuel valve should be turned off when the machine is not in service. Cast fittings should not be used in the LPG system. Use only Underwriters Laboratories or Factory Mutual listed LPG hose assemblies where pressure fuel lines are required. All pipe threaded fittings should be installed using an approved sealing compound. Fuel lines should be supported by clamps to minimize chafing and wear. The LPG solenoid valve should be wired to an automatic shut off switch (oil pressure or vacuum) to prevent leakage of gas in the event the ignition is on without the engine running. Check the LPG solenoid or vacuum shutoff valve for leakage as follows:

1. Turn fuel tank valve off, start and run engine until it stops.
2. Install a 0 to 30 psi pressure gauge per instruction A or B:
 - A. To primary test port of single units consisting of primary and secondary regulators.
 - B. Between the primary and secondary stage regulators when the LPG system consists of two regulators.
3. Turn the tank fuel valve on. The pressure gauge should maintain a zero reading. If it does not, the solenoid valve or vacuum shut-off valve must be repaired or replaced. An odor is added to LPG to help indicate leaks. If you detect gas odor, you should turn off the fuel tank supply valve and engine. Remove all sources of ignition, and ventilate the area. Make all of the necessary repairs before you turn the fuel supply on. The complete LPG system should be inspected periodically. Check all hoses for wear, connections for leaks, and all parts for damage.

NOTE: Fuel hoses have a limited life expectancy. They should be checked for cracking and drying due to age. Hoses with visible signs of age should be replaced. Use only Underwriters Laboratories or Factory Mutual listed LPG parts for replacements.

NOTE: The above information is provided as a guide. Consult the National Fire Protection Association Pamphlet 58 for the safe storage and handling of liquefied petroleum gases. Governmental safety regulations in your locality could vary. Check with the authority having jurisdiction to be sure that you meet all of their requirements. Contact the manufacturer for detailed service information.

Emergency Starting and Towing

Contents

How to Tow a Disabled Truck	6-2
How to Use Battery Jumper Cables	6-4



How to Tow a Disabled Truck

If your lift truck becomes disabled but it can be moved freely on its own wheels without further damage, use the following procedures to tow it safely to a repair area.

IMPORTANT

It is important for your safety and the care of your lift truck to use the proper equipment and carefully follow these recommendations for safe towing.



WARNING


DO NOT tow a lift truck if there is a problem with the brakes or tires or the steering cannot be operated. DO NOT tow up or down ramps and steep inclines. DO NOT attempt to tow a lift truck if traction or weather conditions are poor.

1. Be sure to apply the parking brake or block the drive wheels on the disabled truck while working around it.
2. When possible, raise the carriage (forks) on the disabled truck about 12 inches (300 mm) from the floor or ground. Secure the carriage with a chain.
3. Obtain another lift truck of equal or larger size carrying a partial load for traction.
4. Check that the counterweight bolts are in place and properly torqued. (This bolt is made of a special high-tensile steel and is not commercially available. Replace it, when necessary, only with a genuine Clark replacement part).
5. Use an approved, solid metal tow bar with towing couplers that connect to the towing pins in the counterweights.
6. Release the parking brake on the towed vehicle.
7. Transmission control is in neutral.

NOTICE

DOT approved towing equipment may be available from your Clark dealer.

8. Tow the disabled truck backward. **An operator must be on the towed truck.** Tow the truck slowly. Careful towing is necessary to prevent injury to personnel or damage to the truck. The truck should be towed at a speed of less than 5 m.p.h. (8 kph) with a driver in the seat. Do not lift the truck or any wheels off the floor or ground while the truck is being towed.



⚠ CAUTION

The power steering and brakes will not operate on the disabled truck when the engine is not running. Manual operation of the handwheel and brakes will be difficult to operate. More manual effort will be required to perform these functions.

9. Park the disabled truck in authorized areas only. Fully lower the forks to the floor, put the directional control lever in the NEUTRAL position and turn the ignition switch to the OFF position. Engage the parking brake. Remove the ignition key and, when necessary, block the wheels to prevent the truck from rolling.

⚠ WARNING

Always engage the parking brake when parking a lift truck. The truck can move and cause injury or death to personnel near it.

Towing a Disabled Hydrostatic Truck

Clark does not recommend towing a disabled Hydrostatic lift truck without first consulting your service manual.



⚠ CAUTION

If the Hydrostatic lift truck can not be moved under its own power you should have a trained and authorized mechanic look at it immediately. If a disabled hydrostatic lift truck is moved or towed by an unauthorized person, the result could be serious damage to the Hydrostatic drive train.

Park the disabled truck in authorized areas only. Fully lower the forks to the floor, put the directional control in the NEUTRAL position and turn the ignition switch to the OFF position. Engage the parking brake.

Remove the ignition key and, when necessary, block the wheels to prevent the truck from rolling.

How to Use Battery Jumper Cables

If your lift truck battery is discharged (“dead”), you can start your lift truck by “jumping” it from another lift truck that has a 12-volt, negative-ground electrical system. The “booster” battery must be fully charged and in good condition. This section explains how to perform this procedure safely. To avoid damage to your lift truck and your battery or the possibility of harm to yourself, follow the instructions and warnings carefully. If you have any doubts, ask for help from an experienced mechanic.

If your truck has a battery with terminals on the side you will need a set of jumper cables with matching connector clamps or cable adapters for side-mounted battery terminals.



CAUTION

USE ONLY A 12-VOLT, NEGATIVE GROUND SYSTEM to jump your truck. You can injure yourself and permanently damage your truck’s 12-volt starting motor and ignition system by connecting it to a 24-volt power supply (two 12-volt batteries in series or a 24-volt generating set) or to a positive-ground system.



WARNING

BATTERIES CONTAIN SULFURIC ACID. Avoid acid contact with skin, eyes, or clothing. If acid contacts your eyes or skin, flush immediately with water and get medical assistance. Wear safety glasses when working near the battery to protect against possible splashing of the acid solution.

1. If the discharged battery has filler caps, check the fluid level. Do not use an open flame to check and do not smoke. If low, add distilled water to the correct level. Be sure to install the caps before jump starting.

Do not jump start, charge, or test a sealed-type battery if the test indicator looks illuminated or has a bright color. Install a new battery.



WARNING

BATTERIES EMIT EXPLOSIVE GAS. Do not smoke or have open flames or sparks in battery charging areas or near batteries. An explosion can result and cause injury or death.

Hydrogen gas is produced during normal battery operation. Hydrogen can explode if flames, sparks, or lighted tobacco are brought near the battery. When charging or using a battery in an enclosed space, always provide ventilation and shield your eyes. Wear safety glasses when working around batteries.

2. Put the truck with the booster battery as near to the other truck as necessary for the jumper cables to reach both batteries. Check and make sure that the trucks do not touch each other. **Use particular care when connecting a booster battery to prevent sparks.**
3. On both trucks:
 - a. Apply the parking brake.
 - b. Put the directional control lever in the NEUTRAL position.
 - c. Turn the key/start switch to the OFF position.
 - d. Turn all accessories to the OFF position and leave them off until after the engine has been started and the jumper cables have been removed.




WARNING

To avoid **SHORT CIRCUITS**, remove all jewelry and do not permit any metal tools to make contact between the positive battery terminal and other metal on the truck. When you connect jumper cable clamps to the positive terminals of the two batteries, make sure that neither clamp contacts any other metal. Injury can occur from electrical shock or explosion.



4. Connect the jumper cables in the following sequence:

- a. Connect a jumper cable from the positive (+; red) terminal on one battery to the positive (+; red) terminal on the other battery. Never connect positive (+; red) to negative (-; black), or negative to positive.
- b. Connect one end of the second cable to the grounded negative (-; black) terminal of the "Jumper Vehicle" battery.
- c. Connect the other end of the second cable to a stationary, solid metallic point **on the engine** of the "Stalled Vehicle," **not to the negative (-; black) terminal** of its battery. Make this connection at a point at least 18 inches (450 mm) away from the battery, if possible. Do not connect it to pulleys, fans or other parts that move. Do not touch hot manifolds that can cause severe burns.



5. Start the engine on the "Jumper Vehicle" and run the engine at a moderate speed for a minimum of five minutes.
6. Start the engine on the "Stalled Vehicle." Follow the starting instructions in Section 4, "Operating Procedures" in this manual. Be sure that the engine is at idle speed before disconnecting the jumper cables.
7. Remove the jumper cables by reversing the installation sequence exactly. Start by removing the last jumper cable from the stalled vehicle first. Remove the cable end from the engine block first, then the other end of the negative (-; black) cable.
8. Remove both ends of the positive (+; red) cable.

Planned Maintenance and Lubrication

Contents

Introduction	7-2
Safe Maintenance Practices	7-3
Major Component Locations	7-8
Planned Maintenance Intervals	7-9
PM Report Form	7-12
How to Perform Planned Maintenance	7-14

NOTICE

THIS SECTION IS FOR TRAINED SERVICE PERSONNEL to use as a reference for Planned Maintenance procedures. Complete maintenance information is in the Service Manuals.



Introduction

NOTICE

ONLY TRAINED AND AUTHORIZED PERSONNEL should perform **Planned Maintenance**. Local **CLARK** dealers are prepared to help customers put in place a **Planned Maintenance program** for checking and maintaining their lift trucks according to applicable safety regulations.



CAUTION

Powered industrial trucks may become hazardous if maintenance is neglected.

The operator should make a safety inspection of the lift truck before operating it. The purpose of this daily examination is to check for any obvious damage and maintenance problems, and to have minor adjustments and repairs made to correct any unsafe condition.

In addition to the operator's daily inspection, CLARK recommends that the owner set up and follow a periodic planned maintenance (PM) and inspection program. Performed on a regular basis **by trained** personnel, the program provides thorough inspections and checks of the safe operating condition of the lift truck. The "PM" identifies needed adjustments, repairs, or replacements so they can be made before failure occurs. The specific schedule (frequency) for the PM inspections depends on the particular application and lift truck usage.

This Section recommends typical Planned Maintenance and Lubrication Schedules for items essential to the safety, life, and performance of the truck. It also outlines safe maintenance practices and gives brief procedures for inspections, operational checks, cleaning, lubrication, and minor adjustments.

Specifications for selected components, fuel, lubricants, critical bolt torques, refill capacities, and settings for the truck are found in Section 8.

If you have need for more information on the care and repair of your truck, see your CLARK dealer.

Safe Maintenance Practices

The following instructions have been prepared from current industry and government safety standards applicable to industrial truck operation and maintenance. These recommended procedures specify conditions, methods, and accepted practices that aid in the safe maintenance of industrial trucks. They are listed here for the reference and safety of all workers during maintenance operations. Carefully read and understand these instructions and the specific maintenance procedures before attempting to do any repair work. When in doubt of any maintenance procedure, please contact your local CLARK dealer.

1. Powered industrial trucks can become hazardous if maintenance is neglected. Therefore, suitable maintenance facilities and trained personnel and procedures shall be provided.
2. Maintenance and inspection of all powered industrial trucks shall be performed in conformance with the manufacturer's recommendations.
3. Follow a scheduled planned maintenance, lubrication, and inspection system.
4. Only trained and authorized personnel are permitted to maintain, repair, adjust, and inspect industrial trucks-and must do so in accordance with the manufacturer's specifications.
5. Always wear safety glasses. Wear a safety (hard) hat in industrial plants and in special work areas where protection is necessary and required.
6. Properly ventilate work area, vent exhaust fumes, and keep shop clean and floors dry.
7. Avoid fire hazards and have fire protection equipment present in the work area. Do not use an open flame to check for leakage. Do not use open pans of fuel or flammable cleaning fluids for cleaning parts.
8. Before starting work on truck:
 - a. Raise drive wheels free of floor and use oak blocks or other positive truck positioning devices.
 - b. Remove all jewelry (watches, rings, bracelets, etc.).
 - c. Put oak blocks under the load-engaging means, innermasts, or chassis before working on them.
 - d. Disconnect the battery ground cable (-) before working on the electrical system.





CAUTION

Refer to the “Jacking and Blocking” section in the Service Manual for proper procedures.

9. Operation of the truck to check performance must be conducted in an authorized, safe, clear area.
10. Before starting to operate the truck:
 - a. Be seated in a safe operating position and fasten your seat belt.
 - b. Make sure parking brake is applied.
 - c. Put the direction control in NEUTRAL.
 - d. Start the engine.
 - e. Check functioning of lift and tilt systems, direction and speed controls, steering, brakes, warning devices, and load handling attachments.
11. Before leaving the truck:
 - a. Stop the truck.
 - b. Fully lower the load-engaging means: upright, carriage, forks or attachments.
 - c. Put the directional control in NEUTRAL.
 - d. Apply the parking brake.
 - e. Stop the engine.
 - f. Turn the key switch to the OFF position.
 - g. Put blocks at the wheels if the truck must be left on an incline.
12. Brakes, steering mechanisms, control mechanisms, warning devices, lights, governors, lift overload devices, lift and tilt mechanisms, articulating axle stops, load back rest, overhead guard and frame members must be carefully and regularly inspected and maintained in a safe operating condition.
13. Special trucks or devices designed and approved for hazardous-area operation must receive special attention to insure that maintenance preserves the original approved safe operating features.

14. Fuel systems must be checked for leaks and condition of parts. Extra special consideration must be given in the case of a leak in the fuel system. Action must be taken to prevent the use of the truck until the leak has been corrected.
15. All hydraulic systems must be regularly inspected and maintained in conformance with good practice. Tilt and lift cylinders, valves, and other parts must be checked to assure that "drift" or leakage has not developed to the extent that it would create a hazard.
16. When working on the hydraulic system, be sure the engine is turned off, upright is in the fully-lowered position, and hydraulic pressure is relieved in hoses and tubing.



WARNING

Always put oak blocks under the carriage and upright rails when it is necessary to work with the upright in an elevated position.

17. The truck manufacturer's capacity, operation, and maintenance instruction plates, tags, or decals must be maintained in legible condition.
18. Batteries, limit switches, protective devices, electrical conductors, and connections must be maintained in conformance with good practice. Special attention must be paid to the condition of electrical insulation.
19. To avoid injury to personnel or damage to the equipment, consult the manufacturer's procedures in replacing contacts on any battery connection.
20. Industrial trucks must be kept in a clean condition to minimize fire hazards and help in detection of loose or defective parts.
21. Modifications and additions that affect capacity and safe truck operation must not be done without the manufacturer's prior written approval. Capacity, operation, and maintenance instruction plates, tags, or decals must be changed accordingly.

22. Care must be taken to assure that all replacement parts, including tires, are interchangeable with the original parts and of a quality at least equal to that provided in the original equipment. Parts, including tires, are to be installed per the manufacturer's procedures. Always use genuine CLARK or CLARK-approved parts.



WARNING

When removing tires follow industry safety practices. Most importantly, deflate pneumatic tires completely prior to removal. Following assembly of tires on multi-piece rims, use a safety cage or restraining device while inflating.

23. Use special care when removing heavy components, such as counterweight, upright, etc. Be sure that lifting and handling equipment is of the correct capacity and in good condition.

IMPORTANT

Your new CLARK lift truck has been built to meet all applicable mandatory requirements of ASME B56.1 Safety Standard for Powered Industrial Trucks. Each truck also includes certain safety devices—such as horn, overhead guard, and load back rest—as standard equipment. No additions, omissions, or modifications should be made that affect compliance to the above requirements or in any way minimize the effectiveness of the safety devices.

NOTICE

You should be familiar with additional operating and maintenance safety instructions contained in the following publications:


ASME B56.1: Safety Standard for Low Lift and High Lift Trucks (Safety Code For Powered Industrial Trucks). Published by: The American Society of Mechanical Engineers, Three Park Avenue, New York, NY 10016.

NFPA 505: Fire Safety Standard for Powered Industrial Trucks: Type Designations, Areas of Use, Maintenance and Operation. Available from National Fire Protection Association, Inc., Batterymarch Park, Quincy, MA 02269.

General Industrial Standards, OSHA 2206: OSHA Safety and Health Standards (929 CFR 1910), Subpart N-Materials Handling and Storage, Section 1910.178 Powered Industrial Trucks. For sale by: Superintendent of Documents, US Government Printing Office, Washington, DC 20402.

Major Component Locations

Use the illustration below to help locate components included in the PM procedures.



- | | |
|----------------------------|--------------------------|
| 1. Engine Cooling | 8. Overhead Guard |
| 2. Transmission Cooling | 9. Exhaust |
| 3. Steer Axle | 10. Carburetion |
| 4. Engine | 11. Sheet Metal |
| 5. Transaxle | 12. Upright and Carriage |
| 6. Wheels and Tires | |
| 7. Frame and Counterweight | |

The truck shown above is a typical representation of a Clark internal combustion lift truck. Your model may vary slightly.

Planned Maintenance Intervals

Time intervals between maintenances are largely determined by operating conditions. For example, operation in sandy, dusty locations requires shorter maintenance intervals than operation in clean warehouses. The indicated intervals are intended for **normal** operation. The operating condition classifications are:

Normal Operation

Eight-hour material handling, mostly in buildings or in clean, open air on clean paved surfaces.

Severe Operation

Prolonged operating hours or constant usage.

Extreme Operation

- In sandy or dusty locations, such as cement plants, lumber mills, and coal dust or stone crushing sites.
- High-temperature locations, such as steel mills and foundries.
- Sudden temperature changes, such as constant trips from buildings into the open air, or in refrigeration plants.

If the lift truck is used in severe or extreme operating conditions, you must shorten the maintenance intervals accordingly.

NOTICE

Since the operating environment of lift trucks varies widely, the above descriptions are highly generalized and should be applied as actual conditions dictate.

The maintenance time intervals referred to in this manual relate to truck operating hours as recorded on the hourmeter, and are based on experience CLARK has found to be convenient and suitable under typical (normal or average) operating conditions. The periods and their designations are:

PM Interval:

A=8 - 10 hours or daily

B=50 - 250 hours or every month (typical PM interval)

C=450 - 500 hours or every 3 months

D=900 - 1000 hours or every 6 months

E=2000 hours or every year

PERIODIC CHECKS and PLANNED MAINTENANCE (PM)	A	B	C	D	E
Check truck visually and inspect components.	•				
Test drive truck/check functional performance.	•				
Air clean truck and radiator.	•				
Check torque on critical fasteners.	•				
Lubricate truck. (See component)	•				
Drain and replace engine oil.	•				
Replace gas engine oil filter.	•				
Replace diesel engine oil filter.	•				
Clean and replace gas engine air filter. (*)					•
Clean and replace diesel engine air filter. (*)				•	
Change diesel fuel filter(***)				•	
Change gas fuel filter				•	
Inspect / adjust fan belts.	•				
Drain / flush radiator coolant.					•
Check engine ignition and timing.			•		
Engine tune-up.					•
Check battery.		•			
Check transaxle fluid level.		•			
Change transaxle fluid. (drain and replace)				•	
Change (replace) transaxle oil filter.				•	
Clean drive axle air vent.		•			
Check brake condition and wear.					•
Check drive axle mounting and fasteners.				•	
Lubricate steer axle linkage.		•			
Check / lubricate steer axle wheel bearings.					•
Change / replace hydraulic sump oil filter and breather. (**)				•	
Change / replace hydraulic sump fluid and oil filter. (**)				•	
Lubricate tilt cylinder rod ends.		•			
Check lift chain adjustment and wear.		•			
Check / lubricate lift chains.		•			
Lubricate upright rollers.		•			

NOTES:

* Air filter change interval may be determined by using an air restriction indicator.

** Hydraulic filter change interval may be determined by hydraulic filter restriction indicator.

*** Diesel fuel filter change interval may be determined by fuel filter restriction indicator.

DAILY MAINTENANCE CHECKS	A	B	C	D	E
Check truck for obvious damage and leaks.	•				
Check fuel system for leaks, etc.	•				
Check capacity, warning plates and decals.	•				
Check condition of tires and wheels. Remove embedded objects. Check air pressure.	•				
Check for missing or loose wheel lugs nuts.	•				
Check engine oil level.	•				
Check engine coolant level (radiator and recovery tank)	•				
Check transaxle fluid level	•				
Check fuel level.	•				
Check hydraulic sump oil level.	•				
Check gauges and instruments.	•				
Check warning lights and hour meter.	•				
Check overhead guard condition and bolts.	•				
Check horn operation and other warning devices.	•				
Check steering operation.	•				
Check service brake operation.	•				
Check parking brake operation.	•				
Check parking brake linkage for damage, broken parts.	•				
Check directional and speed controls operation.	•				
Check accelerator and engine speed operation.	•				
Check lift, tilt and aux. operation.	•				
Check upright, lift chains and fasteners.	•				
Check carriage or attachments and forks.	•				
Check seat deck hold-down latch for correct locking.	•				
Check optional safety equipment. (alarms, lights etc.)	•				

PM Report Form

Make and keep records of your PM inspections. Use these records to help establish the correct PM intervals for the truck application and to indicate maintenance required to prevent major problems from occurring during operation.

As an aid in performing and documenting your PM inspections, CLARK has prepared a **Gas, LPG, or Diesel Planned Maintenance Report Form**. Copies of this form may be obtained from your authorized CLARK dealer. We recommend that you use this form as a checklist and record of your inspection and truck condition.

The maintenance procedures outlined in this Section are intended to be used in conjunction with the PM Report Form. They are arranged in a logical and efficient sequence.

You make a check mark or entry on the PM Report Form when the PM is performed. A special coding system for indicating the importance of needed repairs and/or adjustments appears on the form.

When you have finished the PM inspections, be sure to give a copy of the report to the designated authority or person responsible for lift truck maintenance.

Do not make repairs or adjustments unless authorized to do so.



CAUTION

For safety, it is good practice to:

- **Remove all jewelry (watch, rings, bracelets, etc.) before working on the truck.**
- **Disconnect the battery ground cable (-) from the battery before working on electrical components.**
- **Always wear safety glasses. Wear a safety (hard) hat in industrial plants and in special work areas where protection is necessary and required.**

Section 7. Planned Maintenance and Lubrication



OPERATORS' DAILY CHECKLIST

Check Each Item Before Start Of Each Shift

Date: _____

Check one: Gas/LPG/Diesel Truck Electric Sit-down Electric Stand-up Electric Pallet

Truck Serial Number: _____ Operator: _____ Supervisor's OK: _____

Hour meter reading: _____

Check each of the following items before the start of each shift. Let your supervisor and/or maintenance department know of any problem. **DO NOT OPERATE A FAULTY TRUCK. Your safety is at risk.**
After checking, mark each item accordingly. Explain below as necessary.

Check boxes as follows: OK NG, needs attention, or repair. Circle problem and explain below

OK	NG	VISUAL CHECKS
<input type="checkbox"/>	<input type="checkbox"/>	Tires/Wheels: wear, damage, nuts tight
<input type="checkbox"/>	<input type="checkbox"/>	Head/Tail Working Lights: damage, mounting, operation
<input type="checkbox"/>	<input type="checkbox"/>	Gauges/Instruments: damage, operation
<input type="checkbox"/>	<input type="checkbox"/>	Operator Restraint: damage, mounting, operation, oily, dirty
<input type="checkbox"/>	<input type="checkbox"/>	Warning Decals/Operator's Manual: missing, not readable
<input type="checkbox"/>	<input type="checkbox"/>	Data Plate: not readable, missing
<input type="checkbox"/>	<input type="checkbox"/>	Overhead Guard: bent, cracked, loose, missing
<input type="checkbox"/>	<input type="checkbox"/>	Load Back Rest: bent, cracked, loose, missing
<input type="checkbox"/>	<input type="checkbox"/>	Forks: bent, worn, stops OK
<input type="checkbox"/>	<input type="checkbox"/>	Engine Oil: level, dirty, leaks
<input type="checkbox"/>	<input type="checkbox"/>	Hydraulic Oil: level, dirty, leaks
<input type="checkbox"/>	<input type="checkbox"/>	Radiator: fluid level, dirty, leaks
<input type="checkbox"/>	<input type="checkbox"/>	Fuel: level, leaks
<input type="checkbox"/>	<input type="checkbox"/>	Battery: connections loose, charge, electrolyte low
<input type="checkbox"/>	<input type="checkbox"/>	Covers/Sheetmetal: damaged, missing
<input type="checkbox"/>	<input type="checkbox"/>	Brakes: linkage, reservoir fluid level, leaks, debris on floor

OK	NG	OPERATIONAL CHECKS
<input type="checkbox"/>	<input type="checkbox"/>	Engine: runs rough, noisy, leaks
<input type="checkbox"/>	<input type="checkbox"/>	Steering: loose/binding, leaks, operation
<input type="checkbox"/>	<input type="checkbox"/>	Service Brake: linkage loose/binding, stops OK, grab
<input type="checkbox"/>	<input type="checkbox"/>	Parking Brake: loose/binding, operational, adjustment
<input type="checkbox"/>	<input type="checkbox"/>	Seat Brake (if equipped): loose/binding, operational, adjustment
<input type="checkbox"/>	<input type="checkbox"/>	Horn: operation
<input type="checkbox"/>	<input type="checkbox"/>	Backup Alarm (if equipped): mounting, operation
<input type="checkbox"/>	<input type="checkbox"/>	Warning Lights (if equipped): mounting, operation
<input type="checkbox"/>	<input type="checkbox"/>	Lift/Lower: loose/binding, excessive drift, leaks
<input type="checkbox"/>	<input type="checkbox"/>	Tilt: loose/binding, excessive drift, "chatters," leaks
<input type="checkbox"/>	<input type="checkbox"/>	Attachments: mounting, damaged, operation, leaks
<input type="checkbox"/>	<input type="checkbox"/>	Battery Test (electric trucks only): indicator in green while holding full forward tilt
<input type="checkbox"/>	<input type="checkbox"/>	Control Levers: loose/binding, freely return to neutral
<input type="checkbox"/>	<input type="checkbox"/>	Directional Control: loose/binding, find neutral OK

Explanation of problems marked above:

59-770-2937 Jan 1996

How to Perform Planned Maintenance

Visual Inspection

First, perform a visual inspection of the lift truck and its components. Walk around the truck and take note of any obvious damage or maintenance problems.

Check to be sure all capacity, safety, and warning plates are attached and legible.

NOTICE

NAME PLATES AND DECALS: Do not operate a lift truck with damaged or lost decals and nameplates. Replace them immediately. They contain important information.

Inspect the truck, before and after starting the engine, for any sign of external leakage of fuel, engine coolant, transmission fluid, etc.

Check for hydraulic oil leaks and loose fittings.




CAUTION

HYDRAULIC FLUID PRESSURE: Do not use your hands to check for hydraulic leakage. Fluid under pressure can penetrate your skin and cause serious injury.

Overhead Guard

Be sure that the driver's overhead guard and any safety devices are in place, undamaged, and attached securely.

Check the overhead guard for damage. Be sure that it is properly positioned and all mounting fasteners are in place and tight.



Load Handling Components

Inspect the upright assembly, load backrest (LBR), rails, carriage rollers, lift chains, and lift and tilt cylinders. Look for obvious wear and maintenance problems and damaged or missing parts. Check for any loose parts or fittings. Check for leaks, damaged or loose rollers, and rail wear (metal flaking). Carefully check the lift chains for


wear, rust, corrosion, cracked or broken links, stretching, etc. Check that the lift and carriage chains are correctly adjusted to have equal tension. Check that the lift chain anchor fasteners and locking means are in place and tight. Inspect all lift line hydraulic connections for leaks.

IMPORTANT

Uprights and lift chains require special attention and maintenance to remain in safe operating condition. Refer to "Lift Chain Maintenance" in this Section for additional information.

Forks


Inspect the load forks for cracks, breaks, bending, and wear. The fork top surfaces should be level and even with each other. The height difference between both fork tips should be no more than 6mm (0.25in).



WARNING

If the fork blade at the heel is worn down by more than 10 %, the load capacity is reduced and the fork must be replaced.

Inspect the forks for twists and bends. Put a 2"-thick metal block, at least 4" wide by 24" long with parallel sides, on the blade of the fork with the 4" surface against the blade. Put a 24" carpenter's square on the top of the block and against the shank. Check the fork 20" above the blade to make sure it is not bent more than 1" maximum.





If the fork blades are obviously bent or damaged, have them inspected by a trained maintenance person before operating the truck.

Inspect the fork locking pins for cracks or damage. Reinsert them and note whether they fit properly.

Wheels and Tires

Check the condition of the drive and steer wheels and tires. Remove objects that are embedded in the tread. Inspect the tires for excessive wear and breaks or “chunking out.”

Check all wheel lug nuts or bolts to be sure none are loose or missing. Replace missing bolts or lug nuts. Torque loose or replaced items to specifications.




WARNING

Check tire pressure from a position facing the tread of the tire, not from the side. Use a long-handled gauge to keep your body away from the side. If tires are low, do not operate and do not add air. Check with a mechanic. The tire may require removal and repair. Incorrect (low) tire pressure can reduce the stability of your lift truck. Do not operate truck with low tire pressure. Proper cold inflation is 100 psi.

Disassembling the split rim wheel

When you disassemble the split-rim wheel, NEVER remove the tire before you deflate the tire pressure. First, remove the tire pressure and then loosen the wheel bolts and nuts. Failure to do so could result in serious personal injury. This work should be performed only by a trained and authorized mechanic.



Functional Tests

You will start the engine to complete the functional tests, so be sure that:

- The parking brake is applied.
- Directional control is in NEUTRAL.
- Forks are fully lowered to the floor or ground
- All controls are in neutral or other correct position
- You are familiar with the safety procedures given in Section 4, "Operating Procedures," in this manual.

As you test the following components, be sure they are properly mounted and working correctly.

Horn

Press the horn button to check horn function. If the horn or any other part does not operate, report the failure and have it repaired before the truck is put into operation.

Neutral Start Switch

Check the operation of the neutral start switch by placing the direction control lever in FORWARD or REVERSE and turning the key switch to START position. The starter must not engage until the direction control lever is moved to the NEUTRAL position.

Hour Meter

Start the engine and let it warm up until it runs evenly and accelerates smoothly when you push on the accelerator pedal. Check the hour meter for operation with the engine running. Write the hour meter reading on the PM report form. Report any malfunction or damage.

Indicator Lights

Check that all lights are functioning and indicate normal truck operation as described in Section 3, "Operator Compartment and Controls," in this manual.

Service Brakes and Inching Pedal

With the direction control in NEUTRAL and the engine running, push the service brake pedal fully down and hold. The brakes should apply before the pedal reaches the floorplate. If the pedal continues to creep downward, report the failure immediately. **Do not operate the truck until the brakes are repaired.** Perform the same check with the inching pedal. (Additional braking/inching checks will follow.)


Parking Brake

Check the function of the parking brake. Release, then reapply. To check parking brake holding capability, park the lift truck on a grade and apply the parking brake. The parking brake should hold a lift truck with rated load on a 15% grade.



CAUTION

Do not operate a lift truck if the service or parking brakes are not operating properly.



Lift Mechanisms and Controls


Pull back on the tilt control lever and hold until the upright reaches the full back tilt position. Push forward on the lever to return the upright to the vertical position. Release the lever.



CAUTION

Be sure that there is adequate overhead clearance before raising the upright.

Pull back on the lift control lever and raise the fork carriage to full height. Watch the upright assembly as it rises. Release the lever.



If the maximum fork height is not reached, this indicates there is an inadequate (low) oil level in the hydraulic sump tank or severe binding within the upright.

Push forward on the lift control lever. Watch the upright as it lowers. When the forks reach the floor, release the lever.

All movements of the upright, fork carriage, and lift chains must be even and smooth, without binding or jerking. Watch for chain wobble or looseness; the chains should have equal tension and move smoothly without noticeable wobble.

Auxiliary Controls (Option)

If your lift truck is equipped with an attachment, test the control lever for correct function and briefly operate the attachment.

Steering System

NOTICE

The steering system, steer axle, and steering linkage on your truck should be inspected periodically for abnormal looseness and damage, leaking seals, etc. Also, be alert for any changes in steering action. Hard steering, excessive freeplay (looseness), or unusual sound when turning or maneuvering indicates a need for inspection or servicing.

Check the steering system by moving the steering handwheel in a full right turn and then in a full left turn. Return the handwheel to the straight-ahead position. The steering system components should operate smoothly when the handwheel is turned. **Never operate a truck that has a steering system fault.**



WARNING

Fasten your seat belt before driving the truck.

Direction Control, Braking, and Inching

Be sure that the travel area is clear in front of the truck.

1. Push firmly on the brake pedal. Release the parking brake. Move the directional control lever from NEUTRAL to FORWARD.



2. Remove your right foot from the service brake pedal and put it on the accelerator pedal. Push down until the truck moves slowly forward. Remove your foot from the accelerator pedal and push down on the service brake pedal to stop the truck. The brakes should apply smoothly and equally.

Be sure the travel area is clear behind the truck.

3. Put the directional control lever in the REVERSE travel position. Release the service brake and push down on the accelerator pedal until the truck moves slowly in the reverse direction. Remove your foot from the accelerator pedal and push down on the service brake pedal to stop the truck. The brakes should apply smoothly and equally.
4. Put the directional control in FORWARD. Press the inching pedal fully down and hold. Depress the accelerator. The truck should not move. Now, with the accelerator still depressed, slowly release the inching pedal until the truck "inches" forward smoothly and slowly.

Report any problems.

When you have completed the operational tests, park and leave the truck according to standard shut down procedure as described in Section 4 of this manual. Be sure to make a record of all maintenance and operating problems you find.

Fluids, Filters, and Engine Accessories

To check fluid levels and other components within the engine compartment, unlatch and open the hood to access the engine compartment.



CAUTION

To avoid the possibility of personal injury, never work in the engine compartment with the engine running, except when it is absolutely necessary to check or make adjustments. Take extreme care to keep hands, tools, loose clothing, etc., away from fan and drive belts. Also remove watches, bracelets, and rings.

Engine Accessories

Inspect the engine coolant hoses and fan belt(s). Look for leaking and obvious damage, worn (frayed) condition, breaks, etc. that could cause failure during operation.

Engine Air Cleaner

Check the engine air cleaner for damage and contamination (excessive dirt buildup and clogging). Be sure that the air cleaner hose is securely connected (not loose or leaking). Fan or cone shaped dust deposits on tube or hose surfaces indicate a leak.

Change or service the air cleaner element every 2000 operating hours for gas engine, every 1000 operating hours for diesel engine, depending upon your application. Service intervals may also be determined by the air restriction indicator.

Battery

Inspect the battery for damage, cracks, leaking condition, etc. If the terminals are corroded, clean and protect them with CLARK Battery Saver (available from your CLARK dealer). If your battery has removable cell caps, check to be sure the cells are all filled. Refill them with distilled water.



WARNING

EXPLOSIVE GASES: Do not smoke or have open flames or sparks near batteries. An explosion can cause injury or death.

Engine Cooling System

To check engine coolant level open the hood to the engine compartment. Visually inspect the recovery bottle, locate the "HOT" and "COLD" marks. The "HOT" mark indicates maximum level at operating temperature. The "COLD" mark indicates additional coolant needs to be added to the system.

IMPORTANT


The recovery bottle shown is a typical illustration of overflow system. Your actual system may vary slightly.

IMPORTANT

A level anywhere between the HOT and COLD marks is normal.

IMPORTANT

Inspect the coolant level in the overflow bottle only.



WARNING

Do not remove the radiator cap when the radiator is hot. STEAM from the radiator will cause severe burns. Do not remove the radiator cap to check the coolant level.

WARNING

Never remove the radiator cap while the engine is running. Stop the engine and wait until it has cooled. Failure to do so could result in serious personal injury from hot coolant or steam blowout and/or damage to the cooling system or engine.

If the level is low, add a 50/50 mixture of specified coolant and water to the correct fill level. If you have to add coolant more than once a month or if you have to add more than one quart at a time, check the coolant system for leaks.

- Check engine oil for presence of coolant leaking into engine.
- Inspect the coolant for condition. Look for excessive contamination or rust or oil in the coolant solution.
- Check the PM time interval for need to change coolant.
- Check the condition of radiator cap rubber seal and radiator filler neck for damage. Be sure they are clean.
- Check overflow hose for clogging or damage.

NOTICE

Your lift truck cooling system is filled with a factory-installed solution of 50% water and 50% permanent-type antifreeze containing rust and corrosion inhibitors. You should leave the solution in year around. Plain water may be used in an emergency, but replace it with the specified coolant as soon as possible to avoid damage to the system. Do not use alcohol or methanol antifreeze.

Engine Oil and Filter

Locate the engine oil dipstick. Pull the dipstick out, wipe it with a clean wiper, and reinsert it fully into the dipstick tube. Remove the dipstick and check oil level.

It is normal to add some oil between oil changes. Keep the oil level above the ADD mark on the dipstick by adding oil as required. Do not overfill. Use the correct oil as specified under Lubricant Specifications.

It is recommended to:

- Drain and replace the engine crankcase oil every 50 to 250 operating hours. (depending on application). See NOTICE
- Engine Oil Filter must be changed at every PM when the oil is changed.
- Remove the oil pan drain plug to drain old oil after the truck has been in operation and the engine (oil) is at operating temperature.

**WARNING**

Engine oil at operating temperature is hot and can cause burns. Beware of splashing oil.

- Carefully check for leaks after changing oil and installing new filter.

NOTICE

The time interval for changing engine oil depends upon your application and operating conditions. To determine the correct schedule for your truck, it is suggested that you periodically submit engine oil samples to a commercial laboratory for analysis of the condition of the oil.

OIL PERFORMANCE DESIGNATION: To help achieve proper engine performance and durability, use only engine lubricating oils of the proper quality. For gas engines, CLARK recommends that you use motor oil that meets API Service Classification SD, SE/SG, SF and SAE 10W-30. For diesel engines, CLARK recommends that you use motor oil that meets API Service Classification CD, CF-4 and SAE 15W-40.

Hydraulic Sump Tank

Check the hydraulic sump tank fluid level. Correct fluid level is important for proper system operation. Low fluid level can cause pump damage. Overfilling can cause loss of fluid or lift system malfunction.

Hydraulic fluid expands as its temperature rises. Therefore, it is preferable to check the fluid level at operating temperature (after approximately 30 minutes of truck operation). To check the fluid level, first park the truck on a level surface and apply the parking brake. Put the upright in a vertical position and lower the fork carriage fully down. Pull the dipstick out, (attached to the sump breather) wipe it with a clean wiper, and reinsert it. Remove dipstick and check oil level. Keep the oil level above the LOW mark on the dipstick by adding recommended hydraulic fluid only, as required. **Do not overfill.**

Check the condition of the hydraulic fluid (age, color or clarity, contamination). Change (replace) the oil as necessary.

Hydraulic Fluid and Filter Change

Drain and replace the hydraulic sump fluid every 2000 operating hours. (Severe service or adverse conditions may require more frequent fluid change). Replace the hydraulic oil filter elements at every oil change. Remove, clean, and reinstall the hydraulic and steer system suction line screens at first PM and every 500 hours thereafter. Check for leaks after installation of the filters. Also, check that the hydraulic line connections at the filter adapter are tightened correctly. The procedure for draining hydraulic sump tank is in your Service Manual.

Sump Tank Breather Maintenance and Inspection

Remove the sump tank fill cap/breather and inspect for excessive (obvious) contamination and damage. Replace the fill cap/breather, per recommended PM schedule or as required by operating conditions.

Transaxle Fluid Check

Before checking, run the engine until the unit is at operating temperature. This is important since transmission oil temperature should be minimum of 65°C (150°F) to 121°C(250°F) maximum, the engine should also be at operating temperature. Apply the parking brake.

With the engine operating at idle and the transmission in NEUTRAL, and the parking brake set, check the fluid on the dipstick. Fill, if necessary, to the FULL mark on the dipstick, using CLARK transmission fluid. If unable to determine actual oil temperature, use this alternate check method: With the unit cold, start and run the engine at idle for 30 seconds then check the level and fill only to the add mark.

NOTICE

Check the planned maintenance interval (operating hours) or the condition of the oil to determine if the transaxle fluid needs to be changed.

Lubrication

Truck Chassis Inspection and Lubrication

Lubrication and inspection of truck chassis components, including steer wheels, steer axle linkage, steering cylinder, and wheel bearings are easier if the truck is raised and blocked up under the frame. Refer to your Service Manual for additional information on machine blocking and jacking. Also refer to your Service Manual for the location of grease fittings.



WARNING

Do not raise the truck by lifting under the counterweight.

Inspect the steering cylinder piston rods, seals, and fasteners for damage, leaks, and looseness. Lubricate the steer axle linkage rod ends and linkage pivot points. Be sure to clean the grease fittings before lubricating, and remove the excess grease from all points after lubricating. Lubricate miscellaneous linkage as needed.

Upright and Tilt Cylinder Lubrication

Clean the fittings and lubricate the tilt cylinder rod end bushings (forward end) and both the base rod-end bushings (rear end). Clean and lubricate the upright trunnion bushings.

Lift Chains

Lubricate the entire length of the upright rail lift and carriage chains with CLARK Chain and Cable Lube.

IMPORTANT

Do not lubricate the carriage roller rails.

Air Cleaning

Always maintain a lift truck in a clean condition. Do not allow dirt, dust, lint, or other contaminants to accumulate on the truck. Keep the truck free from leaking oil and grease. Wipe up all oil spills. Keep the controls and floorboards clean, dry, and safe. A clean truck makes it easier to see leakage and loose, missing, or damaged parts, and helps prevent fires. A clean truck runs cooler. The environment in which a lift truck operates determines how often and to what extent cleaning is necessary.

For example, trucks operating in manufacturing plants that have a high level of dirt, dust, or lint (for example, cotton fibers or paper dust) in the air or on the floor or ground, require more frequent cleaning. The radiator especially may require daily air cleaning to ensure correct cooling. If air pressure does not remove heavy deposits of grease, oil, etc., it may be necessary to use steam or liquid spray cleaner.

IMPORTANT

Lift trucks should be air cleaned at every PM interval, or more often if necessary.

Use an air hose with special adapter or extension, a control valve, and a nozzle to direct the air properly. Use clean, dry, low pressure, compressed air. Restrict air pressure to 30 psi (207 kPa), maximum. (OSHA requirement.)



CAUTION

Wear suitable eye protection and protective clothing when air cleaning. Never point the air nozzle at anyone.

Air clean the upright assembly, drive axle, radiator—from both counterweight and engine side, engine and accessories, driveline and related components, and steer axle and cylinder.

Critical Fastener Torque Checks

Fasteners in highly loaded (critical) components can quickly fail if they become loosened. Also, loose fasteners can cause damage or failure of the component. For safety, it is important that the correct torque be maintained on all critical fasteners of components that directly support, handle, or control the load and protect the operator.

Critical items include:

- Drive axle mounting
- Overhead guard
- Drive and steer wheel mounting
- Tilt cylinder mounting and yokes
- Counterweight mounting
- Upright mounting and components

Torque specifications are in your Service Manual.

Lift Chain Maintenance

The chain system on the upright was designed for safe, efficient, and reliable transmission of lifting force from hydraulic cylinder to the forks. Safe use of your truck with minimum down-time depends on the correct care and maintenance of the lift chains. Most complaints of unacceptable chain performance are a result of poor maintenance. Chains need periodic maintenance to give maximum service life.



WARNING

Do not attempt to repair a worn chain. Replace worn or damaged chains. Do not piece chains together.

Lift Chain Inspection and Measurement

Inspect and lubricate the lift chains every PM (50-250 hours). When operating in corrosive environments, inspect the chains every 50 hours. During the inspection, check for the following conditions:


- Rust and corrosion, cracked plates, raised or turned pins, tight joints, wear, and worn pins or holes.
- When the pins or holes become worn, the chain becomes longer. When a section of chain is 3% longer than a section of new chain, the chain is worn and must be discarded.
- Chain wear can be measured by using a chain scale or a steel tape measure. When checking chain wear, be sure to measure a segment of chain that moves over a sheave. Do not repair chains by cutting out the worn section and joining in a new piece. If part of a chain is worn, replace all the chains on a truck.

Lift Chain Lubrication

Lift chain lubrication is an important part of your maintenance program. The lift chains operate under heavy loadings and function more safely and have longer life if they are regularly and correctly lubricated. CLARK chain lubricant is recommended; it is easily sprayed on and provides superior lubrication. Heavy motor oil may also be used as a lubricant and corrosion inhibitor.

Lift Chain Wear and Replacement Criteria:

1. (NEW CHAIN LENGTH) The distance from the first pin counted to the last pin counted in a span while the chains are lifting a small load.
2. (WORN CHAIN LENGTH) The distance from the first pin counted to the last pin counted in a span while the chains are lifting a small load.



3. (SPAN) The number of pins in the length (segment) of chain to be measured.
4. (PITCH) The distance from the center of one pin to the center of the next pin.

All chains must be replaced if any link has wear of 3% or more, or if any of the damaged conditions noted above are found during inspection. Order replacement chains from your CLARK dealer. Replace all chains as a set. Do not remove factory lubrication or paint new chains. Replace anchor pins and worn or broken anchors when installing new chains. Adjust tension on new chains. Lubricate chains when they are installed on the upright.

NOTICE

Please refer to your Service Manual for additional information on lift chain measurement and maintenance.



Specifications

Contents

CMC15-20S, CMP15-75S	8-2
CGC/CGP/CDP	8-6
CGC/CGP/CDP Hydrostatic	8-11
Engine Oil	8-13



CMC15-20S, CMP15-75S

Clark products and specifications are subject to improvements and changes without notice or obligation.

Model Designation - Rated Load Capacity

CMC 15	1360kg @600mm load center	[3,000lbs@24in]	[1500kg@500mm]
CMC 18	1590kg @600mm load center	[3,500lbs@24in]	[1800kg@500mm]
CMC 20S	1810kg @600mm load center	[4,000lbs@24in]	[2000kg@500mm]
CMP 15	1360kg @600mm load center	[3,000lbs@24in]	[1500kg@500mm]
CMP 18	1590kg @600mm load center	[3,500lbs@24in]	[1800kg@500mm]
CMP 20S	1810kg @600mm load center	[4,000lbs@24in]	[2000kg@500mm]
CMP 20	1810kg @600mm load center	[4,000lbs@24in]	[2000kg@500mm]
CMP 25	2270kg @600mm load center	[5,000lbs@24in]	[2500kg@500mm]
CMP 30	2720kg @600mm load center	[6,000lbs@24in]	[3000kg@500mm]
CMP 40	3630kg @600mm load center	[8,000lbs@24in]	[4000kg@500mm]
CMP 45	4080kg @600mm load center	[9,000lbs@24in]	[4500kg@500mm]
CMP 50S	4530kg @600mm load center	[10,000lbs@24in]	[5000kg@500mm]
CMP 50	5000kg @600mm load center	[11,000lbs@24in]	
CMP 60	6000kg @600mm load center	[13,500lbs@24in]	
CMP 70	7000kg @600mm load center	[15,500lbs@24in]	
CMP 75S	7500kg @600mm load center	[16,500lbs@24in]	

Note: Rated capacity applies when using uprights.

Engine, Gas/LPG (Models CMC15-20S, CMP 15-20S)

Model Mitsubishi	4G63
Cylinders	4
Liters	2.0
Engine speed +/- 50 @	
Idle.....	800
No Load.....	2600
Full Load.....	2300

Engine, Gas/LPG(Models CMP 20, 25, 30)

Model Mitsubishi	4G64
Cylinders	4
Liters	2.4
Engine speed +/- 50 @	
Idle	800
No Load.....	2600
Full Load	2100

Engine, LPG(Models CMP 40, 45, 50S, 50, 60, 70, 75S)

Model GM.....	V6
Cylinders	6
Liters	4.3
Engine speed +/- 50 @	
Idle	750
No Load.....	2650
Full Load	2000

Engine, Diesel (Models CMP 20, 25, 30)

Model Yanmar.....	4TNE 94
Cylinders	4
Liters	2.8
Engine speed +/- 50 @	
Idle	750
No Load	2700
Full Load	2500

Engine, Diesel (Models CMP 40, 45, 50S, 50, 60, 70, 75S)

Model Perkins	1004-42
Cylinders	4
Liters	4.2
Engine speed +/- 50 @	
Idle	750
No Load	2400
Full Load	2200

Cooling System

Automotive type crossflow radiator.
(See Service Manual)

Powershift Transmission (See Service Manual)

Drive Axle (See Service Manual)

Wheels and Tires

<i>Drive:</i> CMC 15/18	18 x 7 x 12 1/8	
CMC 20S	18 x 8 x 12 1/8	
CMP 15/18/20S	6.5 x 10,	12 ply rating
CMP 20/25	7 x 12,	14 ply rating
CMP 30	8.15 x 15,	14 ply rating
CMP 40 (Single)	8.25 x 15,	14 ply rating
(Duals)	7.5 x 15,	12 ply rating
CMP 45 (Single)	8.25 x 15,	16 ply rating
(Duals)	7.5 x 15,	12 ply rating
CMP 50S (Single)	300 x 15,	18 ply rating
(Duals)	7.5 x 15,	12 ply rating
CMP 50/60/70/75S	8.15 x 15,	14 ply rating
<i>Steer:</i> CMC 15/18/20S	16 x 5 x 10 1/2	
CMP 15/18	5 x 8 ,	8 ply rating
CMP 20S	5 x 8 ,	10 ply rating
CMP 20/25/30	6.5 x 10,	12 ply rating
CMP 40/45/50S	7 x 12,	14 ply rating
CMP 50/60/70/75S	8.15 x 15,	14 ply rating

Standard Electrical System

Type: 12 volt DC, negative ground

Fuses: 15 amps (in-line)

Fuel Recommendations

Diesel: D-2 with cetane rating of 45 or higher. D-1 and Jet A-1 also acceptable.

Gasoline: 87 octane minimum

LPG: HD-5 propane

Fill Capacities (fluid volumes - liters, quarts, gallons)

	Cooling system	Eng. oil, w/filter	Transaxle	Hydraulic sump
CMC15-20S	8.5L [9.0Q]	4.8L [5.1Q]	12L [12.7Q]	25L [6.5G]
CMP15-20S	8.5L [9.0Q]	4.8L [5.1Q]	12L [12.7Q]	31L [8G]
CMP20-30	8.5L [9.0Q]	4.8L [5.1Q]	16L [17.0Q]	38L [10G]
CMP20-30D	11L [11.6Q]	7.5L [8.0Q]	16L [17.0Q]	38L [10G]
CMP40-50S	17L [18.0Q]	6.6L [7.0Q]	19L [20.0Q]	64L [17G]
CMP40-50SLPG	17L [18.0Q]	5.0L [5.3Q]	19L [20.0Q]	64L [17G]
CMP50-75S	25L [26.4Q]	6.6L [7.0Q]	7.5L [7.9Q]	110L [29G]
CMP50-75SLPG	25L [26.4Q]	5.0L [5.3Q]	7.5L [7.9Q]	110L [29G]

Truck Weights (approximate, with cutoff height upright)

	Empty Vehicle Weight (kg/lbs)	Loaded Drive Axle (kg/lbs)	Loaded Steer Axle (kg/lbs)
CMC 15-20S LPG			
CMC 15	2810 [6200]	3680 [8110]	630 [1390]
CMC 18	3010 [6640]	4140 [9130]	670 [1475]
CMC 20S	3160 [6970]	4240 [9347]	720 [1590]
CMP 15-20S Gas & LPG			
CMP 15	2690 [5930]	3606 [7950]	445 [980]
CMP 18	2817 [6210]	3878 [8550]	526 [1160]
CMP 20S	3070 [6770]	4390 [9680]	680 [1500]
CMP 20-30 Gas & LPG			
CMP 20	3515 [7750]	4755 [10485]	760 [1675]
CMP 25	3745 [8255]	5545 [12225]	700 [1545]
CMP 30	4185 [9225]	6305 [13900]	880 [1940]
CMP 20-30 Diesel			
CMP 20	3560 [7850]	4850 [10700]	710 [1565]
CMP 25	3790 [8350]	5580 [12300]	700 [1545]
CMP 30	4200 [9260]	6360 [14020]	840 [1850]
CMP 40-50S Diesel & LPG			
CMP 40	5990 [13205]	8365 [18440]	1125 [2480]
CMP 45	6300 [13890]	9120 [20105]	1180 [2600]
CMP 50S	6900 [15210]	10265 [22630]	1135 [2500]
CMP 50-75S Diesel & LPG			
CMP 50	8430 [18585]	11935 [26310]	1495 [3295]
CMP 60	8990 [19820]	13375 [29490]	1615 [3560]
CMP 70	9620 [21210]	14815 [32660]	1805 [3980]
CMP 75S	9800 [21600]	15960 [35190]	1370 [3020]

Clark products and specifications are subject to improvements and changes without notice or obligation

Model Designation-Rated Load Capacity

CGC/CGP/CDP	20 (D)	-4,000 lbs	@ 24in load center	[2000 kg]	@ [500mm]
CGC/CGP/CDP	25 (D)	-5,000 lbs	@ 24in load center	[2500 kg]	@ [500mm]
CGC/CGP/CDP	30 (D)	-6,000 lbs	@ 24in load center	[3000 kg]	@ [500mm]
CGC/CGP/CDP	40 (D)	-8,000 lbs	@ 24in load center	[4000 kg]	@ [500mm]
CGP/CDP	45 (D)	-9,000 lbs	@ 24in load center	[4500 kg]	@ [500mm]
CGC/CGP/CDP	50 (D)	-10,000lbs	@ 24in load center	[5000 kg]	@ [500mm]
CGC/CGP/CDP	55 (D)	-11,000lbs	@ 24in load center	[5500 kg]	@ [500mm]
CGC/CDC	60(D)	-13,500lbs	@ 24in load center	[6000 kg]	@ [500mm]
CGC/CDC	70(D)	-15,500lbs	@ 24in load center	[7000 kg]	@ [500mm]

Note: Rated capacity applies when using uprights with maximum MFH up to and including: 152 Inches [3861mm]

Engine

(Models CGC/CGP/CDP 20, 25, 30, 32, 35)

	<i>Diesel</i>	<i>Diesel</i>	<i>Gas</i>	<i>LPG/CNG</i>
Model Mitsubishi:	S4S	704-30	4G64	4G64
Cylinders:	4	4	4	4
Displacement				
<i>cubic inches:</i>	201	181	146	146
<i>liters:</i>	3.3	3.0	2.4	2.4
Idle RPM	650-750	750	650-750	650-750
Governed RPM				
<i>No load @ high idle:</i>	2700	2600	2600	2600
<i>Full load:</i>	2700	2400	2600	2600
				<i>LPG</i>
Model GM:				3.0
Cylinders:				4
Displacement				
<i>cubic inches:</i>				181
<i>liters:</i>				3.0
Idle RPM:				750-800
Governed RPM				
<i>No load @ high idle:</i>				2550-2650
<i>Full load:</i>				2400



CGC/CGP/CDP

(Models CGC/CGP/CDP 40, 45, 50, 55, 60, 70)

	Diesel	Diesel	Gas	LPG
Model Perkins:	1004	1004.42		
Model GM			V6	V6
Cylinders	4	4	6	6
Displacement				
<i>cubic inches</i>	243	258	262	262
<i>liters</i>	4.0	4.2	4.3	4.3
Idle RPM	650-750	650-750	650-750	650-750
Governed RPM				
<i>No load @ high idle</i>	2540	2400	2650	2650
<i>Fullload</i>	2400	2200	2500	2500

Cooling System**(Models CGC/CGP/CDP 20, 25, 30, 32, 35)**

Automotive type crossflow radiator.

Cooling system pressure (radiator cap): 90 kPa nominal, 13psi

Thermostat: Diesel, 85°C (185°F), fully open 98°C (208°F),

Gas/CNG/LPG 83°C (182°F), fully open 96°C (205°F)

(Models CGC/CGP/CDP 40, 45, 50, 55, 60, 70)

Automotive type crossflow radiator.

Cooling system pressure (radiator cap): 48 kPa nominal, 7 psi

Thermostat: Diesel, 82°C (185°F), fully open 95°C (203°F),

Gas/CNG/LPG 88°C (190°F), fully open 96°C (205°F)

Powershift Transmission**(Models CGC/CGP/CDP 20, 25, 30)**

CLARK Model TA-30 Transaxle

Speeds: 1 forward /1 reverse

Overall Ratios: FWD/15.76 :1 REV/11.063:1

Convertor Stall Ratio: 3.24:1

(Models CGC 40, 50, 55)

CLARK Model H-200 Transaxle, Single Speed

Speeds: 1 forward/1 reverse

Overall Ratios: FWD/13.188 :1 REV/12.436 :1

Convertor Stall Ratio: 2.08:1



(Models CGP/CDP 40, 45, 50, 55)

CLARK Model H-200 Transaxle

Speeds:	2 forward /2 reverse	
Overall Ratios (HIGH):	FWD/15.938 :1	REV/15.026:1
(LOW):	FWD/31.13:1	REV/29.338:1
Convertor Stall Ratio:	2.08:1	

TA-30 Drive Axle

Full floating straight drive axle. 2 pinion differential w/hydraulic shoe brakes.

HR-200

2 pinion differential, 3 piston Disc Brakes

Wheels and Tires for Pneumatic Truck

<i>Drive</i>	CGP/CDP 20/25	Single: 7.00 X 12,	14-ply rating
<i>Tires:</i>		Dual: 7.00 X 12,	14-ply rating
	CGP/CDP 30/35	Single: 28 X 9 X 15	14-ply rating
		Dual: 7.00 X 12,	14-ply rating
	CGP/CDP 40/45	Single: 250 X 15,	16-ply rating
		Dual: 250 X 15,	16-ply rating
	CGP/CDP 50/55	Single: 300 X 15,	20-ply rating
		Dual: 250 X 15,	16-ply rating
<i>Steer:</i>	CGP/CDP 20/25	6.00 X 9,	10-ply rating
	CGP/CDP 30/35	6.50 X 10	10-ply rating
	CGP/CDP 40/45	7.00 X 12	12-ply rating
	CGP/CDP 50/55	7.00 X 12	12-ply rating

Tire Pressures:

<i>Drive:</i>	CGP/CDP 20/25	Single: 862 kPa	(125psi)
		Dual: 862 kPa	(125psi)
	CGP/CDP 30/35	Single: 862 kPa	(125psi)
		Dual: 862 kPa	(125psi)
	CGP/CDP 40/55	Single: 931 kPa	(135psi)
		Dual: 931 kPa	(135psi)
<i>Steer:</i>	CGP/CDP 20/25	862 kPa	(125psi)
	CGP/CDP 30/35		

Wheels and Tires for Cushion Truck

	<i>Drive:</i>	<i>Steer:</i>
CGC 20-25	21 X 7 X 15	16 X 5 X 10.5
CGC 30	21 X 8 X 15	16 X 6 X 10.5
CGC 40	22 X 9 X 16	18 X 6 X 12.12
CGC 50-55	22 X 12 X 16	22 X 7 X 16
CGC 60-70	22 X 14 X 16	22 X 8 X 16

Standard Electrical System

Type: 12 volt DC, negative ground

Fuses: 5, 15 amps

Batteries:

*BCI Group 45**BCI Group 31*

Gas, LPG

Diesel

Cold cranking current

12 volt DC-420 amps 12 volt DC-625 amps

@ 0°F total

Filters

Engine air:

Dry type—replaceable element

Engine oil:

Spin-on

Transmission:

Spin-on

Hydraulic system oil:

100 mesh suction screen in sump tank and filter in return line-B10=5.0;
(used for steering and brake system)

Hydraulic sump

breather cap:

Replaceable element

Use genuine CLARK parts. See your CLARK dealer.

Truck Weights (approximate, with cutoff height upright)

	Gross Vehicle Weight (lbs)	Empty Vehicle Weight (lbs)	Loaded Drive Axle (lbs)	Empty Drive Axle (lbs)
CGC 20	11720	7741	10127	3210
CGC 25	13749	8635	11793	3001
CGC 30	15356	9356	13241	2816
CGC 32	16145	9745	13770	2940
CGC 40	20921	12921	18429	5084
CGC 50	24852	14852	22431	6504
CGC 55	28881	16881	25942	6720
CGC 60	32309	18809	28922	7804
CGC 70	36359	20859	32415	8173
CGP 20	11617	7617	10314	3687
CGP 25	13466	8466	11810	3526
CGP 30	15262	9262	13393	3452
CGP 35	17252	10252	15984	3814
CDC 60	32309	18809	28922	7804
CDC 70	36359	20859	32415	8173
CDP 20	11837	7837	10399	3771
CDP 25	13686	8686	11895	3611
CDP 30	15482	9482	13478	3537
CDP 35	17472	10472	16138	3902



Truck Weights (approximate, with cutoff height upright)

	Gross Vehicle Weight (lbs)	Empty Vehicle Weight (lbs)	Loaded Drive Axle (lbs)	Empty Drive Axle (lbs)
CGP 40	20881	12881	18925	6036
CGP 45	22675	13675	20475	5974
CGP 50	25201	15201	23865	6636
CGP 55	27083	16083	24041	6592
CDP 40	20881	12881	18925	6036
CDP 45	22675	13675	20475	5974
CDP 50	25201	15201	23865	6636
CDP 55	27083	16083	24041	6592

NEW SHEET



Fuel Recommendations

Diesel: D-2 with cetane rating of 45 or higher. D-1 and Jet A-1 also acceptable.

Gasoline: 87 octane minimum

LPG: HD-5 propane

Fill Capacities (fluid volumes)

Fuel tank:	20/35	14.8 US gallons;	56 liters
	40/60	18.7 US Gallons	70.8 liters
Cooling system:	CGC	6.3 quarts;	6 liters
	CGP	8 quarts;	7.5 liters
	CDP	10.6 quarts;	10 liters

(Mitsubishi)

Engine oil, w/filter (diesel):	10.6 quarts;	10 liters
Engine oil, w/filter (gas):	4.5 quarts	4.3 liters

(Perkins)

Engine oil, w/filter (1004.42 diesel):	8.0 quarts;	7.6 liters
--	-------------	------------

(GM 4.3)

Engine oil, w/filter (gas):	5.0 quarts	4.7 liters
-----------------------------	------------	------------

(GM 3.0)

Engine oil, w/filter (gas):	5.0 quarts	4.7 liters
-----------------------------	------------	------------

Transaxle:

	TA-30	15 quarts;	14.2 liters
	H-200	15 quarts;	14.2 liters
Hyd Sump: (Usable Volume)	CGC 20/30	5.1 US gallons;	19.3 liters
	CGP 20/35	11.6 US gallons;	44 liters
	CGP 40/55	16.9 US gallons;	63.8 liters

Engine Coolant Recommendation

Use a mixture of 50% ethylene glycol permanent-type antifreeze containing rust and corrosion inhibitors only. **Note:** This mixture provides antifreeze protection level of -37°C (-34°F), approximately.

Transmission Fluid Recommendation

Use CLARK Transmission Fluid.

Hydraulic Fluid Recommendation

Use CLARK Specification MS-68 Hydraulic Oil, with anti-wear additives, or equivalent, only.



Model Designation — Rated Load Capacity

CGC/CGP/CDP 20(H)-4,000 lbs @24in load center [2000 kg] @[500mm]

CGC/CGP/CDP 25(H)-5,000 lbs @24in load center [2500 kg] @[500mm]

CGC/CGP/CDP 30(H)-6,000 lbs @24in load center [3000 kg] @[500mm]

Note: Rated capacity applies when using uprights with maximum MFH up to and including: 152 Inches [3861mm]

Engine	Diesel	Gas	LPG
Model Mitsubishi:	S4S	4G64	4G64
Cylinders:	4	4	4
Displacement			
<i>cubic inches:</i>	201	146	146
<i>liters:</i>	3.3	2.4	2.4
Idle RPM:	650-700	650-700	650-700
Governed RPM			
<i>No load @ high idle:</i>	2600	2600	2600
<i>Full load:</i>	2220	1850	1850

Cooling System

Automotive type crossflow radiator.

Cooling system pressure (radiator cap): 90 kPa nominal, 13psi

Thermostat: Diesel, 85°C (185°F), fully open 98°C (208°F),

Gas/LPG 83°C (182°F), fully open 96°C (205°F)

Hydrostatic Pump

Sauer-Sundstrand Series 90 axial piston, variable displacement unit
CDP/CGP20-35H: Maximum Displacement: 75 cm³/rev (4.57 in 3/rev)

Maximum Pressure: 480 bar (7,000 psi)

Rated Pressure: 420 bar (6,000 psi)

Drive Axle

Drive axle constructed with integral Rexroth radial piston hydraulic motors and hydraulic shoe brakes.

CDP/CGP20-35: Motor Displacement: 2 x 565 cm³/rev (2 x 34.5 in 3/rev)

Maximum Pressure: 450 bar (6,500 psi)

Rated Pressure: 450 bar (6,500 psi)




Truck Weights lbs./kg (approximate, with cutoff height upright)

	<i>Gross Vehicle Weight</i>	<i>Empty Vehicle Weight</i>	<i>Loaded Drive Axle</i>	<i>Empty Drive Axle</i>
CGC 20H	11385 [5165]	7385 [3350]	9875 [4480]	3000 [1360]
CGC 25H	13230 [6000]	8230 [3733]	11360 [5152]	2770 [1256]
CGC 30H	15120 [6860]	9120 [4136]	12930 [5865]	2625 [1190]
CGP 20H	11694 [5490]	7694 [3490]	10803 [4900]	3351 [1520]
CGP 25H	13466 [6340]	8466 [3840]	12280 [5570]	3527 [1600]
CGP 30H	15259 [7200]	9259 [4200]	13955 [6330]	3450 [1565]
CDP 20H	11782 [5530]	7782 [3530]	11001 [4990]	3395 [1540]
CDP 25H	13686 [6440]	8686 [3940]	12370 [5610]	3616 [1640]
CDP 30H	15480 [7300]	9480 [4300]	14043 [6370]	3527 [1600]

Note: All other specifications are the same as the non-hydrostatic CGC/CGP/CDP outlined on previous pages in this section.

Engine Oil

Use these SAE viscosity grades.



Engine Oil Recommendations

American Petroleum Institute (API) classifications CD, CC/SG, SF and API CF-4 SAE 15W-40, gas engines can also use API SD SAE 10W-30 oil or better.

IMPORTANT

Do not extend oil change intervals from those specified when using synthetic lubricants.

Fill crankcase with correct amount of oil. When adding oil between oil changes, it is preferable to use the same brand as various oils may be incompatible. Refer to the Maintenance and Lubrication Section for recommended oil change intervals.

IMPORTANT

Do not overfill crankcase. Excess oil causes foaming and can cause loss of lubrication and higher operating temperatures, resulting in engine damage.

Index

- A**
A Message to CLARK Lift Truck Operators ii
Adjusting the Load Forks 4-10
Adjusting the Seat 4-4
After Operating the Truck 4-16
Air Cleaning 7-26
Auto Choke Control (Gasoline Only) 3-18
Auxiliary Control Lever (Optional) 3-17
Auxiliary Controls (Option) 7-19
- B**
Battery 7-21
Before Operating the Truck 4-2
Brake Pedals 3-16
Brake Pedals/Pedals 3-12
Braking 4-6
Buckling Up 4-4
- C**
CGC/CGP 3-8
CGC/CGP/CDP 8-6
CGC/CGP/CDP Hydrostatic 8-6
CGC/CGP Dash Pod Symbols .. 3-9
CMC15-20S, CMP15-75S 8-2
CGC/CGP Hydrostatic Controls 3-12
Chain Slack 2-7
Checks 7-27
Cooling System 8-3
Cold Start Preheating (Diesel Only) 3-11
Concluding the Inspection 5-4
Controlling Speed 4-6
Critical Fastener Torque Checks 7-27
CGC/CGP Hydrostatic Operators Compartment 3-10
CGC/CGP Operators Compartment 3-7
CMC/CMP Instrument Panel 3-4
CMC/CMP Instrument Panel Symbols 3-5
CMC/CMP Operator Compartment 3-3
CMP 50,60,70,75S EGS 3-6
Cold Start Preheating (Diesel Only) 3-14
- D**
Daily Inspection 1-2
Dash Pod Display 3-8
Direction Control Lever 3-16
Daily Safety Inspection 5-2
Direction Control, Braking, and Inching 7-19
Disassembling the split rim wheel 7-17
Do's and Don'ts 1-3
Drop-Offs 2-5
- E**
Engine 8-6
Engine Accessories 7-21
Engine Air Cleaner 7-21
Engine Coolant Recommendation 8-10
Engine Cooling System 7-21
Engine Oil 8-13
Electronic Gear Shift (E.G.S.) 3-6
Engine Oil and Filter 7-23
Engine Oil Recommendations 8-13
Engine Stop 3-14
Extreme Operation 7-9
- F**
Fill Capacities 8-4
Fluids, Filters, and Engine Accessories 7-20
Fork Safety 1-8
Forks 7-15
Fuel Recommendations 8-4
Fuel Safety Practices 5-5
Functional Checks 5-4
Functional Tests 7-17

G		Lift Mechanisms and	
General Tire Maintenance,		Controls	7-18
Inspection, and Repair	1-16	Load Handling	4-11
Grades, Ramps, Slopes,		Load Handling Components ...	7-14
and Inclines	1-11	Long and Wide Loads	
Ground Speed Control		/ Rear Swing	2-3
(acceleration)	3-13	Longitudinal Tip-over	1-13
H		Loose Loads	2-2
Horn	7-17	Low Overhead Clearance	
Horn Button	3-16	Fast Turns and High Loads	2-4
Hour Meter	3-16	Lubrication	7-25
Hour Meter	7-17	Lift Chain wear and	
How to Perform Planned		Replacement Criteriai	7-28
Maintenance	7-14	M	
How to Tow a Disabled Truck ..	6-2	Major Component Locations	7-8
How to Use Battery Jumper		N	
Cables	6-4	Neutral Start Switch	7-17
How to Use this Manual	viii	No Riders	1-5
Hydraulic Control Levers	3-17	Normal Operation	7-9
Hydraulic Fluid and Filter		O	
Change	7-24	Operating Safely	4-7
Hydraulic Fluid		Operator Compartment	3-3
Recommendation	8-4	Operator Daily Inspection	vii
Hydraulic Sump Tank	7-24	Optional Hydraulic Control	
I		Levers (Deck Mounted).....	3-13
Indicator Lights	7-18	Operator Safety Warning	
Instrument Pod	3-4	Decal	3-20
Introduction	vi	Operator/Tip-Over	3-20
Introduction	7-2	Overhead Guard	7-14
K		Operator Controls	3-14
Keep Away from Forks		P	
Decal	3-21	Pallets and Skids	2-8
Key/Start Switch	3-14	Parking	1-15
L		Parking Brake	7-18
Lateral Tip-over	1-13	Parking Brake.....	3-15
Lift Chain Inspection and		Parking Brake Lever.....	3-15
Measurement	7-28	Parking Brake Pedal.....	3-15
Lift Chain Lubrication	7-28	Pedestrians	1-6
Lift Chain Maintenance	7-27	Picking Up and Moving	
Lift Chain Wear and		Loads	4-13
Replacement Criteria	7-28	Pinch Points	1-9
Lift Chains	7-26	Planned Maintenance	vii
Lift Control Function	3-17	Planned Maintenance	

Intervals	7-9
PM Report Form	7-12
Positioning Forks and Upright ..	4-5
Powershift Transmission	8-3
Preferred Method of Inching ..	3-13

R

Refueling Gasoline and Diesel Trucks	5-5
Recommended Safety Maintenance Procedures For Lpg Fueled Lift Trucks	5-7
Refueling LPG Tanks	5-6
Right-Angle Stacking	2-6
Routine Servicing and Maintenance	vi

S

Safe Maintenance Practices	7-3
Safety Signs and Safety Messages	x
Seat Adjustment	3-15
Seat Belts	1-4
Steering Column Pylon	3-18
Steering Column Pylon	3-7
Service Brakes and Inching Pedal	7-18
Stacking	4-14
Standard Electrical System	8-3
Starting from a Safe Condition ..	4-3
Starting the Truck	4-4
Steering Column Pylon	3-18
Steering System	3-16
Stopping the Truck	3-13
Severe Operation	7-9
Steering System	7-19
Sump Tank Breather Maintenance and Inspection ..	7-25
Surface and Capacity	1-12

T

TA-30 Drive Axle	8-8
Tilt Control Lever	3-17
Tip-Over	1-13
Transaxle Fluid Check	7-25
Transmission Flued Travel	1-10

Traveling with a Load	4-12
Truck Chassis Inspection and Lubrication	7-25
Truck Data and Capacity Plate	3-19
Truck Description	3-2
Truck Weights	8-5
Two Pedal Control	3-11

U

Unitrol Pedal	3-11
Unloading	4-13
Upright and Tilt Cylinder Lubrication	7-26

V

Visual Checks	5-3
Visual Inspection	7-14

W

What to do in Case of a Tip-over	1-14
Wheels and Tires	8-4
Wheels and Tires	7-16



Additional copies of this manual may be purchased from
YOUR AUTHORIZED CLARK DEALER



CLARK® Material Handling
Company

Lexington, Ky. 40517
Printed in KOREA

